

Service Manual

- Sec. 1** General Description
- Sec. 2** Adjustment Procedures
- Sec. 3** Block / Schematic / Circuit Board Diagrams
- Sec. 4** Exploded Views & Replacement Parts Lists
- Sec. 5** VW-AD7


Panasonic Mini DV PAL

Digital Video Camera Recorder

AG-EZ15E

AC Adaptor

VW-AD7E



SPECIFICATIONS

ITEM	SPECIFICATION	ITEM	SPECIFICATION
POWER	Source: Battery Pack; 7.2 V DC AC Adaptor; 7.9 V DC	VIDEO	VIDEO OUTPUT LEVEL: 1.0 V _{p-p} , 75Ω (OUTPUT TERMINAL BOX, AV OUT)
	Consumption: During Camera Recording Using The LCD; 5.1 W During Camera Recording Using The Viewfinder; 4.3 W		S-VIDEO OUTPUT LEVEL; Y: 1.0 V _{p-p} , 75Ω C: 0.3 V _{p-p} , 75Ω (OUTPUT TERMINAL BOX)
RECORDING FORMAT	Digital Video SD Format	AUDIO	RECORDING FORMAT: PCM Digital Recording; 16 bit (48 kHz/2 ch) 12 bit (32 kHz/4 ch)
TAPE FORMAT	Mini DV Cassette Tape (Tape width 6.35 mm)		MIC IN LEVEL: -70 dBV, 5.6 kΩ (OUTPUT TERMINAL BOX) OUTPUT LEVEL: 316 mV, 600Ω (OUTPUT TERMINAL BOX, AV OUT)
TAPE SPEED	SP mode: 18.83 mm/s LP mode: 12.57 mm/s	DIGITAL STILL PICTURE	Digital Still Picture Output, Control Signal Input/Output (Transfer rate: max. 115 kbps)
	Record/ Playback Time SP mode: 80 min. with DVM80 LP mode: 120 min. with DVM80	DIGITAL INTERFACE	DV Output Terminal (i. LINK, 4 pin))
CAMERA	PICK-UP ELEMENT: CCD (Charge Coupled Device)	MICROPHONE	Stereo
	STANDARD ILLUMINATION: 1,400 lux	SPEAKER	1 round speaker ϕ 20 mm
	MINIMUM REQUIRED ILLUMINATION: 1 Lux	OPERATING TEMPERATURE	0-40°C
	LENS: 10 : 1 Power Zoom Focal Length: 3.6-36.0 mm Macro (Full Range AF), Auto Iris, F1.8 Filter Diameter: 30.5 mm	OPERATING HUMIDITY	10-80%
	IMAGE SENSOR: 1/4 inch CCD Image Sensor	WEIGHT	Approx. 440 g (without Battery Pack)
	VIEWFINDER: 0.5 inch Colour Electronic Viewfinder 2.5 inch Colour LCD Monitor	DIMENSIONS	Approx. 54 (W)×118 (H)×86 (D) mm
VIDEO	RECORDING FORMAT: Digital Component		
	TELEVISION SYSTEM: CCIR; 625 Lines, 50 Fields PAL Colour Signal		

Weight and dimensions shown are approximate.
Specifications are subject to change without notice

Panasonic

© 1999 Matsushita Electric Industrial Co., Ltd. All rights reserved.
Unauthorized copying and distribution is a violation of law.

WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product.

Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

INTRODUCTION

This Service Manual contains technical information such as General Description, Adjustment Procedures, Block Diagrams / Schematic Diagrams / C.B.A. Diagrams, Exploded Views / Parts Lists and Battery Charger VW-AD7E which service personnel to understand and service the Panasonic Digital Video Camera Recorder model AG-EZ15E.

Panasonic

CONTENTS

ADDENDUM	a-1
VTR Main C.B.A. and Chassis Unit.....	a-1
3. Preparation for Electrical Adjustment.....	a-1
3-1 Measuring Equipment.....	a-1
3-2. Adjustment System.....	a-1
3-3. Special Fixtures and Tools	a-3
3-4. PC EVR Software	a-4
3-5. VTR Main C.B.A. Replacement.....	a-6
Standard Accessories	a-7
Cassette Adaptor for DVCPRO	a-8
Optional Accessories.....	a-8
SERVICE INFORMATION.....	1
SECTION 1 GENERAL DESCRIPTIONS	1-1
SECTION 2 ADJUSTMENT PROCEDURE	2-1
SECTION 3 BLOCK/SCHEMATIC/CIRCUIT BOARD DIAGRAMS	3-1
SECTION 4 EXPLODED VIEWS & PARTS LIST	4-1
SECTION 5 VW-AD7E	5-1

INTRODUCTION

Caution for AC CORD (VJA0940 type)

Information for Your Safety

IMPORTANT

Your attention is drawn to the fact that recording of pre-recorded tapes or discs or other published or broadcast material may infringe copyright laws.

WARNING

To reduce the risk of fire or shock hazard, do not expose this equipment to rain or moisture.

CAUTION

To reduce the risk of fire or shock hazard and annoying interference, use the recommended accessories only.

FOR YOUR SAFETY

■DO NOT REMOVE THE OUTER COVER.

To prevent electric shock, do not remove the cover. No user serviceable parts inside. Refer servicing to qualified service personnel.



Caution for AC Mains Lead

For your safety, please read the following text carefully.

This appliance is supplied with a moulded three-pin mains plug for your safety and convenience.

A 5-ampere fuse is fitted in this plug.

Should the fuse need to be replaced please ensure that the replacement fuse has a rating of 5 amperes and it is approved by ASTA or BSI to BS1362.

Check for the ASTA mark  or the BSI mark  on the body of the fuse.

If the plug contains a removable fuse cover you must ensure that it is refitted when the fuse is replaced.

If you lose the fuse cover, the plug must not be used until a replacement cover is obtained.

A replacement fuse cover can be purchased from your local Panasonic Dealer.

If the fitted moulded plug is unsuitable for the socket outlet in your home then the fuse should be removed and the plug cut off and disposed of safely.

There is a danger of severe electrical shock if the cut off plug is inserted into any 13-ampere socket.

If a new plug is to be fitted please observe the wiring code as shown below.

If in any doubt, please consult a qualified electrician.

■IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:


Blue: Neutral

Brown: Live

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:


the wire which is coloured BLUE must be connected to the terminal in the plug which is marked with the letter N or coloured BLACK.

The wire which is coloured BROWN must be connected to the terminal in the plug which is marked with the letter L or coloured RED.

Under no circumstances should either of these wires be connected to the earth terminal of the three pin plug, marked with the letter E or the Earth Symbol .


■Before use

remove the Connector Cover as follows.




■How to replace the Fuse

1. Remove the Fuse Cover with a screwdriver.



2. Replace the fuse and attach the Fuse cover.



ADDENDUM

VTR Main C.B.A. and Mechanical Chassis

When a parts replacement on the VTR Main C.B.A. and Mechanical Chassis is required, please replace the assembly part (VTR Main C.B.A. and/or Mechanical Chassis Unit).

Page 3

3. Preparation for Electrical Adjustment

It describes recommendation of EVR adjustment system from Video Equipment Division.

The following electrical adjustment procedures are recommended by Video system division.

3. PREPARATION FOR ELECTRICAL ADJUSTMENT

3-1. Measuring Equipment

Dual Trace Oscilloscope	Voltage Range	-----	0.001 to 50V/Div
	Frequency Range	-----	DC to 100MHz
	Probes	-----	10:1 and 1:1
DVM (Digital Volt Meter)			
Frequency Counter	Frequency Range	-----	0 to 150MHz

3-2. Adjustment System

3-2-1. With Measuring Board VFK1308P

The VFK1308P has 2 types of RS-232C connectors (9pin D-sub connector and M3 RS-232C connectors). When using with the VFK1308P in the adjustment system, an ordinary 9-pin RS-232C straight cable can be connected between the measuring board and personal computer. In this case, the RS-232C select switch on the measuring board should be selected at D-sub position.

Other type which supplied from Video Equipment Division has only M3 RS-232C connector.




Fig. E1

3-2-2. System Hook up Procedures

1. Unscrew the screw and remove the EVR Cover as shown in Figure E2 .




Fig. E2

2. Connect the 2 pcs of 30 pin flat cables between P101 / P102 on the Measuring Board, and 2 connectors on the Connector Board.
Make sure that the contact surface of 2 pcs. of 30 pin Flat Cables are inner side and direction of the Connection Board is as shown in Figure E3.




Fig. E3

3. Set the Connector Board with the 30 pin Cables to the unit as shown in Figure E6..
Make sure that the direction of the Connection Board is correctly fit as shown in Figure E4.




Fig. E4

4. Connect the AC adaptor or set the Battery to the unit.
5. Connect an ordinary 9 pin RS-232C cable between the Measuring Board and RS232C connector on Personal Computer as shown in Figure E1.
8. Connect the 4 pin 6V/DC Power cable between AC adaptor or DC power supply unit.

3-2-3. Lighting System

1) In the camera room using halogen lamps.

The camera adjustments should be performed under the following lighting condition.

Colour Temperature	: 3100 K°
Lamination	: 2000 Lux

2) Using "TATSUJIN" light box

If the camera room or halogen lighting system is not available, "TATSUJIN" light box can be used as shown in Figure E5.




Fig. E5

3-4. Special Fixtures and Tools

In order to keep the factory adjustment specifications, the following special tools should be used to conduct mechanical, electrical adjustments and servicing.















VFM3010EDS Alignment Tape (Colour Bar) 	VFK1233 Tape End/Beg. Sensor. Cassette 	VFK1308P Measuring Board 	VFK1309 EVR Connector Board 
VFK1515 EVR Adjustment Software 	Ordinary 9pin RS-232C Cross Cable 	VFK1317 30pin Flat Cable 	VJA0941 DC Cable 
VFK1164TAR3A 30.5mm Attachment Ring 	VFK1164TCM01 Collimator Set (with Focus Chart) 	VFK1164TFCB1 Color Chart 	VFK1164TFGS1 Gray Scale Chart 
VFK1164TFWC1 White Chart 	VFK0374 C12 Color Conversion Filter 		

Fig. E6

3-5. PC EVR (Adjustment) Software

3-5-1. Boot Up the Adjustment Software

1. Power ON the Personal Computer.
Windows 95 is set up (AUTO).
2. Restart the PC in Dos mode.
3. Insert the EVR software floppy disk (VFK1515) into the FDD drive of the PC.

	Name of Directory (Folder)	Name of Execute File
AG-EZ15E	Agez15e	ex1. exe

4. Boot up the EVR program as the following steps.

- 1) Input "a :" and then press the "ENTER" key.

```
C:\WINDOWS>a:
      ↑
    Input
```

- 2) Input "cd \" and then press the "ENTER" key.

```
A:\ * * * * >cd \
      ↑
    Input
```

- 3) Input "cd agez15e" and press the "ENTER" key.

```
A: \>cd agez15e
      ↑
    Input
```

- 4) input "ex1" and then press the "ENTER" key.

```
AG-EZ10
A: \AGEZ15E>ex1
      ↑
    Input
```

- 5) Wait for a few seconds so that the EVR adjustment program is started.
- 6) For the adjustments, follow the program display.

3-5-2. How to Use the Main Menu

Select a Sub Menu to check, adjust the unit and etc. by pressing ↑ ↓ (UP/DOWN) Key in Main Menu. Then, press "ENTER" Key. The Sub Menu will be displayed.

Note: Menu (pages) 3 through 6 are needed for adjustment.




Fig. E7

With using ← → keys, also the menu can be changed.




Fig. E8

3-5-3. Introduction of the Sub Menu

1) Camera Check Menu




Fig. E9

2) Video Check Menu




Fig. E10

3) Camera Adjustment Menu




Fig.E11

4) Video Adjustment Menu




Fig. E12

5) LCD Adjustment Menu




Fig. E13

6) EVF Adjustment Menu




Fig. E14

3-5-4. Restoration of Connecting Error

This program checks connecting condition with the movie all the time.

When the movie power is off, or VTR is reset, or cable is disconnected during servicing, restart the program by pressing "CTRL" key and "BREAK" key together.

3-5-5. Waveform Illustration

This program displays the waveform illustration, when "F2" key is pressed in the adjustment mode.

Be sure to save both the EEPROM data into the personal computer before performing service and adjustment, in order to avoid any accidental data loss.

3-5-6. How to Save Camera EEPROM Data

- 1) Select "1. Check [Camera]." In the Main menu, and then press the "Enter" key.
- 2) Select "3. Read [Save]/Write All EEPROM data" in the Camera check menu, and then press the "Enter" key.
- 3) Select "5. Save all data of EEPROM" in Read [Save]/Write All EEPROM data menu, and then press the "Enter" Key.
- 4) Input the File name and, then press the "Enter" key. The data of EEPROM can be stored in the personal computer.

3-5-7. How to Save VTR EEPROM Data

- 1) Select "2. Check [Video]." In the Main menu, and then press the "Enter" key.
- 2) Select "3. Read [Save]/Write All EEPROM data" in the Video check menu, and then press the "Enter" key.
- 3) Select "2. Save all EEPROM data" in Read [Save]/Write All EEPROM data menu, and then press the "Enter" key.
- 4) Input the File name, and then press "Enter" key.
The data of EEPROM will be stored in the personal computer.

3-5-8. How to REWRITE Saved data

When it becomes impossible to adjust during service and adjustment, rewrite the saved data which stored in paragraphs 3-5-6., 3-5-7. to the EEPROM as follows. And readjust.

3-5-9. How Rewrite Camera Saved Data

- 1) Select "1. Check [Camera]." In the Main menu, and then press the "Enter" key.
- 2) Select "3. Read [Save]/Write All EEPROM data" in the Camera check menu, and then press the "Enter" key.
- 3) Select "6. Data write using stored file" in Read [Save]/Write All EEPROM data menu, and then press the "Enter" key.
- 4) Input the saved file name, and then press the "Enter" key.
- 5) The data can be written in the EEPROM.

3-5-10. How Rewrite Video C.B.A. Saved Data

- 1) Select "2. Check [Video]." In the Main menu, and then press the "Enter" key.
- 2) Select "3. Read [Save]/Write All EEPROM data" in the Video check menu, and then press the "Enter" key.
- 3) Select "3. Writing from the stored data files" in the Read [Save]/Write All EEPROM data menu, and then press "Enter" key.
- 4) Input the saved file name, and then press the "Enter" key.
- 5) The data will be written in the EEPROM .

3-6. VTR Main C.B.A. REPLACEMENT

3-6-1. Camera Data

In case that the VTR Main C.B.A. is replaced, be sure to write the data to Camera EEPROM on the VTR main C.B.A. as follows.

1. Select "1. Check [Camera]." In the Main menu, and then press the "Enter" key.
2. Select "3. Read [Save]/Write All EEPROM data" in the Camera check menu, and then press the "Enter" key.
3. Select "6. Data write using stored file" in the Read [Save]/Write All EEPROM data menu, and then press the "Enter" key. Input the saved file name, and then press the "Enter" key.
OR;
Select "7. Data write with Average data," and then press the "Enter" key. And press the "Enter" key once again.

3-6-2. VTR Data.

In case that the VTR Main C.B.A. is replaced, be sure to write the data to the EEPROM on the VTR Main C.B.A. as follows.

1. Select "2. Check [Video]." In the Main menu, and then press the "Enter" key.
2. Select "3. Read [Save]/Write All EEPROM data" in the Video check menu, and then press the "Enter" key.
3. Select "3. Writing from stored data files." In Read [Save]/Write All EEPROM data menu, and then press the "Enter" key. Input the saved file name, and then press the "Enter" key.
OR;
Select "4. Writing of fixed/average values," and then press the "Enter" key. And press the "Enter" key once again. Then, input ID Number as follows.

3-6-3. How to input ID Number

When writing the data to the EEPROM after replacing VTR Main C.B.A.;

When selecting "4. Writing of fixed/average values," ID Number needs to be input.

When selecting "3. Writing from stored data files," ID Number stored data file will be written automatically.

When writing ID Number from the saved data which is stored in 3-5-7.

1. Select "2. Check [Video]." In the Main menu, and then press the "Enter" key.
2. Select "3. Read [Save]/Write All EEPROM data" in the Video check menu, and then press the "Enter" key.
3. Select "5. Writing ID from the stored file." In Read [Save]/Write All EEPROM data menu, and then press the "Enter" key. Input the saved file name, and then press the "Enter" key.
The ID Number will be automatically written.

When the original ID information can not be read because of the destruction of EEPROM etc.:

1. Select "4. Adjust [Video]." In Main menu, and then press "Enter" key.
2. Select "9. Write products ID" in the Video adjustment menu, and then press the "Enter" key.
3. ID Number will be written automatically.


Note: The adjusted data has been written to the EEPROM after each adjustments.

Page 1-1.

Standard Accessories

It shows the standard accessories of NV-EX1(PAL)


The following list shows the accessories of AG-EZ15.



Standard Accessories

- | | | |
|---|---|--|
| <p>1. AC Adaptor (→ 18, 18, 140)
To supply power to the Movie Camera.
To charge the Battery.</p> <p>2. DC Input Cable (→ 16)
To connect the AC Adaptor to the Movie Camera.</p> <p>3. AC Mains Cables (→ 16, 18)
To connect the AC Adaptor to an AC mains socket.
[A] England and Hong Kong only
[B] Aress other England and Hong Kong</p> <p>4. Battery Pack (→ 18)
To supply the Movie Camera with power.</p> <p>5. Remote Controller and Button-Type Battery (→ 100, 108)</p> | <p>6. 21-pin Adaptor (→ 54, 114, 116, 118)</p> <p>7. Headphone Conversion Adaptor (→ 156)</p> <p>8. A. AV Cable (PHONO - M3)
(→ 54, 114)
B. AV Cable (PHONO - PHONO)
(→ 54, 114, 116, 118)
C. S-Video-Cable
(→ 54, 114, 116, 118, 120, 122)</p> <p>9. Output Terminal Box [AV ONE TOUCH STATION] (→ 54, 56, 112)
Equipped with AV Sockets, Edit Socket and Microphone Socket.</p> | <p>10. Hand Grip (→ 28)</p> <p>11. Hand Strap (→ 30)
Lens Cap Holder for Hand Strap (→ 30)</p> <p>12. Wide Conversion Lens (→ 190)</p> <p>13. ND Filter (→ 190)</p> <p>14. Mini DV Cassette (→ 22)</p> <p>15. Cassette Adaptor (→ 128)</p> <p>16. Cleaning Tissue
To clean the Lens and the LCD Monitor.</p> <p>17. Soft Bag (→ 58)
To store the Movie Camera when it is not being used or when you carry it.</p> |
|---|---|--|

The following shows the operating instruction of Cassette Adaptor for DVCPRO.



Cassette Adaptor

It can only be used with S cassettes bearing the DV mark.
It can only be used to play back DV cassettes which are recorded in format.

- 1 Take care to insert the cassette in the proper direction.
- 2 Open the Cassette Adaptor.
- 3 Insert the Cassette tape.
- 4 Close the Cassette Adaptor.


• Do not subject the cassette adaptor to strong shocks or vibration as it uses precision parts. Also, do not modify or disassemble the cassette adaptor. After use, remove the DV cassette and store it in its case.
• Do not push down A (rear door) using an unnecessarily large force.

Page 1-30.

Optional Accessories

It shows the optional accessories of NV-EX1(PAL)

The following list shows the optional accessories of AG-EZ15.



Optional Accessories

- | | | | |
|--------------------------|--------------------------|--------------------------|----------------------|
| ① Battery Pack (Lithium) | ⑤ Battery Pack (Lithium) | ⑨ Stereo Zoom Microphone | ⑬ Editing Controller |
| ② Battery Pack (Lithium) | ⑥ Car Adaptor Cord | ⑩ Shoe Adaptor | ⑭ Video Titler |
| ③ Battery Pack (Lithium) | ⑦ 5-Pin Synchro Cord | ⑪ Tripod | ⑮ Edit Cable |
| ④ Battery Pack (Lithium) | ⑧ Tele Conversion Lens | ⑫ Editing Controller | ⑯ DV Cable |

• Some accessories are not available in some countries.

Memo

Service Information

1. Service Extension Cables

Use the following extension cables when checking or adjusting individual circuit boards.

No.	Part No.	Pin	Part Name	Connection	Q'ty	Remarks
①	VFK1458	70	Flat Cable	PS2001 (VTR Main)-PP2001 (Drive)	1	
②	VFK1284	24	Flat Cable	FP3201 (VTR Main)-Head Amp	1	
③	VFK1442	21	Flat Cable	FP601 (VTR Main)-FP903 (Monitor)	1	
④	VFK1442	21	Flat Cable	FP602 (VTR Main)-FP904 (Monitor)	1	
⑤	VFK1442	21	Flat Cable	FP701 (VTR Main)-Lens Flex.	1	
⑥	VFK1459	39	Flat Cable	FP4201 (VTR Main)-FP4001 (Mic Unit)	1	
⑦	VFK1460	20	Flat Cable	PS201 (VTR Main)-PP291 (CCD)	1	
⑧	VFK1461	20	Flat Cable	FP801 (VTR Main)-E.V.F. (A)	1	
⑨	VFK1462	70	Flat Cable	PS301 (VTR Main)-PP3401 (Operation I/F)	1	
⑩	VFK1463	90	Flat Cable	PP1001 (VTR Main)-PS1001 (Power)	1	
⑪	VFK1464	7	Flat Cable	FP3301 (VTR Main)-AV Jack	1	
⑫	VFK1441	8	Flat Cable	FP2204 (VTR Main)-Mecha. Flex.	1	
⑬	VFK1465	5	Flat Cable	FP6303 (VTR Main)-Cassette Down Flex.	1	
⑭	VFK1443	18	Flat Cable	FP2203 (Drive)-Mecha. Flex.	1	
⑮	VFK0977	20	Flat Cable	FP6001 (VTR Main)-Rear Operation U.	1	
⑯	VFK1440	10	Flat Cable	FP6302 (Operation I/F)-VTR Operation U.	1	
⑰	VFK1364	14	Flat Cable	FP1001 (Power)-Battery Catcher	1	
⑱	VFK1480	6	Flat Cable	FP6702 (Operation I/F)-Zoom Operation U.	1	
⑲	VFK1443	18	Flat Cable	FP2201 (Drive)-Mecha. Cap.	1	
⑳	VFK1440	10	Flat Cable	FP2202 (Drive)-Mecha. Cyl.	1	

2. Service Position




Fig. T1

3. Preparation for Electrical Adjustment

Remove Screw and EVR Cover which is located on the Side Case Unit as follows.




Fig. E1

Then connect the following cables as shown in Fig. E2.

Part No.	Part Name	Q'ty	Remarks
VFK1395	232C (M3) I/F Cable	1	
VFK1308E	Measuring Board	1	
VFK1309	EVR Connector Board	1	
VFK1317	30 Pin Flat Cable	2	
VJA0941	DC Output Cable	1	For AC Adaptor
VFK1164TAR3A	Setup Ring (φ30.5 mm)	1	For Collimator




Fig. E2





Fig. E3

4. Service Mode

When undesirable conditions occurred, the error code is displayed on the EVF or LCD Monitor.
Also, the Camera LED is flashed according to the error code as follows.



DISPLAY	CONDITION	POWER OFF TIMING / POWER LED FLASHING TIMING
F01	T-Reel Lock	After 1 minute flashing the LED
F02	S-Reel Lock	After 1 minute flashing the LED
F03	Unloading Lock	After 1 minute flashing the LED
F04	Loading Lock	After 1 minute flashing the LED
F05	Cylinder Lock	After 1 minute flashing the LED
F31	Data Transmission Error	Not turning OFF
F51	Focus Motor Lock	Not turning OFF Power LED is flashed at 1 Hz timing
F52	Zoom Motor Lock	Not turning OFF Power LED is flashed at 1 Hz timing
U10	Dew Detection	After 18 seconds flashing the LED Power LED is flashed at 1 Hz timing
U11	Head Clogging	Not turning OFF

5. How to replace the Lithium Battery (Procedure)

1. Remove the 7 Screws. (See Fig. B1)
2. Open the Rear Operation Unit.
3. Unsolder the Lithium Battery "VL1220/1FC" and then replace the new one. (See Fig. B1)




Fig. B1

NOTE:

The lithium battery is a critical component (Type No.: VL1220/1FC Manufactured by Panasonic.)
It must never be subjected to excessive heat or discharge.
It must therefore only be fitted in equipment designed specifically for its use.
Replacement batteries must be of the same type and manufacture.
They must be fitted in the same manner and location as the original battery, with the correct polarity contacts observed.
Do not attempt to re-charge the old battery or re-use it for any other purpose.
It should be disposed of in waste products destined for burial rather than incineration.

CAUTION

Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type recommended by the equipment manufacturer.
Discard used batteries according to manufacturer's instructions.

VARNING

Explosionsfara vid felaktigt batteribyte.
Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren.
Kassera använt batteri enligt fabrikantens instruktion.

ADVARSEL!

Lithiumbatteri - Eksplosionsfare ved fejlagtig håndtering.
Udskiftning må kun ske med batteri af samme fabrikat og type.
Levér det brugte batteri tilbage til leverandøren.


VAROITUS

Paristo voi räjähtää, jos se on virheellisesti asennettu.
Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.


SECTION 1

GENERAL DESCRIPTIONS

Controls and Components

- 1 Reverse Search Button [←SEARCH] (→ 58)
Rewind/Review Button [←4] (→ 48)
Recording Check Button [RE] (→ 34)
- 2 Forward Search Button [SEARCH+] (→ 58)
Fast Forward/Cue Button [▶▶] (→ 48)
- 3 Fade Button [FADE] (→ 68)
Stop Button [■] (→ 46)
- 4 White Balance Button [W.B.] (→ 82, 84)
Pause Button [II] (→ 52)
- 5 Backlight Button [BLC] (→ 34)
Play Button [▶] (→ 46, 48)
- 6 Focus Button [FOCUS] (→ 86)
- 7 Microphone (built-in, stereo)
- 8 MC Protector (→ 156)
To protect the lens against getting damaged.
- 9 Lens
- 10 Recording Lamp (→ 32)
- 11 DV Terminal (i.LINK) [i] 
To output digital signals.
Connect it to digital video equipment.
"i.LINK" is the name of the connector in accordance with the International Standard IEEE1394-1995.
"i" is the logo marked on products conforming with the "i.LINK" specifications.
Inputting digital signals into this Movie Camera is not possible.
- 12 White Balance Sensor (→ 164)
Remote Control Sensor (→ 110)
- 13 Battery Holder Cover
When attaching the Battery or connecting the DC Input cable, remove this cover.










-10-



- 14 Menu Button [MENU] (→ 128)
- 15 Power Lamp
- 16 Selector Switch for Camera Mode/Power Off/VCR Mode [POWER] (→ 26, 32, 46, 56)
- 17 Recording Start/Stop Button (→ 32)
- 18 Photoshot Button [PHOTO SHOT] (→ 40)
- 19 Battery Eject Lever [BATT. EJECT] (→ 18)
- 20 Speaker (→ 46)
- 21 Audio-Video Output Socket [AV OUT] (→ 54, 114, 156)
When a cable is connected to this socket, the Movie Camera's built-in speaker is turned off.
- 22 LCD Monitor (→ 26)

Due to limitations in LCD production technology, there may be some tiny bright or dark spots on the LCD Monitor screen. However, this is not a malfunction and does not affect the recorded picture.
- 23 Multi-Function Dial [PUSH] (→ 46, 48, 52, 86, 88, 90, 128)
- 24 Battery Holder


-12-

1. 	2. 	3. 
4. 	5. 	6. 
7. 	8. 	9. 

Standard Accessories

1. AC Adaptor (→ 16, 18, 140)
To supply power to the Movie Camera.
To charge the Battery.
DC Input Cable and AC Mains Cable (→ 16, 18)
To connect the AC Adaptor to the Movie Camera and to an AC mains socket.
2. Battery Pack (→ 18)
To supply the Movie Camera with power.
3. Remote Controller and Button-Type Battery (→ 100, 108)
4. Output Terminal Box [AV ONE TOUCH STATION] (→ 54, 56, 112)
Equipped with AV Sockets, Edit Socket, Digital Still Picture Terminal and Microphone socket
5. A. 21-pin Adaptor (→ 54, 114, 116, 118)
B. Headphone Conversion Adaptor (→ 156)
6. A. AV Cable (PHONO - M3) (→ 54, 114)
B. AV Cable (PHONO - PHONO) (→ 54, 114, 116, 118)
C. S-Video-Cable (→ 54, 114, 116, 118, 120, 122)
7. Hand Grip (→ 28)
8. A. Hand Strap (→ 30)
B. Lens Cap Holder for Hand Strap (→ 30)
9. Cleaning Tissue
To clean the Lens and the LCD Monitor.

-8-



The 3 Types of Power Supplies

- 1) AC Adaptor (supplied) to supply power from an AC mains socket
- 2) Car Adaptor Cord (optional) to supply power from a Cigarette Lighter Socket
- 3) Battery (supplied) (→ 18)

■ Supplying Power from an AC Mains Socket

- 1 Insert the battery-shaped connector of the DC Input Cable into the Battery Holder on the Movie Camera and slide it toward the front until it locks with a click.
- 2 Connect the other plug of the DC Input Cable to the [DC OUT] Socket on the AC Adaptor.

3 Connect the AC Mains Cable to the AC Adaptor.

4 Connect the other end of the AC Mains Cable to an AC mains socket.


- Before disconnecting the AC Mains Cable, set the [POWER] Switch on the Movie Camera to [OFF].
- If you use the Movie Camera for a long time, it becomes warm. However, this is normal.

■ Supplying Power from the Cigarette Lighter Socket in a Car

The use of the Car Adaptor Cord (VW-KA7E; optional) together with the AC Adaptor makes it possible to supply power to the Movie Camera in a car for recording and playback. It also allows charging the Movie Camera's Battery.

- After use, be sure to disconnect the Car Adaptor Cord from the Cigarette Lighter Socket.
- Be sure to start the car engine before you connect the Car Adaptor Cord, otherwise the fuse may blow.
- Also read the operating instructions of the Car Adaptor Cord.

-16-



■ Supplying Power with the Battery

Before use, fully charge the Battery.

- 1 Place the Battery on the AC Adaptor as shown above and slide it horizontally until it stops.
- 2 Connect the AC Mains Cable to an AC mains socket.
- 3 When all three Charge Lamps on the AC Adaptor are lit, charging is finished.

- The Charge Lamps [50%], [80%] and [100%] flash and then remain lit one after another. These lamps indicate the approximate charging condition reached.

- 4 Remove the Battery by sliding it in the opposite direction of Step 1 above. Also disconnect the AC Mains Cable.

5 After aligning the front edge of the Battery with the mark ① at the bottom edge of the Movie Camera, push it in and then slide it toward the front until it locks with a click.

Removing the Battery from the Movie Camera
While pressing the [BATT. EJECT] Lever ②, slide the Battery toward the rear and then remove it.


- Be careful not to drop the Battery by accident.
- Before removing the Battery, set the [POWER] Switch to [OFF].

Charging Two Batteries

If you attach two Batteries to the AC Adaptor, they will be charged one after the other. To charge, follow Steps 1 - 3.

- Charging starts from Battery 1. At this time, the Charge Lamps for Battery 2 show the remaining charge in the Battery 2. (If the remaining charge is less than 50%, no Charge Lamp is lit.)

-18-



- 25 Zoom Lever [W/T] (→ 38)

- 26 Mode Selector Switch [AUTO/MNL/AE SELECT] (→ 32, 70, 82, 84, 86, 88, 90)

- 27 Eyecup

- 28 Finder (→ 26)

Due to limitations in LCD production technology, there may be some tiny bright or dark spots on the Finder screen. However, this is not a malfunction and does not affect the recorded picture.

- 29 Eyepiece Corrector Knob (→ 26)

- 30 Cassette Compartment Open Lever [CASSETTE DOOR OPEN] (→ 22)

- 31 Upper Cassette Compartment Cover (→ 22)

- 32 Hand Strap Holder (→ 30)

- 33 Tripod Receptacle

To mount the Movie Camera on an optional tripod.

- 34 Multi Terminal (→ 112)

- 35 Cassette Compartment Window (→ 22)


- 36 Cassette Holder (→ 22)


- 37 Cassette Eject Button [Δ/EJECT] (→ 22, 56)

- 38 Lower Cassette Compartment Cover (→ 22)

- 39 Lens Cap (→ 30, 56, 84)

-14-





Charging Time and Maximum Time for Continuous Recording

Battery No.	Charging Time	Max. Continuous Recording Time
CGR-D110 (Supplied)	1 h 20 min	1 h 5 min (55 min)
CGR-D120	1 h	1 h 15 min (1 h 5 min)
CGR-D210	1 h 50 min	2 h 10 min (1 h 55 min)
CGR-D220	2 h	2 h 40 min (2 h 20 min)
CGR-D815	5 h 20 min	9 h (7 h 40 min)


(The times shown in the above chart are approximations. The figures in parentheses show the recording time when using the LCD Monitor.)
The times listed above for your information indicate the duration of recording performed at an ambient temperature of 20°C and 60% relative humidity. The charging time may be longer when you charge the Battery at higher or lower temperature.
• During use and Battery charging, the Battery and the Movie Camera's body will become warm. This is not a malfunction.

- When you repeatedly stop and restart recording, the recording time per Battery is shorter than listed above.
- If you do not use the Battery for a long time, please read "Precautions for Storage" (→ 154).

When the Charge Lamps Flash as Warning
If the ambient temperature is extremely low or extremely high, the Charge Lamps on the AC Adaptor flash. They also flash when some malfunction has occurred in the Battery or the AC Adaptor. For details, read "When the Charge Lamps on the AC Adaptor Flash as Warning" (→ 152).

Using Optional Batteries Equipped with Charge Confirmation Marker

You can use this marker to easily distinguish between charged and discharged Batteries.
For example, slide the knob so that the red dot (●) is visible after the charging is completed.
(The Battery CGP-D110 is not equipped with a Charge Confirmation Marker.)



Inserting the Cassette

- Slide the [CASSETTE DOOR OPEN] Lever (1) to the left and simultaneously open the Lower Cassette Compartment Cover completely.
- Press the [EJECT] Button (2). The Cassette Holder slides out.
- Insert the cassette with its window in position (3) shown above.
- Press on the [PUSH CLOSE] mark to close the Upper Cassette Compartment Cover. The Cassette Holder with the cassette slides back inside. Confirm that the Cassette Holder has retracted completely.
- Close the Lower Cassette Compartment Cover.

- If the AC Adaptor or Battery is used to supply power, it is possible to insert or eject the cassette without turning on the Movie Camera.
- When inserting the cassette, make sure it faces in the right direction and then push it in until it stops.
- When you insert a cassette onto which you have recorded before, use the Camera Search Function (→ 58) to search for the position from which you want to continue recording.
- When you insert a new cassette, rewind the tape to the beginning before starting to record.
- **Preventing Accidental Erasure of Recordings**
Opening the cassette's erasure prevention slider (4) (sliding it in the direction of the [SAVE] arrow) prevents recording. To record again, close the erasure prevention slider (slide it in the direction of the [REC] arrow).

If the Cassette Holder Does Not Slide Back In

- Press on the [PUSH CLOSE] mark and close the Upper Cassette Compartment Cover securely.
- Turn the Movie Camera off and then on again.
- Check if the Battery is discharged.

If the Cassette Holder Does Not Slide Out


- Close the Lower Cassette Compartment Cover completely and then open it again.
- Check if the Battery is discharged.

LP Mode

The desired recording speed can be selected with [REC SPEED] on the [CAMERA MENU2] Menu.

If you select the LP Mode, the possible recording time is 1.5 times as long as in the SP Mode. Recording in the LP mode does not deteriorate the picture quality. However, the playback picture may contain mosaic-like patterns and certain functions may be restricted.

- In the following cases, mosaic-like patterns may appear in the playback picture, or the picture may not be played back correctly:
 - When a cassette recorded in the LP Mode on this Movie Camera is played back on other digital video equipment.
 - When a cassette recorded in the LP Mode on other digital video equipment is played back on this Movie Camera.
 - When a cassette recorded in the LP Mode on this Movie Camera is played back on digital video equipment not featuring the LP Mode.
 - In the Slow Motion or Still Advance Playback Mode. (→ 50, 52)
 - When using the Camera Search Function. (→ 58)
- As the recording track width in the LP Mode is smaller than the head width, recording new sound onto an already recorded cassette (audio dubbing) (→ 96) is not possible.



Using the Finder

Before using the Finder, adjust it to your eyesight so that the indications in the Finder are clear and easy to read.

- 1 Set the [POWER] Switch to [CAMERA] or [VCR].
Turn the switch while pressing the button ①.
- 2 Slide the Finder backward.
- 3 Adjust by sliding the Eyepiece Corrector Knob ②.

It is also possible to adjust the brightness of the Finder with the item [LCD/EVF SET] on the [CAMERA MENU3] Menu or [VCR MENU2] Menu. (→ 142)

Using the LCD Monitor

You can also record while viewing the picture on the opened LCD Monitor.

- 1 Set the [POWER] Switch to [CAMERA] or [VCR].
Turn the switch while pressing the button ③.
- 2 Open the LCD Monitor.
The Finder turns off.
- 3 Adjust the Angle according to the recording angle.


• The LCD Monitor rotates upward a maximum of 180° ④ and downward by a maximum of 90° ⑤ from its normal vertical position. Trying to forcefully rotate it beyond this range could seriously damage the Movie Camera.

• It is also possible to adjust the colour saturation and brightness of the LCD Monitor with the item [LCD/EVF SET] on the [CAMERA MENU3] Menu or [VCR MENU2] Menu. (→ 142)

Closing the LCD Monitor

After use, turn the LCD Monitor upright and close it securely.

-26-



Attaching the Hand Grip

The Hand Grip ensures reduced hand fatigue even during longer recording, and the integrated Grip Belt protects the Movie Camera against accidental falls.

- 1 Place the Hand Grip on the side and bottom of the Movie Camera so that the Hand Grip's screw is aligned with the tripod receptacle.
- 2 Tighten the screw by turning it in the direction of [LOCK].

- 3 Pass your hand through the Grip Belt in the direction indicated by the mark ① and adjust its length.

- 4 Fold up the end of the Grip Belt to securely fasten the velcro tape closure.


Before attaching the Output Terminal Box [AV ONE TOUCH STATION] to the Movie Camera, detach the Hand Grip.

• When inserting and taking out the cassette, turn the Hand Grip as shown above ② so that it does not prevent the Upper Cassette Compartment Cover from opening.

• When using the Movie Camera, also loop the Hand Strap (→ 30) around your wrist for added safety, before passing your hand under the Grip Belt.

• To carry the Movie Camera, do not hold it only by the Hand Grip.

-28-



Attaching the Hand Strap

Attaching the Hand Strap makes it convenient to carry the Movie Camera.

- 1 Pass the longer loop of the Hand Strap through the larger hole ① of the Lens Cap Holder.
- 2 Pass the shorter loop of the Hand Strap through the smaller hole ② of the Lens Cap Holder.
- 3 Pull the small loop at the end of the Hand Strap through the Hand Strap Holder.

- 4 Pass the big loop of the Hand Strap through the small loop.

When using the Hand Strap to carry the Movie Camera, loop the Hand Strap around your wrist and be careful not to accidentally hit the Movie Camera against hard objects.

Handling the Lens Cap

Before you start recording, remove the Lens Cap.

- 5 Attach the removed Lens Cap either to the Lens Cap Holder on the Grip Belt ③ or on the Hand Strap ④.

When not actually recording, always attach the Lens Cap to the Lens to protect it.

-30-

Checking If the Picture Is Recorded (Recording Check)

To play back the final few seconds of the last recorded scene in the Recording Pause Mode.

- 1 Press the Recording Check Button [CHK] briefly in the Recording Pause Mode.

The [CHK] Indication ② appears. After checking, the Movie Camera returns to the Recording Pause Mode.

- For Recording Check, the Movie Camera must be in the same mode (SP or LP) as used for recording, otherwise the playback picture is distorted.

Recording Backlit Scenes (Backlight Compensation)

To prevent the backlit subject from being recorded very dark.


(Backlight means that the light falls on the subject from behind, i.e. the subject is between the light source and the Movie Camera.)

- 1 Keep the Backlight Button [BLC] pressed.

The backlight is being compensated as long as you keep the Button pressed, and the subject is recorded more brightly. (The picture brightens up as a whole.)

Returning to Normal Recording
Release the Backlight Button [BLC].

-34-



Recording Yourself (Recording with the LCD Monitor Facing Forward)

This makes it possible to record yourself while viewing the picture on the LCD Monitor or to show the persons in front of the Movie Camera the picture being recorded.

- 1 Open the LCD Monitor and turn it so that it faces forward (lens side).

Opening the LCD Monitor automatically turns off the Finder. However, when you turn the LCD Monitor forward, the picture also appears in the Finder.

This lets you aim the Movie Camera and view the picture in the Finder, while the persons in front of the Movie Camera can check the picture on the LCD Monitor during recording.

Mirror Mode


If you set [SELF-SHOOT] on the [CAMERA MENU3] Menu to [MIRROR], the picture displayed on the LCD Monitor is reversed like a mirror-image. When recording yourself with the LCD Monitor facing forward, the picture as it is being recorded might look unusual. We usually look at ourselves in the mirror and, although the image we see there is actually reversed right and left, it feels more natural because we are used to it. This Movie Camera features the Mirror Mode which displays the picture as a mirror-image. However, even if you have selected the Mirror Mode, the picture is recorded in the normal way.

- In the Mirror Mode, only the following indications are displayed.

- [RECORDING] : Recording
- [PAUSE] : Recording Pause
- [BATT] : Remaining Battery Power

When the General Warning/Alarm Indication [!] appears, turn the LCD Monitor backward so that you can confirm the actual Warning/Alarm Indication.

-36-



Recording

After setting the [POWER] Switch to [CAMERA] and the Mode Selector Switch to [AUTO], you can simply press the Start/Stop Button to start recording. In this case, the Movie Camera adjusts the focus and white balance fully automatically.

- Depending on the light source and recording situation, correct automatic focusing and white balance adjustment may not be possible. In such cases, adjust them manually.

Focus: (→ 86); White Balance: (→ 82, 84)

- 1 Set the [POWER] Switch to [CAMERA].

Turn the switch while pressing the button ①.

- 2 Press the Start/Stop Button.

Recording starts. The [RECORD] Indication appears briefly and then changes to [REC] ②.

To pause recording:
Press the Start/Stop Button again. ③

The [PAUSE] Indication appears.

To finish recording:
Set the [POWER] Switch to [OFF].

Turn the switch while pressing the button ①.


- If you leave the Movie Camera in the Recording Pause Mode for more than 5 minutes, it automatically switches off to protect the tape and to conserve battery power. To resume recording from this condition, set the [POWER] Switch to [OFF] and then to [CAMERA] again.


Recording Lamp (Tally Lamp)

The Recording Lamp lights ④ during recording to let the people in front of the Movie Camera know that recording is being performed.

If you set [REC LAMP] on the [CAMERA MENU3] Menu to [OFF], the Recording Lamp does not light.

-32-





Recording with zoom function (Zooming In/Out)

Recording close-ups of your subjects and recording wide-angle shots add special effects to your videos.

- 1 Slide the [W/T] Zoom Lever toward [T] to zoom in on a subject, and toward [W] to zoom out.

- The Zoom Magnification Indication appears for a few seconds.
- The farther you slide the [W/T] Zoom Lever toward [W] or [T], the faster the zooming speed becomes.
- During recording, the zooming speed is lower than during recording pause.

Enlarging Your Subjects Even More (Digital Zooming)

If you set [EFFECT1] on the [CAMERA MENU1] Menu to [Z] & [ZOOM] or [ZOOM], it is possible to further enlarge the subject.


- The [D-ZOOM] Indication appears.
- 20X: Digital zooming up to 20X.
- 100X: Digital zooming up to 100X.
- Up to 10X, the Zoom Magnification is done optically.
- The higher the Digital Zoom Magnification, the lower is the picture quality.
- For the item [D-ZOOM] on the [CAMERA MENU1] Menu, you can select either [20X] or [100X] as the maximum zoom magnification.
- The Digital Zoom Function only works when [EFFECT1] on the [CAMERA MENU1] Menu is set to [Z] & [ZOOM] or [ZOOM].

Recording Extra Close-up Shots of Small Subjects (Macro Close-up Function)

When the zoom magnification is 1X, the Movie Camera can focus on subjects down to a distance of approximately 35 mm between lens and subject. This allows recording very small subjects such as insects.

- When you have zoomed to the tele setting, precise focusing is only possible on subjects no closer than 1.2 metres.

-38-



Using the Movie Camera as a Digital Still Camera (Photoshot)


With this function, you can record still pictures with sound for approximately 7 seconds each. This function is convenient for example for pictures that you want to print on a Video Printer.

- 1 Press the [PHOTO SHOT] Button. (This function can be used during recording, too.)

The Movie Camera records a still picture for approximately 7 seconds and then switches over to the Recording Pause Mode.

- If you set [SHTR EFFECT] on the [CAMERA MENU2] Menu to [ON], the screen blinks briefly and a simulated shutter click sound can be heard when you press the [PHOTO SHOT] Button. This audiovisual effect is also recorded.
- With the still pictures that you have recorded in the Photoshot Mode, you can do the following:
 - Index Search (→ 62, 64)
 - (However, searching for the picture(s) recorded at the beginning of the tape may not be possible.)
 - Automatic printing (→ 122)

-40-



- The visual shutter effect and click sound may occur with slight delay after recording of the still picture has started.
- The picture quality deteriorates slightly.

Continuous Photoshot

If you set [SHTR EFFECT] on the [CAMERA MENU2] Menu to [ON] and keep the [PHOTO SHOT] Button pressed (either in the Recording Pause Mode or during recording), the Movie Camera automatically records still pictures successively at intervals of approximately 0.7 second until you release the button.

- One more still picture may be recorded after you release the [PHOTO SHOT] Button.
- As the still pictures recorded in the Continuous Photoshot Mode are not marked with photoshot index signals, they cannot be located by using the Photoshot Index Search Function and printed with the Auto Print Function.

Recording in the Cinema Mode (Cinema Mode)

This mode lets you record in the cinema-like wide-screen format.

- 1 Press the [MENU] Button. The [CAMERA MENU1] Menu appears.
- 2 Turn the [PUSH] Dial to select [MENU2].
- 3 Press the [PUSH] Dial to select [YES]. The [CAMERA MENU2] Menu appears.


- 4 Turn the [PUSH] Dial to select [CINEMA].

- 5 Press the [PUSH] Dial to select [ON]. Black bars appear at the top and bottom on the screen. ①

- 6 Press the [MENU] Button to exit the Menu.

Cancelling the Cinema Mode
Set [CINEMA] on the [CAMERA MENU2] Menu to [OFF].

-42-



Recording with Minimised Camera Shake (Super Image Stabilizer)

In recording situations where shaking of the Movie Camera is likely to happen, for example when you have zoomed in on a distant subject or when you record while walking, you can use this function to stabilize the image.

- In case of very strong camera shake, it may not be possible to stabilize the picture.

- 1 Press the [MENU] Button.
The [CAMERA MENU1] Menu appears.
- 2 Turn the [PUSH] Dial to select [EFFECT1].
- 3 Press the [PUSH] Dial to select [ZOOM] or [ZOOM].

- 4 Press the [MENU] Button to exit the Menu.
The [ZOOM] Indication 1 appears.

- In a dimly lit place, the Super Image Stabilizer Function may not work. In this case, the [ZOOM] Indication flashes.
- Under fluorescent lamps, the picture brightness may fluctuate and the colours may be unnatural.
- After-image distortion may occur.
- When you use a tripod, we recommend to turn the Super Image Stabilizer Function off.

Cancelling the Super Image Stabilizer Function
Set [EFFECT1] on the [CAMERA MENU1] Menu to [OFF].

Viewing the Just Recorded Scenes (Playback)

You can play back recorded scenes right after recording.

- 1 Set the [POWER] Switch to [VCR].
- 2 Press the Rewind Button [◀] to rewind the tape.
- 3 Press the Play Button [▶] to start playback.

To stop playback:

- Press the Stop Button [■].
- If a cassette recorded with copyright protection signal is played back, the screen becomes black.


- **Adjusting the Sound Volume**
Keep the [PUSH] Dial 2 pressed until the [VOLUME] Indication 3 appears. Then, turn the [PUSH] Dial to adjust the volume. After adjusting, press the [PUSH] Dial to make the [VOLUME] Indication disappear.
- To adjust the volume with the Remote Controller, press the [T] or [W] Button to make the [VOLUME] Indication appear. You can then increase the volume by pressing the [T] Button or decrease it by pressing the [W] Button. A few seconds after finishing the adjustment, the [VOLUME] Indication disappears.

Repeat Playback

- If you keep the Playback Button [▶] pressed for more than 5 seconds, the Movie Camera switches over to the Repeat Playback Mode and the [R ▶] Indication appears. To cancel the Repeat Playback Mode, set the [POWER] Switch to [OFF].

Making the Date/Time Indication Appear

This Movie Camera automatically records the date and time, however not directly in the picture but as part of the sub code (→ 158).
To make the Date/Time Indication appear, set [DATE/TIME] on the [VCR MENU1] Menu to the desired setting.



Searching for a Scene That You Want to Play Back

Cue Playback 1
Keep the Cue Button [▶▶] 1 pressed during playback.

Review Playback 2
Keep the Review Button [◀◀] 2 pressed during playback.

Search Lock Function

For longer Cue or Review Playback, press the Cue Button [▶▶] or the Review Button [◀◀] only briefly. As this locks the search function, you do not need to keep the button pressed for a long time.

- To resume normal playback, press the Play Button [▶].
- In Cue and Review Playback, pictures with fast-moving subjects may contain mosaic-like patterns.

Hyper Check Function

If you press the Fast-forward Button [▶▶▶] during fast-forwarding of the tape or the Rewind Button [◀◀◀] during rewinding of the tape, Cue Playback or Review Playback continues for as long as you keep the Button pressed.

- At the beginning and end of Cue Playback or Review Playback, some momentary picture distortion may occur.


Variable Speed Search Function 3
It is possible to change the speed of Cue Playback or Review Playback.

- 1 Press the Play Button [▶] during playback.
- 2 Turn the [PUSH] Dial to select the desired search speed.

The Variable Speed Search function offers a choice of five playback speeds (1X, 2X, 5X, 10X, 20X) both in forward direction and reverse direction.

Returning to Normal Playback

- Press the Play Button [▶]. Playback continues at normal speed.
- During Variable Speed Search (except at 1X speed in forward direction), mosaic-like patterns appear in the picture.
- When using the Variable Speed Search Function, the sound is muted.



Playing Back in Slow Motion (Slow Motion Playback)

- 1 Press the Play Button [▶].
- 2 Press the Slow Motion/Still Advance Button [◀] or [▶] on the Remote Controller.
Pressing the [◀] Button starts slow motion playback in reverse direction, and pressing the [▶] Button starts slow motion playback in forward direction.


Scenes recorded in the SP Mode are played back at approximately 1/5th of the normal speed.
Scenes recorded in the LP Mode are played back at approximately 1/3rd of the normal speed.

- During slow motion playback in reverse direction, the Time Code Indication may not be accurate.

Resuming Normal Playback

Press the Play Button [▶].
Playback continues with normal speed.

-50-



Playing Back Still Pictures and Advancing Them One by One (Still Playback/Still Advance Playback)

You can freeze the action during playback and advance the still pictures one by one.

- 1 Press the Play Button [▶].
- 2 Press the Pause Button [⏸].
The playback picture stops in the Still Playback Mode.
- 3 Press the Slow Motion/Still Advance Button [◀] or [▶] on the Remote Controller.
Pressing the [◀] Button advances the still picture frame by frame in reverse direction. Pressing the [▶] Button advances the still picture frame by frame in forward direction.

- Each press of the [◀] Button advances to the next still picture in reverse direction. Each press of the [▶] Button advances to the next still picture in forward direction. Keeping either button pressed continuously advances the still picture frame by frame until you release the button.
- If you leave the Movie Camera in the Still Playback Mode for more than 5 minutes, it switches over to the Stop Mode to protect the video heads against excessive wear.
- During Still Advance Playback, the Time Code Indication may not be accurate.


Resuming Normal Playback

Press the Play Button [▶].
Playback continues with normal speed.

Using the Jog Dial (Jog Playback)

By turning the Jog Dial ([PUSH] Dial) ① on the Movie Camera in the Still Playback Mode, you can advance the still pictures one by one in forward or reverse direction.

-52-



Playing Back on a TV

(With the Output Terminal Box [AV ONE TOUCH STATION] Attached)

Attaching the Output Terminal Box [AV ONE TOUCH STATION] to the Movie Camera makes it possible to play back recorded scenes on a TV.

- 1 Attach the Output Terminal Box [AV ONE TOUCH STATION]. (→ 112)
- 2 Connect the Video and Audio output Socket on the Output Terminal Box [AV ONE TOUCH STATION] with the S-Video Input Sockets on the TV.
Use the AV Cable (PHONO-PHONO) ① and 21-pin Adaptor ② to connect to the TV. If your TV is equipped with an S-Video Socket, also connect the S-Video Cable ③.

Easy Playback on a TV


Instead of connecting the Movie Camera to the TV through the Output Terminal Box [AV ONE TOUCH STATION], as described in step 2 above, you can use the AV Cable (PHONO-M3) ④ to connect [AV OUT] on the Movie Camera directly to the Video and Audio Input Sockets on the TV.

- Before connecting, turn off both the Movie Camera and the TV.
- If a cassette recorded with copyright protection signal is played back, the screen becomes black. However, scenes recorded with this Movie Camera do not contain a copyright protection signal.

Making the Indications Appear on the TV Screen

Press the [OSD] Button ⑤ on the Remote Controller. The On-Screen Indications also appear on the TV screen.


-54-



After Use

- 1 Loosen the locking screw ❶ and remove the Output Terminal Box [AV ONE TOUCH STATION] while pressing the [PUSH RELEASE] Button ❷. Hold both the Movie Camera and the Output Terminal Box firmly to prevent them from dropping.
- 2 Take out the cassette.
- 3 Set the [POWER] Switch to [OFF].
- 4 Close the LCD Monitor.
- 5 Attaching the Lens Cap ❸. After use, attach the supplied Lens Cap ❸ to the Lens to protect it.
- 6 Remove the Battery and retract the Finder. (→ 18)

-56-



Viewing Recorded Scenes During Recording Pause (Camera Search)


You can view recorded scenes when the Movie Camera is in the Recording Pause Mode. The Camera Search Function is convenient to search for a scene from which you want to start recording a new scene with smooth scene-to-scene transition.

- 1 Keep the Reverse Search Button [-SEARCH] or the Forward Search Button [SEARCH+] pressed for more than 1 second.
Pressing the [-SEARCH] Button plays back the picture in reverse direction.
Pressing the [SEARCH+] Button plays back the picture in forward direction.

Starting to Record from the Desired Position

- 2 Release the pressed Search Button.
The Movie Camera is in the Recording Pause Mode.
 - 3 Press the Start/Stop Button to start recording.
The Movie Camera starts recording a new scene with smooth scene-to-scene transition.
- In the Camera Search Mode, the picture may contain mosaic-like patterns. However, this is a phenomenon particular to digital video and completely normal.
 - If the Recording Speed Modes (SPL) of the previous and the new recording are different, the playback picture may be distorted.

-58-



Searching for the End of the Recorded Part on a Cassette (Blank Search)

With the Blank Search Function, you can quickly locate the end of the recorded part on a cassette (or a blank part between recordings).

- 1 Set the [POWER] Switch to [VCR].
Turn the switch while pressing the button ❶.
- 2 Press the [MENU] Button.
The [VCR MENU1] Menu appears.

- 3 Turn the [PUSH] Dial to select [BLANK SEARCH].

- 4 Press the [PUSH] Dial to select [ON].
Approximately 1 second before the end of the last recorded scene, the Movie Camera switches over to the Still Playback Mode.

- If there is no blank part on a cassette, the Movie Camera stops at the end of the tape.
- If you set the [POWER] Switch to [CAMERA] and then start recording after the Blank Search has finished, the new scene will be joined to the end of the last recorded scene with a smooth transition.

-60-

VCR MENU

EFFECT OFF
EFFECT SELECT
EFFECT OFF

SEARCH PHOTO SCENE
BLANK SEARCH OFF
12BIT AUDIO ST1
DATE/TIME OFF
MENU2 YES
PRESS MENU TO EXIT

CAMERA MENU3

LCD MODE NORMAL
LCD/EVF SET OFF
REMOTE VCR1
SELF SHOOT NORMAL
C.RESET OFF
SCENE INDEX 2 HOUR DAY
REC LAMP OFF
SOUND OFF
SHOCK SET OFF
RETURN YES
PRESS MENU TO EXIT

Searching for the Beginning of Recorded Scenes Marked with Index Signal (Index Search)


To allow easy searching for desired scenes, this Movie Camera automatically records index signals during recording as follows:

- 1** Photostill Index Signal
To search for still pictures recorded in the Photostill Mode (→ 40) and to use for automatic printing (→ 122).
A photostill index signal is automatically recorded every time you record a still picture in the Photostill Mode.
• However, in the Continuous Photostill Mode (→ 40), no photostill index signals are recorded.

- 2** Scene Index Signal
To search for the beginning of recorded scenes.
A scene index signal is automatically recorded in the following cases:

- When you start recording after inserting a cassette.
- According to the setting of [SCENEINDEX] on the [CAMERA MENU3] Menu:
[2 HOUR]: An index signal is recorded when recording is restarted after a lapse of more than 2 hours.
[DAY]: An index signal is recorded when recording is restarted after the date has changed since the last recording.
- While an index signal is being recorded, the [INDEX] Indication flashes for a few seconds.

-62-



Searching for Photostill Pictures (Photostill Index Search)


- Set the [POWER] Switch to [VCR].
- Set [SEARCH] on the [VCR MENU1] Menu to [PHOTO].
(The initial setting is [PHOTO].)

Photostill Index Search in Forward Direction
Press the Index Button [▶] 1 on the Remote Controller.

Photostill Index Search in Reverse Direction
Press the Index Button [◀] 2 on the Remote Controller.

- At every press of the corresponding button, the tape is fast-forwarded or rewound to the next still picture recorded in the Photostill Mode.
After reaching the next still picture, the still picture is played back continually, however the sound only for approximately 4 seconds. (If you leave the Movie Camera in the Still Playback Mode for more than 6 minutes, it switches over to the Stop Mode to protect the video heads against excessive wear.)
- The Photostill Index Search may not work correctly for still pictures recorded near the beginning of the tape.
- As no photostill index signals are recorded for still pictures recorded in the Continuous Photostill Mode (→ 40), the Photostill Index Search Function cannot be used to search for these still pictures.
- If you keep the [◀] or [▶] Button pressed for more than 2 seconds, the Intro Search Function is activated and it plays back all still pictures recorded in the Photostill Mode on the cassette one after another for a few seconds each.
(To cancel the Intro Search Function, press the Play Button [▶] 3 or the Stop Button [■] 5.)

-64-



Searching for the Beginning of Recorded Scenes (Scene Index Search)

- Set the [POWER] Switch to [VCR].
- Set [SEARCH] on the [VCR MENU1] Menu to [SCENE].

Scene Index Search in Forward Direction
Press the Index Button [▶] 1 on the Remote Controller.





































Scene Index Search in Reverse Direction
Press the Index Button [◀] 2 on the Remote Controller.


- When you briefly press the corresponding button once, the [S1] Indication appears and the search for the next scene marked with an index signal starts.
After the Scene Index Search has started, every time you press the button, the indication changes successively from [S2] to [S9], and the beginning of the scene corresponding to the selected number is located. 9 After reaching the desired scene, playback starts automatically. (At a time, Scene Index Search in forward or reverse direction is possible up to the ninth scene marked with index signal from the present tape position.)
- If the interval between two scene index signals is less than 1 minute, the Scene Index Search may not work correctly.
- The Scene Index Search may not work correctly for scenes recorded near the beginning of the tape.
- If you keep the [◀] or [▶] Button pressed for more than 2 seconds, the Intro Search Function is activated and it plays back the beginning of all scenes marked with an index signal on the cassette one after another for a few seconds each.
(To cancel the Intro Search Function, press the Play Button [▶] 4 or the Stop Button [■] 5.)

-66-

Recording in Special Situations (Programme AE)

This function lets you select Automatic Exposure settings optimized for special recording situations.

- 1 Set the Mode Selector Switch to [MNL].
The [MNL] indication appears.
- 2 Slide the Mode Selector Switch downward repeatedly until the indication of the desired mode ([, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [, [



Recording with Special Effects (Digital Effects)

There are 9 different modes available for adding special digital picture effects.

Digital Effects 1 [EFFECT1]

- Wipe Mode [WIPE]**
It gradually replaces a picture of the last previously recorded scene with the picture of the new scene, like drawing a curtain. For details, (→ 78).

- Mix Mode [MIX]**
It gradually fades out the picture of the last previously recorded scene while fading in the picture of the new scene. For details, (→ 80).

- Strobe Mode [STROBE]**
It records the pictures with a stroboscope-like effect.

- Gain-up Mode [GAIN UP]**
It electronically brightens up the picture. In this mode, adjust the focus manually.

- Trailing Effect Mode [TRACER]**
The picture is recorded with a trailing effect. If you record in the Continuous Photoshot Mode (→ 40), only the first still picture has this effect.


Digital Effects 2 [EFFECT2]

- Negative/Positive Mode [NEGA]**
The recorded pictures have reversed colours similar to photographic negatives.

- Sepia Mode [SEPIA]**
Scenes are recorded with a brown tint similar to the colour of old photographs.

- Black & White Mode [B/W]**
The picture is recorded in black and white.

- Solarisation Mode [SOLARI]**
The picture is recorded with an effect similar to a painting.



Recording with Special Effects (Digital Effects) (Continued)

- Wipe Mode**
It gradually replaces a still picture of the last recorded scene with the moving picture of the new scene, like drawing a curtain.

- Press the [MENU] Button.**
The [CAMERA MENU1] Menu appears.

- Turn the [PUSH] Dial to select [EFFECT1].**

- Press the [PUSH] Dial to select [WIPE].**

- Press the [MENU] Button to exit the Menu.**
The [WIPE] Indication appears.

- Press the Start/Stop Button to start recording.**
The normal recording starts.

- Press the Start/Stop Button to pause recording.**
The last picture is stored in memory. The [WIPE] Indication changes to [WIPE].

- Press the Start/Stop Button to start recording again.**
The last picture of the previous scene is gradually replaced by the new scene.

Recording with Special Effects (Digital Effects) (Continued)

Selecting the Desired Digital Effect

- Press the [MENU] Button.**
The [CAMERA MENU1] Menu appears.

- Turn the [PUSH] Dial to select [EFFECT1] or [EFFECT2].**


- Press the [PUSH] Dial to select the desired digital effect.**

- Press the [MENU] Button to exit the Menu.**
The picture now has the selected digital effect. However, the effect of the Wipe Function and the Mix Function only become visible when actually recording in the respective mode. (→ 78, 80)

- If you have set [EFFECT1] on the [CAMERA MENU1] Menu to [GAINUP], you need to adjust the focus manually; however, adjusting the shutter speed and selecting a white balance mode are not possible.
- If you have set [EFFECT2] on the [CAMERA MENU1] Menu to [B/W] or [SEPIA], changing the selected white balance mode is not possible.
- It is not possible to use the Sports Mode [S.] or the Portrait Mode [P.] together with the Gain-up Mode [GAINUP].

Cancelling the Digital Effect


Set [EFFECT1] or [EFFECT2] on the [CAMERA MENU1] Menu to [OFF].



1, 4

2, 3


5, 6, 7



Recording with Special Effects (Digital Effects) (Continued)

- **Mix Mode**
It gradually fades out a still picture of the last recorded scene while fading in the moving picture of the new scene.
- 1 Press the [MENU] Button.
The [CAMERA MENU1] Menu appears.
- 2 Turn the [PUSH] Dial to select [EFFECT1].
- 3 Press the [PUSH] Dial to select [MIX].
- 4 Press the [MENU] Button to exit the Menu.
The [MIX] indication appears.
- 5 Press the Start/Stop Button to start recording.
The normal recording starts.
- 6 Press the Start/Stop Button to pause recording.
The last picture is stored in memory.
The [MIX] indication changes to [MIX].
- 7 Press the Start/Stop Button to start recording again.
The last picture gradually fades out while the new scene fades in.

-80-



Recording with Natural Colours (White Balance)


This Movie Camera automatically adjusts the white balance to ensure that the pictures are recorded with natural colours. For certain types of subjects and lighting conditions, however, this Auto White Balance Adjustment Mode may not be able to ensure natural colours (→ 164, 166). In these cases, you can select either one of the 3 preset modes explained below (indoor, outdoor, or the last manually adjusted white balance setting), or you can manually adjust the white balance (→ 84).

- 1 Set the Mode Selector Switch to [MNL].
The [MNL] indication appears.
- 2 Press the White Balance [W.B] Button.
Repeatedly press the [W.B] Button to select the desired White Balance Mode.

The modes change in the following order:

- ① Indoor Mode
(recording under incandescent lamp) (☼)

-82-



Adjusting the White Balance Manually

Use the Manual White Balance Adjustment Mode for all types of lighting outside the range ① (→ 166), as the Auto White Balance Adjustment Mode can only ensure natural colours for the types of lighting within that range. For optimum results under almost any type of lighting, we recommend that you adjust the white balance manually for each new scene.

- 1 Attach the Lens Cap and zoom in until the entire screen becomes white.
- 2 Set the Mode Selector Switch to [MNL].
The [MNL] indication appears.
- 3 Keep the [W.B] Button pressed until the [☼] indication ① stops flashing and remains lit.

- 2 Outdoor Mode (☼)
- 3 Last manually adjusted White Balance setting (☼) (→ 84)
- 4 Automatic White Balance Adjustment (no indication)

• If you have set [EFFECT1] on the [CAMERA MENU1] Menu to [GAINUP] or you have set [EFFECT2] to [SEPIA] or [BW], it is not possible to change the white balance mode.

• To change the white balance mode, the Movie Camera must be set within the optical zoom range (1x - 10x). If you try to change it in the digital zoom range, the [☼] indication flashes.

Returning to the Auto White Balance Adjustment Mode


Press the [W.B] Button repeatedly until none of the White Balance Mode Indications (☼, ☼, ☼, ☼) are displayed any more. Or, set the Mode Selector Switch to [AUTO].

- The Manual White Balance Adjustment is now finished. If you want to use this setting again later on, for example after having used Automatic White Balance Adjustment, you can recall it by pressing the [W.B] Button 3 times. (In this case, the [☼] indication flashes.)
- When the [☼] indication remains flashing under weak illumination, the Manual White Balance Adjustment cannot be set manually.
- If you have set [EFFECT1] on the [CAMERA MENU1] Menu to [GAINUP], or you have set [EFFECT2] to [SEPIA] or [BW], it is not possible to adjust the white balance.
- Adjusting the white balance is only possible when the Movie Camera is set within the optical zoom range (1x - 10x). If you try to adjust it in the digital zoom range, the [☼] indication flashes.

Returning to the Auto White Balance Adjustment Mode

Press the [W.B] Button repeatedly until none of the White Balance Mode Indications (☼, ☼, ☼, ☼) are displayed any more. Or, set the Mode Selector Switch to [AUTO].

-84-



Adjusting the Shutter Speed Manually

To achieve special creative effects or to cope with special lighting situations or fast-action scenes, you can adjust the shutter manually.

- 1 Set the Mode Selector Switch to [MNL].
The [MNL] Indication appears.
- 2 Press the [PUSH] Dial.
The Shutter Speed Indication appears.
You can change between the Shutter Speed Indication and the Iris (F Number) (→ 90) Indication by repeatedly pressing the [PUSH] Dial.

-88-

Focusing on the Subject Manually (Manual Focus)

This makes it possible to adjust the focus manually for subjects and recording situations for which automatic focusing is not precise.


- 1 Set the Mode Selector to [MNL].
The [MNL] Indication appears.
- 2 Press the [FOCUS] Button.
The [MF] Indication ① appears.
MF: Manual Focus Mode
- 3 Turn the [PUSH] Dial until the subject is sharp.

-86-

Returning to the Automatic Focusing Mode
Press the [FOCUS] Button to make the [MF] Indication disappear. Or, set the Mode Selector Switch to [AUTO].

Hint for Manual Focus Adjustment

- If you adjust the focus in the wide-angle setting, the subject may go out of focus when you enlarge it. Therefore, enlarge the subject ② before you adjust the focus, so that the picture remains focused when you zoom out ③.
- If you want to adjust the focus manually after having adjusted the shutter speed (→ 88) or the iris (→ 90), be sure to press the [FOCUS] Button to make the [MF] Indication appear, even if the [MF] Indication is displayed.



Adjusting the Iris (F Number) Manually

To achieve special creative effects or to cope with special lighting situations, you can adjust the iris (F number) manually.


- 1 Set the Mode Selector Switch to [MNL].
The [MNL] Indication appears.
- 2 Press the [PUSH] Dial twice.
The [F] Indication appears.
You can change between the Iris (F Number) Indication and the Shutter Speed Indication by repeatedly pressing the [PUSH] Dial.
- 3 Turn the [PUSH] Dial to adjust the iris.

Range of Iris Adjustment
CLOSE (Closed) → F16...F2.0 → OP (Opened)
+0 dB...OP+18 dB
The nearer to [CLOSE] a value you select, the darker the picture becomes.
The nearer to [OP+18 dB] a value you select, the brighter the picture becomes.
The figures with +dB show the Gain-up value. If you increase the value too much, the picture quality deteriorates.

Returning to the Normal Iris Value (F Number)
Press the [PUSH] Dial one time to make the [F] Indication disappear. Or set the Mode Selector Switch to [AUTO].

• Manually adjusting the shutter speed after performing manual iris adjustment changes the iris back to automatic adjustment. Therefore, if you want to adjust both the shutter speed and iris manually, be sure to adjust the shutter speed first. (→ 88)

-90-




Playing Back with Special Effects (Playback Digital Effects) (Continued)

- **Wipe Function and Mix Function**
After having selected [WIPE] or [MIX] in Step 3 on page 92:
- 1 Press the [▶] Button to start playback.
- 2 Press the [STORE] Button at the moment that you want to store as still image in memory.
The [WIPE] or [MIX] Indication appears and the picture is stored in memory.

- 3 Press the [OFF/ON] Button at the scene at which you want to use a Wipe or Mix effect.
The scenes change with a Wipe or Mix effect.

- Operating the Wipe Function and the Mix Function during playback is only possible with the Remote Controller.
- It is not possible to add a Wipe or Mix effect during playback of an unrecorded part on the tape.
- If you press the [OFF/ON] Button while the Wipe or Mix is being performed, the effect is paused at that point. If you press the [OFF/ON] Button again, the effect resumes.

-94-



Playing Back with Special Effects (Playback Digital Effects)

There are 8 different modes available for adding special digital picture effects to your recordings during playback. They are identical to the Digital Effects 1 and 2 (→ 74) that can be used during recording.

- 1 WIPE
 - 2 MIX
 - 3 STROBE
 - 4 NEGA
 - 5 SEPIA
 - 6 BW
 - 7 TRACER
 - 8 SOLARI
- 1 Set the [POWER] Switch to [VCR].
 - 2 Press the Play Button [▶].
 - 3 Press the [SELECT] Button on the Remote Controller to select the desired digital effect.
Repeatedly pressing the [SELECT] Button changes the selected digital effect in the order to 6.
 - 4 Selecting a digital effect is also possible by setting [EFFECT SELECT] on the [VCR MENU1] Menu to the desired effect.

- The signal of the picture with a digital effect added during playback cannot be output from the DV Terminal (→ 10) or the Digital Still Picture Terminal. (→ 126).


Suspending the Playback Digital Effect

Temporarily
You can suspend and re-activate the digital effect by repeatedly pressing the [OFF/ON] Button ①. Suspending the digital effect is also possible by setting [EFFECT] on the [VCR MENU1] Menu to [OFF], and later to [ON] to re-activate it. When the digital effect is temporarily suspended, the indication of the selected effect flashes.

Cancelling the Digital Effect

Set [EFFECT SELECT] on the [VCR MENU1] Menu to [OFF].

-92-



Adding New Sound on a Recorded Cassette (Audio Dubbing)

You can add music or narration on a recorded cassette.

- If [AUDIO REC] on the [CAMERA MENU2] Menu has been set to [16bit], performing audio dubbing erases the previously recorded sound. (If you intend to perform audio dubbing but also want to keep the original sound, be sure to set [AUDIO REC] to [12bit] before making the original recording.)
- It is not possible to perform audio dubbing onto recordings made in the LP Mode. (→ 24)

- 1 Insert the recorded cassette and set the [POWER] Switch to [VCR].

- 2 At the point from which you want to insert the new sound, switch the Movie Camera over to the Still Playback Mode.


- 3 Press the [A.DUB] Button on the Remote Controller.

- 4 Press the Pause Button [II] on the Remote Controller to start audio dubbing.

Stopping Audio Dubbing

Press the Pause Button [II] on the Remote Controller. The Movie Camera is again in the Still Playback Mode.

-96-



Playing Back the Sound Recorded with Audio Dubbing

Depending on the setting selected for [12bit AUDIO] on the [VCR MENU1] Menu, the sound added with audio dubbing and the original sound are played back as follows:

- ST1: The original sound alone is played back.
- ST2: The dubbed sound alone is played back.
- MIX: The original sound and the sound added with audio dubbing are played back together.

- Do not perform audio dubbing onto unrecorded parts of the tape. This could cause the playback picture and sound to be distorted.
- If you reset the Tape Counter to zero at the point where you want the audio dubbing to end and turn on the Memory Stop Function (→ 168), the audio dubbing automatically stops when the tape reaches that point.

-98-

Remote Controller

Using the wireless Remote Controller supplied with the Movie Camera allows operating most of the Movie Camera's major functions from a distance.

Buttons on the Remote Controller

- 1 **Indication Output Button [OSD]**
To display the function and operation indications on a connected TV. (→ 54)

- 2 **Date and Time Button [DATE/TIME]**
To make the Date/Time indication appear or disappear in the picture during recording or playback. (→ 46)

- 3 **Indication Shift Button [DISPLAY]**
To select the desired Counter Indication. (→ 176)


- 4 **Reset Button [RESET]**

To reset the Tape Counter to zero. (→ 168)

- 5 **Audio Dubbing Button [A.DUB]**

To perform audio dubbing. (→ 96)

-100-



Controls for Recording and Sound Volume

Photoshot Button [PHOTO SHOT]
To record still pictures. (→ 40)

Recording Start/Stop Button [START/STOP]
To start and pause recording. (→ 32)

Zoom/Sound Volume Buttons [ZOOM/VOLUME]
CAMERA Mode: To zoom in and out. (→ 38)
VCR Mode: To adjust the volume of the playback sound. (→ 46)

Controls for Playback and Menu Settings

Rewind/Review Button [←44]

To start review playback (→ 48) if pressed during normal playback; and to rewind the tape if pressed in the Stop Mode.

Also to activate the Camera Search Function (→ 58) in reverse direction if kept pressed in the Recording Pause Mode. Pressing it briefly activates the Recording Check Function (→ 34).

Fast-forward/Cue Button [▶▶]


To start cue playback (→ 48) if pressed during normal playback; and to fast-forward the tape if pressed in the Stop Mode.


Also to activate the Camera Search Function (→ 58) in forward direction if kept pressed in the Recording Pause Mode.

Play Button [▶]

To start playback. (→ 46)

-102-





7 Controls for Playback and Menu Setting (Continued)

Slow Motion/Still Advance Button [◀, ▶]
To perform Slow Motion Playback if pressed in the Normal Playback Mode; and to perform Still Advance Playback if pressed in the Still Playback Mode. (→ 50, 52)

Index Search Button [◀◀, ▶▶]
To search for recorded scenes marked with an index signal and for still images recorded in the Photostat Mode. (→ 62, 64, 66)
(◀◀: in reverse direction, ▶▶: in forward direction)

Stop Button [■]
To stop the tape. (→ 46)


Pause Button [⏸]
To pause playback. The playback picture stands still. (→ 52, 56)

8 Menu Button [MENU]
Pressing the Menu Button [MENU] displays the Menu.
In this case, the functions of the following buttons are changed:

Pause Button → Item Button
To select items on the Menu.

Stop Button → Setting Button
To set the mode for the selected item.

-104-



9 Playback Digital Effects

Selection Button [SELECT]

To select the desired digital effect for [EFFECT SELECT] on the [VCR MENU1] Menu. (→ 92)


Store Button [STORE]

To store a still picture in memory for the Wipe or Mix Function. (→ 94)

Off/On Button [OFF/ON]

To suspend the selected digital mode or re-activate it. (→ 92)
To start a Wipe or Mix transition from the still picture stored in memory. (→ 94)

-106-



Remote Controller (Continued)

■ Inserting the Button-type Battery

Insert the supplied button-type battery before using the Remote Controller.


- 1 Pull out the Battery Holder while pressing the Stopper ①.
- 2 Insert the button-type battery with the stamped (+) mark facing upward.
- 3 Insert the Battery Holder into the Remote Controller.

- When the button-type battery is exhausted, replace it with a new CR2025 battery.
(The life of the battery is about 1 year. However, it depends on the frequency of use.)
- **Keep the button-type battery out of the reach of children.**
- Make sure you insert the battery with its poles correctly aligned.

CAUTION

Danger of explosion if battery is incorrectly replaced. Replaces only with the same or equivalent type recommended by the equipment manufacturer. Discard used batteries according to manufacturer's instructions.

-108-



■ Using the Remote Controller

- 1 Set the [POWER] Switch to [CAMERA] or [VCR].

When you want to perform recording operations, set the switch to [CAMERA]; and when you want to perform playback operations, set it to [VCR].

- 2 Aim the Remote Controller at the Remote Control Sensor on the Movie Camera and press the appropriate button.

Distance to the Movie Camera: Less than 5 metres.
Angle: Approximately 15° up, down, left and right from centre axis.

- The operative range described above is valid for using the Remote Controller indoors.
- When using it outdoors or under strong lights, it may not work correctly even within the above range.
- Within a distance of about 1 metre, it is also possible to use the Remote Controller from the side (LCD Monitor side).

Selecting the Remote Controller Mode

When using two Movie Cameras at the same time, selecting different Remote Controller Modes makes it possible to operate them separately.


- If the Remote Controller Mode set on the Movie Camera and on its Remote Controller are not matched, the [REMOTE] Indication appears.
- Replacing the button-type battery in the Remote Controller automatically resets it to the [VCR1] Mode.
- Set [REMOTE] on the Menu to the desired Remote Controller Mode.

Setting to Be Made on the Movie Camera:
Set [REMOTE] on the [CAMERA MENU3] Menu or on the [VCR MENU2] Menu to the desired Remote Controller Mode.

Setting to Be Made on the Remote Controller:
[VCR1]: Press the [▶] Button and [■] Button simultaneously. 1

[VCR2]: Press the [◀] Button and [■] Button simultaneously. 2

-110-



Using the Output Terminal Box [AV ONE TOUCH STATION]

When you want to connect the Movie Camera to a TV for playback or to other video equipment for editing and other purposes, attach the Output Terminal Box [AV ONE TOUCH STATION].

Attaching the Output Terminal Box [AV ONE TOUCH STATION]

- 1 Attach the Movie Camera to the Output Terminal Box [AV ONE TOUCH STATION] as shown above.


- 2 Fasten the locking screw 1 to attach the Output Terminal Box securely.

Removing the Output Terminal Box [AV ONE TOUCH STATION]

- 3 Loosen the locking screw 2 and remove the Output Terminal Box while pressing the [PUSH RELEASE] Button 3.

Hold both the Movie Camera and the Output Terminal Box firmly to prevent them from dropping.

-112-



Copying onto an S-VHS (or VHS) Cassette (Dubbing)

You can copy the picture and sound recorded on this Movie Camera onto an S-VHS or VHS cassette in a home video recorder.

After making the connections shown above, perform the necessary operations.

- Before copying, be sure to press the [OSD] Button on the Remote Controller (→ 100) so that no indications are visible. Otherwise, the displayed tape counter and function indications are also copied.

Movie Camera:

- 1 Set the [POWER] Switch to [VCR].

- 2 Insert the recorded cassette.

VCR:

- 3 Insert an unrecorded cassette with intact erasure prevention tab.

As some settings (external input, tape speed, etc.) on the VCR are necessary, please refer to your VCR's operating instructions.

Movie Camera:

- 4 Press the Play Button [▶] to start playback.

VCR:

- 5 Start recording.

- 6 Press the Pause or Stop Button to stop recording.

Movie Camera:

- 7 Press the Stop Button [■] to stop playback.

- 1 Output Terminal Box [AV ONE TOUCH STATION]


- 2 S-Video Cable

- 3 AV Cable (PHONO-PHONO)

- 4 AV Cable (PHONO-M3)

- 5 21-Pin Adaptor

-114-



Copying with the Help of an Editing Controller

If you connect the Movie Camera to an Editing Controller equipped with 5-pin Edit Socket, this Movie Camera's playback functions can be controlled from the Editing Controller.
(The Output Terminal Box [AV ONE TOUCH STATION] is necessary.)

After connecting all equipment as shown above, perform the necessary operations.

When Connecting the Editing Controller VW-EC500E ① (optional)

- A VCR equipped with 5-pin Edit Socket is necessary.
- When you connect the VW-EC500E to the Movie Camera, an adjustment on the VW-EC500E is necessary. For the operation of the Editing Controller, refer to its operating instructions.


When Editing with Time Code

Press the [DISPLAY] Button on the Remote Controller to make the Time Code appear.

- When the Time Code is displayed, the Time Code Signal is output from the Edit Socket.
- When the Counter indication is displayed, the Linear Tape Counter Signal is output.

- 2 To Edit Socket
- 3 Edit Socket
- 4 Connect the AC Adaptor.
- 5 VCR (not supplied)
- 6 To Edit Socket
- 7 TV (not supplied)
- 8 21-Pin Adaptor

-116-




When Connecting the Editing Controller VW-EC1E (optional)

- When you use the Editing Controller VW-EC1E ①, it is not necessary to connect it to the Edit Socket on the VCR, as the VCR's operation is performed via infrared remote control. Therefore, editing is also possible onto VCRs not equipped with an Edit Socket.
- For the operation of the Editing Controller, refer to its operating instructions.

- 2 To Edit Socket
- 3 Edit Socket
- 4 Connect the AC Adaptor.
- 5 VCR (not supplied)
- 6 TV (not supplied)
- 7 21-pin Adaptor

-118-



Using the Movie Camera with a Video Printer

If you connect the Movie Camera to a Video Printer ①, you can print still pictures from scenes recorded with the Movie Camera.

Movie Camera:

- 1 Set the [POWER] Switch to [VCR].
 - 2 Insert a recorded cassette.
- Video Printer:
- 3 Turn the Video Printer on.

- 4 If the Video Printer is equipped with Digital Image Stabilizer Function and/or Moving/Still Picture Mode, adjust them according to the picture being input.

Movie Camera:

- 5 Press the Play Button [▶].


Video Printer:

- 6 Store the image in memory.
- 7 Start printing.

For details about the operation of the Video Printer, read its operating instructions.

- 2 S-Video Cable

-120-



Using the Automatic Printing Function (Autoprint)

If you connect the Movie Camera to a Video Printer equipped with 5-pin Edit Socket, you can use the Autoprint Function to automatically print all still pictures recorded in the Photoshot Mode.

Video Printer:

- 1 Turn the Video Printer on.
- 2 Make the necessary settings on the Video Printer according to the input signal.


Movie Camera:

- 3 Set the [POWER] Switch to [VCR].

-122-

- When the cooling function of the Video Printer activates and the printing speed slows down, automatic printing may stop. In this case, set [AUTOPRINT] on the [VCR MENU2] Menu to [ON] again.
- If you replace the ink cassette or paper during printing, the same picture may be printed twice.
- If still pictures are recorded successively in the Photoshot Mode, some pictures may be skipped during printing.
- Before storing an image in memory on the Video Printer, press the [OSD] Button (→ 100) on the Remote Controller of the Movie Camera so that no indications appear in the picture. Otherwise, the Counter Indication and other function indications are also printed in the picture.

-124-



Using the Movie Camera with a Computer

The Personal Computer Connection Kit VW-DTA1E (optional) for Digital Video Cameras makes it possible to connect the Movie Camera to a computer and transmit still video images to it. (The Output Terminal Box [AV ONE TOUCH STATION] is also necessary.)

Computer System Requirements

DV STUDIO can be installed in a PC/AT personal computer which can run Microsoft® Windows® 95.

Compatible machines: Personal computer with 80486DX4 or higher CPU (Pentium™ or higher recommended)

Graphic card: True Color (approx. 16.7 million colours) recommended (operation also possible even with 256 colours)

Installed memory:

16 MB or more (32 MB or more recommended)

Free hard disk space: At least 10 MB

Disk drive: CD-ROM drive

Serial port: RS-232C (D-sub 9pin)

Other requirements: Mouse

To connect the Movie Camera to the computer, use the special Interface Adaptor ① contained in the Personal Computer Connection Kit.

- When using the Personal Computer Connection Kit, the [POWER] Switch on the Movie Camera must be set to [VCR].
- Pictures that you intend to import into computer applications should be recorded in the SP Mode.
- When recording, take care that the Time Code is uninterrupted from the beginning of the tape.
- Windows® 95 is a trademark of Microsoft Corporation U.S.A.
- All other company and product names in the operating instructions are trademarks of their respective corporations.

② Digital Still Picture Terminal

③ Output Terminal Box [AV ONE TOUCH STATION]

-126-

Menu Functions


The illustrations of the menus are intended for explaining the functions; the actual menus look somewhat different.

Camera Mode Menu
[CAMERA MENU1]

- 1 Digital Effects 1 [EFFECT1] (→ 74, 76)
- 2 Digital Effects 2 [EFFECT2] (→ 74, 76)
- 3 Digital Zoom [D.ZOOM] (→ 38)
- 4 Advancing to Menu 2 [MENU2] (→ 132)

If you set [MENU2] to [YES], the Menu changes to the [CAMERA MENU2] Menu.

-130-




Camera Mode Menu (Continued)
[CAMERA MENU2]

- 5 Cinema-like Format Recording [CINEMA] (→ 42)
- 6 Shutter Effect [SHTR EFFECT] (→ 40)
- 7 Recording Speed Mode [REC SPEED] (→ 24)
- 8 Audio Recording Mode [AUDIO REC] (→ 96)
- 9 Wind Noise Reduction [WIND CUT]

If you set [WIND CUT] to [ON], the noise of the wind hitting the microphone is reduced. However, this also causes a slight deterioration of the sound reproduction in the bass range.

-132-




Using the Menu Screen

This Movie Camera displays the settings of various functions in Menus to make it easy to select the desired functions and settings.

- 1 Press the [MENU] Button.
The Menu appears.
- 2 Turn the [PUSH] Dial to select the item to be set.
Turning the [PUSH] Dial changes the item highlighted in green.
- 3 Press the [PUSH] Dial to set the selected item to the desired mode.
Every press moves the cursor (▶) to the next mode.

-128-




VCR Mode Menu [VCR MENU1]

- 1 Digital Effect On/Off [EFFECT] (→ 92)
 - 2 Digital Effect Selection [EFFECT SELECT] (→ 92)
 - 3 Index Search Mode [SEARCH] (→ 62, 64, 66)
 - 4 Blank Search [BLANK SEARCH] (→ 60)
 - 5 Audio Output Mode [12bit AUDIO] (→ 98)
 - 6 Advancing to Menu 2 [MENU2]
- If you set [MENU2] to [YES], the Menu changes to the [VCR MENU2] Menu.

[VCR MENU2]

- 7 Automatic Printing [AUTOPRINT] (→ 122)
 - 8 Returning to the Previous Menu [RETURN]
- If you set [RETURN] to [YES], the Menu changes back to the [VCR MENU1] Menu.
- All other items on the VCR Mode Menu are the same as on the Camera Mode Menu.

-136-




Setting the Date and Time

If you set [CLOCK SET] either on the [CAMERA MENU3] Menu or [VCR MENU2] Menu to [ON], the Menu shown above appears.

For example: To set the clock to 15th October 1998, 14:30.

- 1 Turn the [PUSH] Dial to set to [1998].
The years change in the following order:
1990→1991→...→2089→1990→...
- 2 Press the [PUSH] Dial to select [MONTH].
- 3 Turn the [PUSH] Dial to set to [10].
- 4 Press the [PUSH] Dial to select [DAY].
- 5 Turn the [PUSH] Dial to set to [15].
- 6 Press the [PUSH] Dial to select [HOUR].
- 7 Turn the [PUSH] Dial to set to [14].
- 8 Press the [PUSH] Dial to select [MIN.].
- 9 Turn the [PUSH] Dial to set to [30].
- 10 Press the [MENU] Button to finish the date and time setting.
The operation of the clock starts from [00] seconds.



-138-



Camera Mode Menu (Continued) [CAMERA MENU3]

- 14 LCD Lighting Mode [LCD MODE] (→ 142)
- 15 LCD and Finder Adjustment [LCD/EFV SET] (→ 142)
- 16 Remote Controller Mode [REMOTE] (→ 110)
- 17 Self-Recording [SELF SHOOT] (→ 36)
- 18 Counter Reset [C-RESET] (→ 168)
To reset the counter to zero.
However, the Time Code cannot be reset.
- 19 Scene Index Mode [SCENE INDEX] (→ 66)
- 20 Recording Lamp [REC LAMP] (→ 32)
- 21 Beep Sound [BEEP SOUND]
If you set [BEEP SOUND] to [ON], a confirmation/ alarm beep sound is emitted in the following cases:
 - When you turn on the Movie Camera.
 - When you start recording and pause recording.
 - When the tape reaches its end during recording, or when the tape has reached its end and you try to start recording.
 - When you try to start recording without having inserted a cassette.
 - When you insert a cassette with its erasure prevention slider set to [SAVE] and try to start recording.
 - When condensation has formed inside the Movie Camera.
- 22 Date and Time Setting [CLOCK SET] (→ 138)
- 23 Returning to the Previous Menu [RETURN]
If you set [RETURN] to [YES], the Menu changes back to the [CAMERA MENU2] Menu.

-134-



Adjusting the Brightness and Colour Level of the LCD Monitor/ Finder

If you set [LCD/EVF SET] on the [CAMERA MENU3] Menu or [VCR MENU2] Menu to [ON], the following items are displayed:

LCD Brightness [LCD BRIGHTNESS]

To adjust the brightness of the picture on the LCD screen.

LCD Colour Level [LCD COLOUR LEVEL]

To adjust the colour saturation of the picture on the LCD screen.

Finder Brightness [EVF BRIGHTNESS]

To adjust the brightness of the picture in the Finder.

1 Press the [PUSH] Dial to select the item that you want to adjust.

2 Turn the [PUSH] Dial to increase or decrease the vertical bars of the Bar Indication.

The Bar Indication is divided into 8 steps. The more vertical bars are shown, the stronger is the brightness or colour saturation.

If you use the Remote Controller for this adjustment, press the [ITEM] Button and then adjust the brightness or colour saturation by pressing the [SET] Button. The number of the bars gradually increases toward the right end, and then it decreases again.

Increasing the Brightness of the LCD Monitor's Backlighting

Set [LCD MODE] either on the [CAMERA MENU3] Menu or [VCR MENU2] Menu to [BRIGHT].

- All adjustments explained on this page have no influence on the actually recorded picture.

-142-

Cautions for Use

Take care that no water enters the Movie Camera when using it in the rain and snow or on the beach.

- The Movie Camera and the cassette could become damaged. (It might not be repairable.)

Keep the Movie Camera away from magnetized equipment (TVs, Video games, etc.).

- If you use the Movie Camera on or near a TV, the electromagnetic radiation may cause picture and sound distortion.

Strong magnetic fields generated by speakers and large motors may damage the recordings on the tape and distort the picture.

- The electromagnetic radiation from microprocessors can adversely influence the Movie Camera and cause picture and sound distortion.

If the Movie Camera is adversely influenced by magnetized equipment and does not work correctly, turn the Movie Camera off, remove the Battery or disconnect the AC Adaptor and attach the Battery or connect the AC Adaptor again. Then turn the Movie Camera on.

Do not use the Movie Camera near a radio transmitter or high-voltage power line.

- If you record near a radio transmitter or high-voltage power line, the recorded picture and sound may be adversely influenced.


Do not use the Movie Camera for surveillance and other industrial applications.

- If the Movie Camera is being used for a long time, the inside temperature could rise excessively and this may cause malfunction.
- This Movie Camera is not designed for industrial use.

Take care that no sand and fine dust enters the Movie Camera when using it on a beach or similar places.

- Sand and dust could damage the Movie Camera and cassette. (Be careful when inserting and removing the cassette.)

-144-



Charging the Built-in Lithium Battery

The built-in battery maintains the operation of the clock. When the [B] Indication appears, the built-in lithium battery is discharged. Charge the discharged battery in the following way and after charging is finished, set the date and time.


2 Leave the Movie Camera turned off.

3 Leave the Movie Camera in this condition for approximately 4 hours.

After charging for 4 hours, the built-in lithium battery can power the clock for approximately 3 months.

1 Connect the AC Adaptor to the Movie Camera and to an AC mains socket. (→ 16)

-140-



Do not spray insecticide or volatile agents on the Movie Camera.

- Such agents could deform the body and cause the surface coating to peel off.
- Do not leave the Movie Camera in direct contact with rubber or plastic products for a long time.

Do not use benzine or thinner for cleaning.

- They could deform the body and cause the surface coating to peel off.
- Before cleaning, remove the Battery or unplug the AC Mains Cable from the AC mains socket.
- Wipe the Movie Camera with a soft, clean cloth. To remove persistent stains, wipe with a cloth moistened with mild detergent diluted with water, and then finish with a dry cloth.

-146-

■ Condensation

Determining Whether Condensation Has Formed Inside and Remedy for Condensation

If the Condensation Indication flashes after you turn on the Movie Camera, condensation has formed inside the Movie Camera. In this case, the Movie Camera automatically switches off after a few seconds. Remedy as follows:

1

Take out the cassette.

All other functions do not work. Depending on the amount of condensation, it may not be possible to take out the cassette. In this case, wait 2–3 hours before taking out the cassette.

2

Leave the Cassette Compartment open

and wait for 2–3 hours.

The required time depends on the amount of condensation and the ambient temperature.

-148-

After use, always take out the cassette and remove the Battery or unplug the AC Mains Cable from the AC mains socket.

- If you leave the cassette in the Movie Camera, the tape can become loosened and damaged.
- If you leave the Battery attached to the Movie Camera for a long time, the voltage level may drop excessively so that the Battery cannot be used any more even after charging.

■ Video Head Clogging and Remedy

When the video heads (which contact the tape) are dirty, the playback picture contains mosaic-like patterns or the whole screen becomes black. If they become even more dirty, the recording performance deteriorates and in the worst case, recording may not be possible at all.

Causes of Dirty Video Heads

- A lot of dust in the air
- High-temperature and high-humidity environment
- Damaged tape
- Long-time use

Using the Mini-DV Format Digital Video Head Cleaner (not supplied)

- 1 Insert the Head Cleaner into the Movie Camera in the same way as a video cassette.
- 2 Press the Play Button [▶], and after approximately 20 seconds press the Stop Button [■]. (Do not rewind the tape.)
- 3 Take out the Head Cleaner. Insert a video cassette, perform recording and then play it back to check the picture.
- 4 If the picture is still not clear, repeat above operation steps 1 - 3. (Do not use the Head Cleaner more than 3 times in succession.)

-150-

Notes:

- Do not rewind the tape in the Head Cleaner after every use. Rewind it only after the tape has reached its end, and then use it again in the same way from the beginning.
- If the video heads again become clogged with dirt soon after cleaning, this might be caused by a damaged tape. In this case, stop using that cassette immediately.
- Be careful not to clean the video heads too much. (Too much cleaning could cause excessive wear to the video heads. If the video heads get worn, the picture is not played back clearly even after cleaning.)
- If using the Head Cleaner does not clear the video head clogging, the Movie Camera requires cleaning or repairing by a service centre.
- This Video Head Cleaner is available from Panasonic service centres.

Periodic Inspection

To ensure optimum picture quality, we recommend that you have worn-out parts such as video heads replaced after approximately 1000 hours of use. (However, this depends considerably on the conditions of use such as temperature, humidity and dust.)

Discarding a Battery That Has Become Unusable

- The usable life of the Battery is limited.
- Do not throw the Battery in a fire because it could explode.
- **When the Charge Lamps on the AC Adaptor Flash as Warning**
If the ambient temperature is extremely low or high, the Charge Lamps on the AC Adaptor flash. They also flash when some defect has occurred in the Battery or the AC Adaptor.
When the Charge Lamps Flash Slowly
The Battery is being charged, but charging takes longer than normally.
When Only the [80%] Charge Lamp Flashes
Charging is not possible. Remove the Battery once and wait a few minutes, and then re-attach it again for charging.
When the [50%] and [100%] Charge Lamps Flash Alternately, or When No Charge Lamps Light
Remove and then re-attach the Battery. Or, attach the Battery to the Movie Camera and perform playback (or some other operation) for 10 - 20 minutes. Then remove the Battery and attach it again to the AC Adaptor. If charging is still impossible, some malfunction has occurred in the Battery or the AC Adaptor. Please consult with your dealer.

-152-

■ Optimum Use of the Battery

Special Characteristics of the Battery

This Battery is a rechargeable lithium-ion battery. Its ability to generate electric energy is based on an internal chemical reaction. This reaction is easily influenced by ambient temperature and humidity, and the useful operation time that the Battery can provide becomes shorter at high and low temperatures. When used in extremely cold surroundings, the Battery may only be able to provide approximately 5 minutes of operation time. If the Battery becomes extremely hot, a protection function is activated and prevents the use of the Battery for some time.

After Use, Always Remove the Battery.

Be sure to remove the Battery from the Movie Camera. (If it is attached to the Movie Camera, a small amount of electric current is consumed even if the Movie Camera is turned off.) Leaving the Battery attached to the Movie Camera for a very long time could cause it to become excessively discharged, so that it cannot be used any more even after charging.

Keep the Battery's Terminals Clean.

Be careful that the terminals do not get plugged up with dust, dirt or other substances. If you accidentally drop the Battery, confirm that the Battery itself and the terminals are not deformed. Attaching a deformed Battery to the Movie Camera or to the AC Adaptor could damage the Movie Camera or the AC Adaptor.

■ Precautions for Storage

Before Storing the Movie Camera, Take out the Cassette and Remove the Battery.

Store all equipment in a dry place where the temperature remains relatively constant. (Recommended temperature is 15°C–25°C and recommended relative humidity is 40%–60%.)

Movie Camera

- Wrap it with a soft cloth to prevent dust from entering.

Battery

- Extremely low or high temperature shortens the Battery life.
- Storing it in places with oily smoke and a lot of dust could cause the terminals to get rusty, and this can result in malfunction.
- Do not allow metal objects (such as necklaces and hair pins) to touch the battery terminals. Short-circuiting may occur and generate heat, and touching it in this condition could inflict serious burns.
- Store the Battery in discharged condition. If you store the Battery for a long time, we recommend that you charge it once a year and completely use up the charge before storing it again in discharged condition.

Cassette

- Rewind the tape to its beginning before storing. Leaving the cassette with the tape stopped halfway for more than 6 months (depending on the storing condition) loosens the tape. Be sure to rewind it to the beginning.
- Put the cassette in its case to store it. Dust, direct sunlight (ultraviolet rays) and humidity could damage the tape. Dust contains hard mineral particles and cassettes with dust damage the video heads and other parts of the Movie Camera. Make it a habit to always put the cassette back into its case.
- Completely wind the tape forward and then rewind it once every half year. Leaving the cassette for more than a year without winding/rewinding may deform the cassette because of stretching and shrinking of the tape due to changes in temperature and humidity. Also, the tape may stick together.
- Do not place the cassette near strongly magnetized objects or equipment.
- The tape surface is coated with microscopic magnetic particles and they record signals. Such objects as magnetic necklaces and toys have stronger magnetic force than commonly thought, and this could erase the recorded contents and cause noise in picture and sound.

-154-

■ LCD Monitor/Finder/MC Protector/

Microphone Socket

LCD Monitor

- In places where big changes in temperature occur, condensation may form on the LCD Monitor. Wipe it with a soft, dry cloth.
- If the Movie Camera is very cold when it is turned on, the picture on the LCD Monitor is initially a little darker than normally. However, as the internal temperature rises, the LCD Monitor regains its normal brightness.
- Extremely high precision technology is employed in producing the LCD Monitor. The result is more than 99.99% effective pixels with a mere 0.01% of the pixels inactive or always lit. However, this is not a malfunction and does not affect the recorded picture.

Finder

- Extremely high precision technology is employed in producing the Finder screen. The result is more than 99.99% active pixels, with a mere 0.01% of the pixels inactive or always lit. However, this is not a malfunction and does not affect the recorded picture.
- Do not leave the Finder or the Lens aimed at the sun. This could seriously damage internal parts.

-156-

Glossary

■ Digital Video System

In the digital video system, picture and sound are converted into digital signals and recorded onto the tape.

This completely digital recording allows recording and playback of picture and sound with minimum quality deterioration.

In addition, such data as Time Code, Date and Time are also automatically recorded as digital signals.

Features

- Superior picture resolution
- Excellent signal-to-noise ratio
- Stable pictures
- Minimised quality deterioration in dubbing
- Minimised cross colour distortion
- PCM digital sound
- No picture deterioration in LP Mode
- 6.35 mm-wide tape
- Compact cassette with long recording time
- Minimised quality deterioration in editing
- Time Code editing

Compatibility with S-VHS or VHS Cassettes

As this Movie Camera uses a digital method for recording picture and sound, there is no compatibility with conventional S-VHS or VHS video equipment using analog recording methods. In addition, the size and shape of the cassette are completely different.

-158-

Compatibility with Output Signals

As the video and audio signals output from the audio and video output sockets are analog—the same as in conventional video systems—you can connect this Movie Camera to your S-VHS or VHS VCR or TV for playback.

PCM Digital Sound

For recording of the sound, this Movie Camera offers the choice between two different PCM Audio Recording Modes.

- 16 bit, 48 kHz, 2 channels
 - 12 bit, 32 kHz, 4 channels
- The "16 bit, 48 kHz, 2 channels" Mode offers superior recording sound quality.
- The "12 bit, 32 kHz, 4 channels" Mode lets you record the original sound in stereo on two channels and the dubbed sound in stereo on two separate channels.

Sub Code

The digital recording system offers the added capability of recording sub code containing various data.

The following data is recorded as sub code on this Movie Camera:

- Time code
- Recording date and time
- Index signals for locating still images recorded in the Photoshot Mode
- Index signals for locating the beginning of scenes marked with index signal

Auto Focus Adjustment

The Auto Focus System automatically moves the internal focusing lens forward or backward and adjusts the focus so that the subject can be seen clearly. The Auto Focus Adjustment has the following characteristics:

- It adjusts until the vertical contours of the subject are as sharp and clean as possible.
- It adjusts the focus on the subjects with strong contrast.
- It adjusts the focus on the subject in the centre of the LCD Monitor or Finder.

Unlike human eyes, the lens of the Movie Camera cannot instantaneously change the focus from a nearby to a distant subject and vice versa.

Lens Unit

The lens construction used in this Movie Camera generates some clicking noise if the Movie Camera is rocked up and down while it is turned off. This is not a malfunction of the lens unit. This noise does not occur when the Movie Camera is turned on.

-160-

■ Focus

If you look at an object through a magnifying glass and move it closer or further away from your eye, you will reach a point where the object becomes clearly visible. Being focused or in focus means that the subject can be seen with optimum clarity and sharpness.

Human Eyes

Human eyes have lenses as well, and when we look at objects at different distances, the shape of these lenses changes automatically so that we can always see these objects clearly.

Movie Camera

The image of the subject enters the Movie Camera through the lens and is converted into an electric signal (video signal) for recording onto magnetic tape. The focus is adjusted either manually or automatically by moving a focusing lens.

For the following subjects and recording situations, the Auto Focus System cannot provide precise adjustment.
Use the Manual Focus Mode instead. (→ 86)

1 Recording subjects with a part of it near the Movie Camera and another part far away from it

As the Auto Focus adjusts on the centre part of the image, it is often impossible to bring the nearby and distant parts of the subject into focus.
When you want to record a person with a distant mountain in the back, it is not possible to focus on both.

2 Recording subjects behind glass covered with dirt or dust

As the focus is adjusted on the dirty glass, the subject behind the glass is out of focus. When recording a subject across a street on which cars are running, the focus may be adjusted on the cars.

3 Recording subjects in dark surroundings

As the amount of light information entering through the lens is greatly reduced, the Movie Camera cannot adjust the focus precisely.

-162-

4 Recording subjects surrounded by objects with shiny surfaces or much light reflection


As the Movie Camera adjusts the focus on objects with shiny surfaces or much light reflection, the subject may go out of focus.
Therefore, when recording at a lake or the sea, evening scenes, fireworks, or under special types of lighting, the subject may be out of focus.

5 Recording fast-moving subjects

As the internal focusing lens is moved mechanically, it cannot follow fast-moving subjects without delay. Therefore, subjects like children running back and forth may temporarily go out of focus.

6 Subjects with weak contrast

As the Movie Camera adjusts the focus based on vertical contours in the picture, subjects with little contrast such as a white wall may be out of focus.



■ Colour Temperature

Every light source has its own colour temperature measured in Kelvin (K). The higher the Kelvin value, the more bluish the light; the lower the value, the more reddish the light. The Kelvin value is related to the tint of the light, but not directly to its brightness.

The range 1 indicated in the illustration above shows the light sources for which this Movie Camera can provide precise white balance adjustment and, therefore, natural colours in the recorded pictures, when using the Full Auto Mode. For light sources outside this range, adjust the white balance manually (→ 84). Also, additional lighting may be necessary.

- 1 Control range of this Movie Camera's Auto White Balance Adjustment Mode
- 2 Blue sky
- 3 Cloudy sky (Rain)
- 4 TV screen
- 5 Sunlight
- 6 White fluorescent lamp
- 7 2 hours after sunrise or before sunset
- 8 1 hour after sunrise or before sunset
- 9 Halogen light bulb
- 10 Incandescent light bulb
- 11 Sunrise or sunset
- 12 Candlelight

-166-

Auto White Balance Adjustment

This Movie Camera stores the optimum settings for several common light sources in memory. The Movie Camera judges the recording situation by determining the tint of the light received through the lens and by the White Balance Sensor (→ 10), and it selects the setting for the most similar tint. This function is called Auto White Balance Adjustment.

However, as the white balance settings for only a few light sources are stored in memory, the white balance is not correctly adjusted for other lighting conditions.

For the range of different types of lighting within which the Auto White Balance Function can provide precise adjustment, refer to the chart (→ 166). For recording under lighting conditions outside this range, the Auto White Balance Function does not work correctly, and the recorded picture has a red or blue cast. However, the same also applies, if the subject is lit by more than one light source, even if these light sources are within this range.

-164-

■ White Balance Adjustment

While most recording with a Movie Camera is probably done outdoors under sunlight, video recording is also done very often under artificial light sources, both indoors and outdoors. However, each of these light sources gives the subject slightly different colours.

Human Eyes

Human eyes can easily adjust to different kinds of lighting and see an object with the same colours even under different lighting.

Movie Camera

Unlike human eyes, the Movie Camera does not have the innate ability to adapt to changes in lighting, and they influence the colours being recorded. Therefore, depending on the light source, the picture would be recorded with a bluish or reddish tint. To minimise the influence of the lighting on the colours of the subject, an adjustment called White Balance Adjustment is necessary.

White Balance Adjustment

The White Balance Adjustment determines the colour of the light and adjusts the colours so that white remains pure white. As white is the basic colour of the entire colour spectrum, if white is reproduced correctly, the other colours are correct and natural, too.

■ Time Code

Time Code signals are the data which indicates the time in hours, minutes, seconds and frames (25 frames/sec). Having this data included in the recording gives every single picture on the tape its own address.

- The Time Code is automatically recorded as part of the sub code with every recording you make.
- When you insert a new (previously unrecorded) cassette, the Time Code automatically starts from zero. If you insert a recorded cassette, the Time Code continues where the time code of the last previous scene stopped. (In this case, the zero indication [00000000] may appear after inserting the cassette, but when the recording starts, the Time Code records from the previous value.)
- You cannot reset the Time Code to zero.
- In playback modes other than the Normal Playback Mode, the Time Code may not be displayed (or not be correct).
- Unless the Time Code is recorded continuously from the beginning of the tape, precise editing may not be possible. To ensure that the Time Code is recorded without interruption, we recommend that you use the Camera Search Function (→ 58) or Blank Search Function (→ 60) before starting to record a new scene.

■ Memory Stop Function

The Memory Stop Function is convenient for the following operations.

Rewinding or fast-forwarding the tape to a desired position

- 1 Reset the Tape Counter to zero at the tape position from which you want to play back later. (→ 100, 134)

- 2 Set [DISPLAY] on the [CAMERA MENU2] Menu or [VCR MENU2] Menu to [MEMORY].

- 3 Start playback or recording.

- 4 After playback or recording is finished: Set the [POWER] Switch to [VCR].

- 5 Rewind the tape.

The tape automatically stops approximately at the position at which you reset the counter to zero.

Stopping the editing automatically in the audio dubbing

- 1 Reset the Tape Counter to zero at the tape position at which you want the editing to stop.


- 2 Set [DISPLAY] on the [CAMERA MENU2] Menu or [VCR MENU2] Menu to [MEMORY].

- 3 Play back a still picture at the point at which you want the audio dubbing to start.

- 4 Start the audio dubbing. (→ 96)

The audio dubbing automatically stops approximately at the position at which you reset the counter to zero.

-168-



Indications on the LCD Monitor/in the Finder

① Remaining Battery Power

As the remaining battery power decreases, the indication changes as follows:

When the battery is completely discharged, the [] indication flashes.

(When you are using the AC Adaptor, the indication may appear, however, this has no meaning in this case.)

② Remaining Tape Time

The remaining tape time is displayed in minutes. (When it becomes less than 3 minutes, the indication starts flashing.)

- If a recording lasts less than 15 seconds, the remaining tape time cannot be displayed correctly.
- The displayed remaining tape time may be shorter than the actual remaining tape time.

③ Cinema Mode (→ 42)

When recording in the Cinema Mode, this indication is displayed.


④ Digital Zoom (→ 38)

When the Digital Zoom Function is activated, this indication is displayed.

Digital Effects (→ 74)

When a digital effect is activated, the corresponding indication is displayed.

-170-



⑤ Recording Speed Mode (→ 24)

The selected Recording Speed Mode is displayed.

SP: Standard Mode

LP: Long-play Mode

⑥ Tape Counter, Time Code (→ 176)

The Tape Counter, Memory Stop Function or Time Code indication is displayed.

⑦ Zoom Magnification (→ 38)

When you push the [W/T] Zoom Lever up or down, the Zoom Magnification Indication and the Zoom Gauge are displayed.

Recording Mode (→ 32, 82, 84, 86, 88, 90)

AUTO: This appears when the Mode Selector Switch is set to [AUTO].

MNL: This appears when the Mode Selector Switch is set to [MNL].

Super Image Stabilizer (→ 44)

When the Super Image Stabilizer Function is activated, this indication is displayed.


Audio Recording Mode (→ 96)

The indication of the Audio Recording Mode that was selected for recording is displayed during playback.

Automatic Printing (→ 122)

This indication is displayed when the Auto Print Function is being used.

-172-



8 Tape Run Indications


- REC:** Recording (→ 32)
PAUSE: Recording Pause (→ 32)
▷: Playback (→ 46)/Camera Search in forward direction (→ 58)
<: Camera Search in reverse direction (→ 58)
II: Still Playback (→ 52)
II▷: Fast-Forward/Cue Playback (→ 48)
<<: Rewind/Review Playback (→ 48)
II<: Slow Playback in forward direction/Slow Playback in reverse direction (→ 50)
II▷<: Still Advance Playback in forward direction/Still Advance Playback in reverse direction (→ 52)
▷>||<: Index Search in forward direction/Index Search in reverse direction (→ 62, 64, 66)

- CHK:** Recording Check (→ 34)
A.DUB ▷: Audio Dubbing (→ 96)
A.DUB II: Audio Dubbing Pause (→ 96)
PHOTO: Recording in the Photoshot Mode (→ 40)
BLANK: Blank Search (→ 60)
R ▷: Repeat Playback (→ 46)

• When recording with the LCD Monitor facing forward using the Mirror Mode, only the Remaining Battery Power Indication, the Recording Indication (II) and the Recording Pause Indication (II) are displayed.

- 9 Shutter Speed**
 When you manually adjust the shutter speed, this indication is displayed. (→ 88)
10 Iris Value (F Number)
 When you manually adjust the iris, this indication is displayed. (→ 90)

-174-




Changing the Indications

By changing the setting for [DISPLAY] on the [CAMERA MENU2] Menu or [VCR MENU2] Menu, or by repeatedly pressing the [DISPLAY] Button on the Remote Controller (→ 100), the Counter Display Mode can be changed in the order shown in the above illustrations ①-④.

- ① Tape Counter Indication
 ② Tape Counter Indication with activated Memory Stop Indication

-176-



11 Index (→ 62)

INDEX: The [INDEX] Indication flashes for a few seconds while an Index signal is being recorded.

Search Number (→ 66)

S1: The figure indicates which number of scene ahead from the present scene is to be played back.

12 Programme AE Mode (→ 70)

The Programme AE Function offers the following settings:

- SPORTS : Sports Mode
 PORTRAIT : Portrait Mode
 LOW LIGHT : Low Light Mode

13 White Balance Mode (→ 82)

The White Balance Mode offers the following possible settings:

- INDOOR : Indoor Mode (recording under incandescent lamp)
 OUTDOOR : Outdoor Mode
 LAST : Last manually adjusted White Balance setting

When the Movie Camera is in the Auto Mode, none of the above 3 indications are displayed.


14 Manual Focus (→ 86)

If you select the Manual Focus Mode, the [MF] Indication is displayed.

15 Wind Noise Reduction [WIND CUT]

If you set [WIND CUT] on the [CAMERA MENU2] Menu to [ON], the [WIND CUT] Indication is displayed.

-178-



15 Sound Volume (→ 46)

Use this indication to adjust the volume of the playback sound from the built-in speaker. Set the [POWER] Switch to [VCR] and keep the [PUSH] Dial pressed until the [VOLUME] Indication appears. Then turn the [PUSH] Dial to adjust the volume.

17 Date and Time (→ 46)

The time is indicated in the 24-hour system.

18 Warning/Alarm

When any of the following indications lights or flashes, confirm the condition of the Movie Camera.

[]: Condensation has occurred. (→ 148)
[]: The erasure prevention slider of the inserted cassette is open (set to [SAVE]).

No cassette is inserted.

The built-in battery is discharged.

(→ 140)

The video heads are dirty.

[] END: During recording, the tape has reached its end.

REMOTE: Wrong Remote Controller Mode is selected. (→ 110)

PRINTER

ERROR: This indication is displayed if you set [AUTOPRINT] on the [VCR MENU2] Menu to [ON] when no printer is connected to the Movie Camera. (→ 122)

-180-

Before Requesting Service (Problems & Solutions)

Power Supply

P1: The Movie Camera does not turn on.

S1: Is the Battery or the AC Adaptor connected correctly? Confirm the connection. (→ 16)

P2: The Movie Camera has turned off automatically.

S2: If you leave the Movie Camera in the Recording Pause Mode for more than 6 minutes, it automatically switches off to protect the tape and to conserve battery power. (→ 32)

P3: The Movie Camera quickly turns off.

S3-1: Is the Battery discharged? When the Remaining Battery Power Indication is flashing or the [] Indication is displayed, the Battery is discharged. Charge the Battery or attach a fully charged Battery. (→ 18, 170)

S3-2: Has condensation formed? If the Movie Camera is brought from a cold to a warm place, condensation may form inside. In this case, the Movie Camera automatically switches off and no operation can be performed except taking out the cassette. Wait until the Condensation Indication disappears. (→ 148)

-182-

Battery

P1: The Battery discharges quickly.

S1-1: Is the Battery fully charged? Charge it until all 3 Charge Lamps on the AC Adaptor light. (→ 18)

S1-2: Are you using the Battery in a place where the temperature is very low? The ambient temperature greatly influences the Battery's performance. Its operation time becomes shorter in a cold place. (→ 152)

S1-3: Has the Battery reached the end of its service life? The service life of the Battery is limited. It depends on the way the Battery is used, but when the operation time even after proper charging is too short for normal use, the service life of the Battery has reached its end.

P2: The Battery cannot be charged.

S2: If the DC Input Cable is connected to the AC Adaptor, charging is not possible. Disconnect the DC Input Cable.

Normal Recording

P1: Recording cannot be started even though the Movie Camera is supplied with power and the cassette is inserted correctly.

S1-1: Is the erasure prevention slider of the cassette open? If it is open (set to [SAVE]), recording is not possible. (→ 22)

S1-2: Has the tape reached its end? Insert a new cassette. (→ 22)

S1-3: Is the Movie Camera turned on? (→ 32)

S1-4: Is the [POWER] Switch set to [CAMERA]? When it is set to [VCR], recording is not possible. (→ 32)

S1-5: Is the Condensation Indication [] displayed? When condensation has formed, no functions except taking out the cassette can be operated. Wait until the Condensation Indication disappears. (→ 148)

Other Recording

P1: The picture on the LCD Monitor in the Finder suddenly stands still for a few seconds.

S1: Did you press the [PHOTO SHOT] Button? If you press the [PHOTO SHOT] Button, a still picture is recorded for approximately 7 seconds. After approximately 7 seconds, the Movie Camera switches back to the Recording Pause Mode. (→ 40)

-184-

Indications

- P1:** The Time Code becomes incorrect.
S1: In the Slow Motion Playback Mode in reverse direction, the counter of the Time Code Indication may not be stable, however, this is not a malfunction.
- P2:** The Remaining Tape Time Indication disappears.
S2: If you record a still picture in the Photoshot Mode, the Remaining Tape Time Indication may disappear temporarily. However, if you switch the Movie Camera over to the Normal Recording Mode, it appears again.
- P3:** The Remaining Tape Time Indication does not match the actual remaining tape time.
S3-1: If scenes of less than 15 seconds are recorded successively, the remaining tape time is not indicated correctly.
S3-2: The Remaining Tape Time Indication may show a remaining tape time that is 2-3 minutes shorter than the actual remaining tape time.

Playback (Picture)

- P1:** No playback picture is reproduced when pressing the Play Button (▶).
S1: Is the [POWER] Switch set to [VCR]? When it is set to [CAMERA], no playback function can be operated. (→ 46)
- P2:** Mosaic-like patterns appear in the picture during Cue, Review or Slow Motion Playback. This phenomenon is a characteristic of the digital video system. This is not a malfunction. (→ 48)
- P3:** I want to play back the picture on a TV.
S3: Attach the Output Terminal Box [AV ONE TOUCH STATION] to the Movie Camera and use the AV Cable (PHONO-PHONO) to connect it to the TV. Or use the AV Cable (PHONO-M3) to connect the Movie Camera directly to the TV. (→ 54)
- P4:** The Movie Camera is correctly connected to a TV, but no playback picture is reproduced.
S4: Did you select "Video Input" on the TV? Carefully read the operating instructions for your TV and select the channel that matches the input sockets used for connection.
- P5:** The playback picture is not reproduced clearly.
S5: Are the video heads on the Movie Camera dirty? If the video heads are dirty, the picture cannot be played back clearly. (→ 150)

-186-

Playback (Sound)

- P1:** No sound is played back from the Movie Camera's built-in speaker.
S1: Is the volume set too low? During playback, keep the [PUSH] Dial pressed until the [VOLUME] Indication appears. Then turn the [PUSH] Dial to adjust the volume. (→ 46)
- P2:** Different sounds are played back together.
S2: [12bit AUDIO] on the [VCR MENU1] Menu is set to [MIX]. Therefore, the original sound and the sound dubbed with audio dubbing are played back together. It is also possible to play them back individually. (→ 98)
- P3:** The original sound was erased by performing audio dubbing.
S3: If you perform audio dubbing on a recording made in the [16bit] Mode (→ 96), the original sound is erased. If you want to keep the original sound, be sure to select the [12bit] Mode for the original recording.
- P4:** No playback sound is reproduced.
S4-1: Are you playing back a cassette that was recorded with [AUDIO REC] on the [CAMERA MENU2] Menu set to [12bit]? In this case, make sure that [12bit AUDIO] on the [VCR MENU1] Menu is set to [ST1] (→ 98).
S4-2: Is the Variable Speed Search Function activated? Press the Play Button (▶) to cancel the Variable Speed Search Function (→ 48).

-188-

1 CGP-D110	2 CGP-D120	3 CGP-D210	4 CGR-D220	5 CGR-D815	6 VW-KATE	7 VW-K10E
8 VW-LW3007E	9 VW-LT3014E	10 VW-LND30E	11 VW-VMS1E	12 VW-SK10E	13 VZ-CT55E	14 VW-EC500E
15 VW-EC1E	16 VW-VT1E	17 VW-DTA1E	18 VW-K5E	19 VW-CD1E		

Optional Accessories

- 1** Battery Pack (Lithium)
2 Battery Pack (Lithium)
3 Battery Pack (Lithium)
4 Battery Pack (Lithium)
5 Battery Pack (Lithium)
6 Car Adaptor Cord
7 5-Pin Synchro Cord
8 Wide Conversion Lens
9 Tele Conversion Lens
10 ND Filter
- 11** Stereo Zoom Microphone
12 Shoe Adaptor
13 Tripod
14 Editing Controller
15 Editing Controller
16 Video Tiller
17 Personal Computer Connection Kit
18 Edit Cable
19 DV Cable
- Some accessories are not available in some countries.

-190-

SECTION 2

ADJUSTMENT PROCEDURES

2-1. DISASSEMBLE FLOW CHART

This flow chart indicates the disassembly steps the cabinet parts, C.B.A. and Mechanism Unit in order to access to items to be serviced. When reinstalling, perform the steps in the reverse order.





Fig. F1

2-2. DISASSEMBLY PROCEDURES

Flow-chart Disassembly procedure

No.	Item / Part	Fig.	Removal (Screw & Other)
(1)	Front Case Unit	Fig. 1	2-Screws (A) Unlock—Locking Tabs Remove the Grip Cover. 7-Screws (B/C/D/E) Disconnect FP6304. Remove the Front Case Unit.
(2)	Power C.B.A.	Fig. 2	2-Screws (F) Unlock—Locking Tab Remove the Bottom Case Unit. Disconnect PS1001/FP1001.
(3)	Side Case (R) Unit & Operation I/F C.B.A.	Fig. 3-1 Fig. 3-2	8-Screws (G/H/I/J) Disconnect FP601/FP602/FP3301. Remove the Side Case (R) Unit. Disconnect FP6702/PP3401/FP6302. Remove the Operation I/F C.B.A.
(4)	Top Case Unit & EVF Unit	Fig. 4	2-Screws (K/L) Disconnect FP4201/FP801.
(5)	Mic Unit C.B.A. & E.V.F. (A)/(B) & VTR Operation Unit	Fig. 5	1-Screw (M) 2-Screws (N) Unlock—Locking Tabs Remove the Mic Unit C.B.A. & E.V.F. (A)/(B) C.B.A. & VTR Operation Unit.
(6)	Lens Unit	Fig. 6	1-Screw (O) Disconnect PS201/FP701. Remove the Lens Unit.
(7)	LCD Unit	Fig. 7	3-Screws (P) Remove the LCD Top Case Unit. 1-Screw (Q) Remove the LCD Flex. Fixing Piece. Disconnect the FP905 & remove the Hall Sensor Flex. Card. Disconnect the FP901/FP902/FP903 and FP904. Unlock—Locking Tab Remove the Monitor C.B.A.
(8)	Side Case (L) Unit	Fig. 8	4-Screws (R/S) Disconnect FP6001/FP6303. Unlock—Locking Tabs Remove the Side Case (L) Unit.
(9)	VTR Main C.B.A.	Fig. 9	Disconnect FP2204/PS2001/FP3201. Unlock—Locking Tabs Remove the VTR Main C.B.A.
(10)	Drive C.B.A. & Mecha. Unit	Fig. 10	1-Screw (T) Disconnect FP2201/FP2202/FP2203. Unlock—Locking Tabs Remove the Drive C.B.A. 3-Screws (U) Remove the Mecha. Unit.




Fig. 1




Fig. 2




Fig. 3-1




Fig. 3-2




Fig. 4




Fig. 5




Fig. 7







Fig. 6



2-3. DISASSEMBLY PROCEDURES OF LENS UNIT

The following flowchart describes order or steps for removing the lens units and certain printed circuit boards in order to make access to the item needing service.

To reassemble the unit follow the steps in reverse order.




Fig. L1




Fig. L2

SECTION 3

BLOCK DIAGRAMS & SCHEMATIC DIAGRAMS

3-1. ABBREVIATIONS

INITIAL/LOGO		ABBREVIATIONS		INITIAL/LOGO		ABBREVIATIONS	
A	A GND	Analogue GND		ALC MAIN	Auto Level Control Drive		
	A HASW	Audio Head Amp Switching Pulse		ALE	Address Latch Enable		
	A HSW	Audio Switching Pulse		A-LOCK	Full Auto Switch		
	A MUTE	Audio Mute		A-MUT(H)	Audio Mute (H)		
	A ORP	Audio Overlap Pulse		ANLPTH	Analogue Loop Through High		
	A. TR	Auto Tracking		AORP	Audio Overlap Pulse		
	A0-8, 0-17	Memory Address		APCNT	Aperture Control		
	A3V2	AD Converter Reference Voltage		APS	Auto Power Save		
	AB0-4	Address Bus		ART VH	Artificial Vertical Sync		
	AB0-4, AB12-15	Address Bus Line 0-4, 12-15		AT CNT	Automatic Tracking Gain Adjust		
	ABSF	Focus Encoder Input		ATF	Automatic Track Finding		
	ACI	Analogue Channel Cording IC		ATFCLK	41.85MHz Clock		
	AD	AD Converter		ATFG	Auto Track Gain		
	AD	Auto Date, Analogue Digital Converter		ATL	Auto Lock Select		
	AD CLK	AD Clock		ATN	Absolute Track Number		
	AD REC	Audio Delayed REC		ATR OFF(H)	Auto Tracking Off (H)		
	AD0-6	Address		ATV	Advanced TV		
	AD0-6, ADR0-6	Address Data Line		AUDIO(N)	Audio (Normal)		
	ADCLK	Analogue Digital Converter Clock		AUX	Auxiliary		
	ADCNT	Analogue Digital Control		AVDD	Analogue VDD		
	ADCS	Analogue Digital Chip Select		AVSS	Analogue Ground		
	A-DET	Audio Detect		AWTB	Auto White Balance B-Y		
	ADREC	Audio Delaied Rec		AWTR	Auto White Balance R-Y		
	ADUB	Audio Dubbing					
	AE	Auto Expose		B	BACK	Back-up	
	AECNT	Auto Expose Control			BACK UP	Microcomputer Back-up	
	AEE(H)	Audio E-E (H)			BACK VDD	Back-up Power	
	AEH	Audio Erase Head			BATT	Battery	
	AEIRQ	Auto Expose Interrupt Request			BATT ALARM	Battery Alarm	
	AF/MF	Auto Focus/Manual Focus			BATT REF	Reference Voltage for Battery	
	AF DIS CS	AF DIS Chip Select			BCB	B Carrier Balance	
	A-FADE(L)	Audio Fade (L)			BCBM(B-Y)	B-Y Carrier Balance	
	AF-AMP	AF HALL Bias			BCBM(R-Y)	R-Y Carrier Balance	
	AFCs	Auto Focus Chip Select			BD0-7	REC/Play In/Out Buss	
	AFRP	Audio PLL Voltage Control			BDCK	Standard Bus Data Clock (9MHz)	
	AF-VN	Zoom Encoder V-Ref (-)			BDEN	Standard Bus Data Enable	
	AF-VP	Zoom Encoder VREF (+)			BEND	Data Block End Request	
	AGC	Automatic Gain Control			BF	Burst Flag Pulse	
	AGCCNT	Automatic Gain Control Control			BFA	Burst Flag Pulse for Encoder	
	AGND	Analogue Ground/Audio Ground			BFO/BFI	Burst Flug Input/Output	
	AGS	Anti Ground Shooting			BI, BO	Buffer Input, Output	
	AH(P) / (R)	Audio Head (Play) / (Record)			BL	Back Light	
	AHASW	Audio Head Amp Switch Pulse			BL ON	Back Light ON (L)	
	AHSW	Audio Head Switch Pulse			BL4V	Back Light 4V	
	AI, AO	Buffer Input, Output			BLC 0, 1	Back Light Y Control Out, In	
	AIBCK	Bit Clock (to A/D Converter)			BLDI/O	Back Light Drive Input/Output	
	AIDAT	Serial Data (to A/D Converter)			BLK	Blanking Pulse	
	AILRCK	L/R Clock (to A/D Converter)			BLKA	Blanking for Encoder	
AIMCK	Master Clock (to A/D Converter)		BLKA		Blanking Pulse for Encoder		
ALC CNT	Auto Level Control Control		BLKI/O		Blanking Pulse In/Out		

INITIAL/LOGO		ABBREVIATIONS	INITIAL/LOGO		ABBREVIATIONS
	BLKZ	Blanking Pulse for Zoom Encoder		CH1	Channel 1 (Odd Field)
	BM	Balance Modulator		CHR	Character
	BQUIET	Bus Out Control Signal		CHR BACK	Character Back-up
	BUF IN/OUT	Buffer In/Out		CHR MIX	Character Mix
	B-Y KB	B-Y Carrier Balance		CI, CO	Buffer In/Out
	B-YO	B-Y Signal Out		CI,CO	Buffer Input & Output
C	C A In/Out	Pre-Aperture In/Out		CIF	Control Signal Forward Input
	CAPSTP	Capstan Stop Flag		CIF, CIR	Positive Control Pulse, Negative Control Pulse
	C CNT	Colour Control		CIR	Control Signal Reverse Input
	C SYNC	Composite Sync Signal		CK	Clock
	C/N	Carrier/Noise		CL/CLK	Clock
	C0-7, C00-07	Chrominance Signal 0-7		CLASS	Classification Signal for Compress (DCT/VLC)
	CAGAIN	Aperture Gain Control		CLASS 0.1	Class Control Signal Durring DCT/VLC
	CAM	Camera		CLK135	13.5MHz System Clock
	CAM CLK	Camera Clock		CLK18	18MHz System Clock
	CAM RST	Camera Reset		CLK2	Clock 2 (824XFH: 12.875MHz)
	CAM SIOC	Camera Serial In/Out Contol		CLK246	24.576MHz Clock
	CAM T	Camera Test		CLK27	27MHz System Clock
	CAM TL	Capstan Trque Limit		CLK450	450KHz Clock
	CAP EC	Capstan Trque Control		CLKDCLK	Digital Clock
	CAP P(H)	Capstan Power On (H)		CLK-PH	Clock Phase Control
	CAP R/F/S	Capstan Reverse (H)/Stop (M)/Forward (L)		CLK-REF	Reference Clock
	CAP SW	Capstan Power Control Switch		CLP-RST-H	Clamp Reset High Signal
	CAPSTP H	Capstan Stop Flag (Stop High)		CLX	TFT X-axis Transmission Clock
	CAPVM	Capstan Motor Current		CLX, CLX1-4	Shift Clock for X Direction (LCD Panel)
	CAPVS	Capstan Motor Power Control Switch		CLY	Shift Clock for Y Direction (LCD Panel)
	CAS	Compresion, Audio Process, Shuffling/Deshuffling		CLY	TFT Y-axis Transmission Clock
	CAS	Memory Address Strobe (Active Low)		CLY FG	Cylinder FG Signal
	CASDOWN, DWN	Cassette Down (L)		CMEMO0-3	Chroma Memory Output Signal 0-3
	CB, CR	Chroma B, Chroma R		CMIX	Character Mix
	CBLK	Composite Blanking Pulse		CMO	Chrominance Memory Output
	CC	Channel Cording		COMPC	Position Detection Pulse
	CCA	Curent Drive Control		COM RDY	Serial Enable Signal
	CCA	Current Control Amp		CMODE	Camera Mode
	CCD	Charge Coupled Devise		CNCLK	Clock
	CCW	Counterclockwise		CNR	Chrominance Noise Reduction
	CD SP0-7	Digital Chroma		CNT, CONT	Control
	CDS	Correlate Double Sampling Signal		CO	Control Out
	CDS1, 2	Sampling Pulse for CCD Output Signal		CO0-7	Chrominance Output 0 to 7 (Digital)
	CE	Chip Enable		COM	Common
	CE	Control Pulse Erase		COM RDY	Serial Transmission Enable
	CEC	Capstan Error Code		COMB	Comb Filter
	C-ERA(H)	Control Erase (H)		COS EQ	Cosin Equalizer
	CFEM	Chrominance Memory Signal		CP	Clamp Pulse
	CFM	Chrominance Field Memory		CP ON(H)	Camera Power On(H)
	CFM1-4	Chroma Field Memory Signal		CP2, 20	Clamp Pulse
	CG CLK	Character Generator Clock		CP2A, CP2O	Encoder Clamp Pulse
	CG CLK DATA	Clock Generator Data		CPN	Component Signal
	CG DATA	Character Generator Data		CPOB	Clamp Pulse for Optical Blanking
	CGC	Chrominance Gain Control		CPS	Composite Signal
	CGCS	Character Generator Chip Select		CPV	Gate Scan Clock
	CGO	Character Generator Serial Data		CR OUT	Pre Apature Out
	CH	Charge		CR POW SW	Camera Remote Power On Switch
				CRA	Aperture Gain Control

INITIAL/LOGO		ABBREVIATIONS	INITIAL/LOGO		ABBREVIATIONS
	CRA	Pre Apature Gain Control		DISCS	Dis Chip Select
	CRST	Camera Reset		DISP	Display
	CS	Chip Select		DL	Delay Line
	CS 0-7	Chrominance Signal Out 0-7		DOBCK	Audio A/D Converter Bit Clock
	CSEL	Clock Phase Select		DOCTL	Data Output Control Signal
	CSI 0-7	Chrominance Signal In 0-7		DODAT	Serial Data (to D/A Converter)
	CTSW	Crosstalk Switch		DOLRCK	Audio A/D Converter LR Clock
	CURR	Current		DOLRCK	L/R Clock (to D/A Converter)
	CW	Clockwise		DOMCK	Audio A/D Converter Master Clock
	CYL EC	Cylinder Motor Trque Control		DOMCK	Master Clock (to D/A Converter)
	CYL PG	Cylinder Motor PG		DQ 1-16	Memory Data
	CYL VM	Cylinder Motor Current or Power		DRAM CAS	D-RAM Colum Address Strobe
				DRAM OE	D-RAM Out Enable
				DRAM RAS	D-RAM Read Address Strobe
				DREC	AV Delayed REC Start Pulse
				DRK	Dark (LPF Switch for Auto Focus)
				DS1, 2	Double Sampling Pulse
				DSF 0-7	Data In/Out for Shaffling Memory
				DSF 0-7	Input/Output Data to Shuffling Memory (18MHz)
				DSP	Digital Signal Processor
				DSP R/B	DSP IC Rady/Busy
				DSP-48K-H	DSP IC Clock Select
				DSTB	Data Stobe Signal
				DSV	Digital Sum Variation
				DV	Digital Video
				DVB	Digital Video Broadcast
				DVC	Digital Video Cassette
				DVDD	Digital VDD
				DVIO	Digital Video Input Output
				DVSS	Digital Ground
				DX	Shift Data for X Direction (for LCD)
				DY	Shift Data for Y Direction (for LCD)
				DY	TFT Y-axis Shift Data
				DZ	Digital Zoom
D	D CLK	Digital Clock			
	D MODE	Digital Mode Switch Signal			
	D01-03	Zoom 01-03			
	DA UV SEL	D/A Converter U/V Select			
	DAC	Digital Analogue Converter			
	DAG	Digital Analogue Ground			
	DB0-7	Data 0-7			
	DB0-7	Microprocessor Data			
	DCC	DC Clamp Control			
	DCCNT	DC Control			
	DCI	Digital Channel Cording IC			
	DCLR	Digital Clear			
	DCP	Digital Clamp Pulse			
	DCS-CLK, DA	CAS & DV I/F Serial Clock			
	DC-STP1	DCS Serial Start			
	DC-STP2	DCS Serial Stop			
	DCT	Discrete Cosine Transform (Compression)			
	DCX7	Serial Data			
	DEDP 0-3	Playback Data			
	DEDR 0-3	Rec Data			
	DEMO	Demodulation			
	DEMP	A/D Converter Empahsis Control			
	DEMP	De-Emphasis			
	DFD 0-7	Encode Data In/Out Between Shaffling Memory			
	DFD0-7	Encode Input/Output Signal for Shuffling Memory			
	DIBDCK	Bit Clock			
	DICLK	Digital Clock			
	DIDAT	Serial Data			
	DIDAT	Serial Data Durring Digital Audio In			
	DIF	Digital Interface			
	DILRCK	L/R Clock			
	DILRCK	Serial Clock Durring Digital Audio In			
	DIMCK	Master Clock			
	DIMCK	Mater Clock Durring Digital Audio In			
	DIO 1-8	Data In/Out			
	DIOS	Data In/Out Select Control Signal			
	DIOS	Select Signal for Digital In/Out			
	DIS	Digital Image Stabilizer			
	DIS R/B	Digital Image Stabilizer Read (H)/Busy (L)			
	DIS R/B	DIS IC Rady/Busy			
	DIS/KAND	Digital Image Stabilizer/Sensitivity			
			E	E Snap	Electric Snap Shot
				E ZM	Electric Zoom
				E2 CS or E2P CS	EEPROM Chip Select
				E2 R/B	EEPROM Rady/Busy
				E2P	EEPROM
				EARP	Earphone
				EC	Torque Control
				ECC	Error Correction Cording
				ECM	Electric Condencer Mic
				ECR	Reference Voltage for Capstan Torque
				EDA	Error Correction, DCI, ATF Servo
				EE CS	EEPROM Chip Select
				EE R/B	EEPROM Read (H)/Busy (L)
				EEPROM	Electric Erasable Programable Read Only Memory
				EIS	Electric Image Stabilizer (DIS)
				EMP	A/D Converter Emphasis Control
				ENAB	Enable
				ENV	Enverope
				EOB	End of Block


INITIAL/LOGO		ABBREVIATIONS	INITIAL/LOGO		ABBREVIATIONS
	EQ	Equalizer		HD	Horizontal Drive Pulse
	EVF	Electric View Finder		HDTV	High Definition TV
	EXT DC	External DC (AC Adaptor)		HEX	Hexadecimal
	EXT DC(H)	AC Adaptor DC (H)		HG	Hall Gain
	EXT NOREG	AC Adaptor 6V		HID	Head Switching Pulse
	EXT S DATA	Serial Data for Edit		HLT	High Bright Signal
	EXT SCK	Serial Clock for Edit		HALL IN(+), (-)	Input Signal from Hall IC
	EZOOM	Electric Zoom		HP	Headphone
F	F ENC	Lens F-Value		HPF	High Pass Filter
	FACT MODE	Factory Mode (not used in the service)		HSE	Modulated Data Output
	FB	Feed Back		HSP	Timing Pulse for Shuffling Memory
	FC	Saw Tooth Signal In		HSS	Horizontal Sync Signal
	FCK	Clock		HSW	Head Switching Pulse
	FCO	Saw Tooth Signal Generator		HS-WT	High Speed Zoom
	FENC	Focus Encoder		HSZ	High Speed Zoom
	FEND	Frame End Pulse	I	I/F	Interface
	FH2B	FH/2 (15.625KHz / 2=7.8125KHz)		I-2 C	Inter Integrated Circuit
	FIX OSD	Auto Tracking Off (H)		ID(H)	Wide Television (H)
	FLICK	Flicker Output		IMP	Inter Microprocessor Protocol
	FM	Field Memory		INF	CCD Input Signal 1
	FM0-7	Field Memory 0-7		INF	Input Frame Signal
	FMCO0-3	Field Memory Chrominance Out 0-4		INS	CCD Input Signal 2
	FMDIR	Focus Motor Direction		INTER	Interval Recording
	FMOEM	Field Memory Enable		INV	Inverter
	FMOEO	Field Memory Enable		IOU	R-Y Analogue Signal Output
	FMT1-4	Focus Motor Terminal 1-4		IOV	B-Y Analogue Signal Output
	FMY00-07	Field Memory Luminance Out 0-7		IOY	Y Analogue Signal Output
	FMY10-07	Field Memory Luminance In 0-7		IR	Infrared Rays
	FNO	F Value		IRDET	Infrared Ray Detection
	FPS	Frame Reference Signal		IREF	Current Adjustment Terminal
	FR	Capstan Reverse High		IRIS/SH	Iris / Shutter Control
	FRP	Frame Reference Pulse		IRQ	Interrupt Request
	FRPSO	Frame Start Pulse		ITI	Insert & Track Information
G	G1, G2, G3	Gap 1, 2 and 3	J	JPEG	Joint Photographic Image Cording Experts Group
	GCA	Gain Control AMP	K	KANDO	Digital Gain Up
	GCNT	Gain Control		KB	Carrier Balance
	G-CNT	AGC Adjustment		KEY IN	Key Scan
	GCTRL	Gain Control		KND	Digital Gain Up
	GENE	Generator		KNEE	Luminance Compensate
	GF	FG AMP Terminal	L	LCD	Liquid Crystal Display
	GSW	Ground for Switching Power		LCD P(L)	LCD Power On (L)
H	H/M/N	Hi-Fi / Mix / Normal		LD	Load Pulse
	H/N	Hi-Fi / Normal		LDD	Liquid Direct Drive
	H1, 2	H. CCD Drive Pulse		LEDCNT	LED Control
	HAP	Horizontal Aperture		LI-BATT	Lithium Battery
	HASW	Head AMP Switching Pulse		LOAD	Loading
	HB	Hall Bias		LOAD F, R	Loading Direction (F: Forward / R: Reverse)
	HBR SET	High Brightness Set		LPF	Low Pass Filter
	HBRST	High Brightness Set		LRMONO	Monoral Audio (L + R)
	HCLR	High Clear		LSB	Least Significant Bit
	HCP	Shift Clock for Horizontal Drive			

INITIAL/LOGO		ABBREVIATIONS	INITIAL/LOGO		ABBREVIATIONS
	LVL	LPF Switch for Auto Focus	P	P SW	Power Switch
				PB1-3	PNP Base 1-3
M	M1-3	Motor Coil Terminal 1 to 3		PBCTL	Play Back Control
	MA0-5	Microprocessor Address Data 0-5		PBCTL	Pre-Blanking Control
	Mbps	Megahertz Bit Per Second		PBH	Head Amp Switch
	MD	Modulation		PBLK	Pre-Blanking (Pulse)
	MD0-7	Microprocessor Data 0-7		PC1-3	Corrector of PNP Transistor
	MDT0-7	Microprocessor Data 0-7		PCBM	Carrier Balance
	ME (TAPE)	Metal Evaporated (Tape)		PCH	Phase Compensator (Hall AMP)
	MENB	Focus Motor Enable		PCI	Phase Compensator (Current)
	MFF	Manual Focus Far		PCO	Phase Compensator Out
	MFN	Manual Focus Near		PCS	Switching Power Control
	MHSYNC	Monitor Horizontal Sync Signal		PCV	Phase Compensator (Voltage)
	MIC	Memory In Cassette		PE	Emitter of PNP Transistor
	MIG	Meta In Gap		PED	Pedestal
	MIX N.R.D.	Non Rec Data Mix		PEDECNT	Pedestal Control
	MOD	Modulation		PENO	Alarm (L)
	MOUT	Mic Out		PFP	Pilot Frame Position
	MP (TAPE)	Metal Particle (Tape)		PGA, B	Power Ground A, B
	MPEG	Moving Picture Image Cording Experts Group		PGC	Pulse Generator Comparator
	MPEG2	Moving Picture Image Cording Experts Group Phase 2		PGI	Pulse Generator Input
	MRST	Focus Motor Reset		PGMM	Pulse Generator Monostable Multivibrator
	MSB	Most Signal Bit		PGO	Output of Pulse Generator AMP
	MVSYNC	Monitor Vertical Sync Signal		PMODE	Select Signal for Normal / Wide Screen
				PON	Power On
N	N/F	Near/Far Focus		POR	Power On Reset
	N/P	NTSC/PAL		POSCOM	Common Position
	NB1-3	Base for NPN Transistor		PREAMP	Pre-AMP
	NC	No Connection		PREBLK	Pre-Blanking
	NC1-3	Corrector of NPN Transistor		PT	Protect for V Voltage
	NCLR	Power On Reset		PWM	Pulse Width Modulation
	NCP1	Clamp Pulse		PWMB	Pulse Width Modulation Pulse
	NCP2+VDH	Clamp Pulse + Horizontal Drive Pulse			
	NCP2+VDM	Clamp Pulse + Gate Pulse	Q	Q2H	Source Output Select
	NDE	Non Liner De-Emphasis			
	NE	Emitor of NPN Transistor	R	R CTL P	Recorded Control Pulse (+)
	NLE	Non Liner Emphasis		R CTL R	Recorded Control Pulse (-)
	NR	Noise Reduction		R/B	Read/Busy
	NRD	Non Rec Data		R/L	Direction Control for Data Transmition
	NRD BLK	Non Rec Data Blanking		RA	Recording AMP
	NRD CLK	No Rec Data Clock		RA1	Rec AMP 1
	NRE	Read Enable Input (Low Active)		RAC AC	Rec Audio Current
	NWE	Write Enable (Low Active)		RAD	Read Address Data
				RAE	Read Address Enable
O	OB	Optical Black		RB	Read Busy
	OBCNT	Optical Black Control		R-B	R Bias
	OBREF	Reference Voltage for Optical Black Control		RCB	R Carrier Balance
	OE	Output Enable		RE	Read Enable
	OFH	Horizontal Counted Down Clock Signal (Reference)		RE(F), (S)	Rotary Erase Head Transformer
	OFS	Offset		REB	R Bias
	OP	Operation AMP Output		REC CC	Rec Current Control
	OSD	ON Screen Display		REC CCNT	Rec Current Control
	OVL	Overlap Pulse		RECCTRL	Recording Control Pulse
	OZ	Optical Zoom		RECI	Rec Amp Switch


INITIAL/LOGO		ABBREVIATIONS		INITIAL/LOGO		ABBREVIATIONS	
	RENCF	Lens Control (Forward)			SWB	Switching Pre-Drive Pulse	
	RENCR	Lens Control (Reverse)			SYL EC	Cylinder Torque Control	
	RERASE	Rotary Erase Head			SYL FG	Cylinder FG	
	RGBIV1-2	1V Inverted Signal 1-2					
	RGO R/G OFF	Offset Voltage for AWT R		T	T PHOT	Take-up Photo Transistor	
	RSF	Capstan Direction (Reverse / Stop / Forward)			TBC	Time Base Control	
	RST	Reset			TFT	Thin Film Transistor	
	RSTB	R Strobe			TH	Thermostat for Battery	
	RSTPWD	Reset Power Down Input			TI	Test Mode Select	
	RSTR	Reset Read			TL	Torque Limit	
	RSTW	Reset Write			TM	Sub Code	
	RT	Saw Tooth Terminal			TMD	Sub Code Data	
	RVCO	Resistor for Oscillation			TRE	Tracking Error Signal	
	RW	Read Write			TREEL(P)	Take-up Reel (Pulse)	
	RWAE	Read Write Enable			TRFIX	Tracking Fix	
					TRIWAVE	Tracking Wave	
					TRP	Tracking Position	
					TRP	Trap	
					TSR	Head Switching Reference	
					TST	Time Scale Transfer	
S	S PHOT	Supply Photo Transistor		U	U/V SEL	R-Y/B-Y Select Signal	
	S/H	Sampling Hold			UNLOAD	Un-Loading	
	S/S	Start/Stop			UNRE	Microprocessor Read Enable	
	SBD	Serial Data			UNWE	Microprocessor Write Enable	
	SBI	Serial Data Input			UV	R-Y/B-Y	
	SBO	Serial Data Output			UV SEL	R-Y/B-Y Select Signal	
	SBT	Serial Clock					
	SCAN0-5	Key Scan 0-5		V	V1-V4	V. CCD Drive Pulse	
	SCK	Serial Clock			VB	VH Filter Switching	
	SCR	Search			VCE	Power Terminal	
	SCR, S.C.R.	Still Cue Review			VCNTL	Video Control	
	SEG.	Segment			VCO	Voltage Control Oscillator	
	SET	White Balance Set			VCP	Shift Clock Output for Vertical Drive	
	SH/IRIS	Shutter/Iris Control			VCTLD	Video Control	
	SHIFT	Capacitor for Phase Shift			VCTRL	Voltage Charge Control	
	SI	Serial Data Input			VD	Vertical Drive Pulse	
	SIC	Shift In Clock Input			VDDX	X Drive Power for Colour LCD	
	SIOC	Serial In/Out Control			VDDXY	XY Drive Power for Colour LCD	
	SMCE	Shuffling Memory Chip Enable			VDDY	Y Drive Power for Colour LCD	
	SMRS	Shuffling Memory Read Strobe			VDREC	Video Delayed Rec	
	SMWE	Shuffling Memory Write Enable			Vgg	Voltage for Gate IC	
	SMWS	Shuffling Memory Read Strobe			Vgl	Gate off Voltage	
	SNAP	Snap Shot			VID	Video Signal Out	
	SNS LED	Sensor LED			VIN	Video In	
	SO	Serial Data Output			VITC	Vertical Interval Time Code	
	SPA	ATF Sampling Pulse			VITERBI	One of Signal Detection Method	
	SPEN	8 Bit Shift Register Enable			VL	Low Voltage	
	SPK	Speaker			VLC	Variable Length Coding	
	SPO	Reset for Switching Power			VLOCKP	Artificial Sync Pulse	
	SPST	8 Bit Shift Register Strobe			VLP	Artificial Sync Pulse	
	SREELP	Supply Reel Pulse			VM	Motor Voltage	
	SRT	Start			VMD	Velocity Mode Data	
	SSA	Start Sync block Area			VMD1-3	Electric Shutter Mode	
	SSW	Select Signal for Low Pass Filter					
	ST5V	Safety Tab 5V					
	STAB	Safety Tab Switch					
	STB	Stand by Signal					
	STB	Strobe					


INITIAL/LOGO		ABBREVIATIONS	INITIAL/LOGO		ABBREVIATIONS
	VMODE	NTSC/PAL Select Switch			
	VMVH	VH Filter Switching			
	VORP	Video Overlap			
	VRB	Voltage Reference Bottom			
	VRBS	Voltage Reference Bottom Output			
	VREF1R3V	Reference Voltage 1.3V			
	VREF3R3V	Reference Voltage 3.3V			
	VREFH	Reference Voltage High Side			
	VREFL	Reference Voltage Low Side			
	VRI	Reference Voltage Input			
	VRO	Reference Voltage Output			
	VRT	Voltage Reference Top			
	VRTS	Voltage Reference Top Output			
	VS	Switching Comparator			
	VSS	Vertical Sync Signal			
	VSSX	X Driver Power for Colour LCD			
	VSSXY	X-Y Driver Power for Colour LCD			
W	W/N	Mode Select for Window Mode			
	W/N	Wide / Normal			
	WAD	Write Address Enable			
	WAE	Write Address Enable			
	WAERAE	Write Address Enable			
	WARI	Interrupt			
	WB	White Balance			
	WE	Write Enable			
	WEM	Memory Write Enable			
	WHD	Wide Horizontal Drive Pulse			
	WIDE A	Wide Zoom			
	WSB	B AGC Control			
	WSR	R AGC Control			
	WTV	Wide TV			
X	XP	FG Logic Reset			
Y	Y FM0-7	Y Field Memory 0-7			
	YCE	Cylinder Error Code			
	YGC	Y Gain Control			
	YMO 0-7	Y Field Memory 0-7			
	YNCST	Noise Canceller			
	YNR	Luminance Noise Reduction			
	YSDP 0-7	Digital Y Out 0-7			
Z	Z.ENC	Zoom Encoder			
	Z.MIC	Zoom Mic			
	ZENC	Zoom Encoder Output			
	ZMDIR	Zoom Drive			
	ZMEN	Zoom Enable			
	ZMT	Zoom Motor Tele Side			
	ZMT (+)/(-)	Zoom Motor (+)/(-)			
	ZMTER	Zoom Motor Tele Side			
	ZMW	Zoom Motor Wide Side			
	ZSW	Zoom Switch			

3-2. OVERALL BLOCK DIAGRAM




3-3. INTERCONNECTION SCHEMATIC DIAGRAM







3-4. POWER SCHEMATIC DIAGRAM




3-5. DRIVE & IR SCHEMATIC DIAGRAM




3-6. MIC UNIT SCHEMATIC DIAGRAM




3-7. MONITOR & HALL SENSOR FLEX. CARD SCHEMATIC DIAGRAM




3-8. E.V.F. (A) & E.V.F. (B) SCHEMATIC DIAGRAM




3-9. CCD FLEX. CARD SCHEMATIC DIAGRAM




3-10. REAR OPERATION UNIT SCHEMATIC DIAGRAM




3-11. OPERATION I/F SCHEMATIC DIAGRAM



3-12. AV JACK SCHEMATIC DIAGRAM



3-13. CASSETTE DOWN FLEX. CARD SCHEMATIC DIAGRAM




NOTE: MULTILAYER C.B.A.
THIS C.B.A. IS Multi-Layer C.B.A. THIS CIRCUIT BOARD SHOWS COMPONENT LAYOUT-PATTERN FOR COMPONENT SIDE AND FOIL SIDE. LAYOUT-PATTERNS ARE SINGLE PATTERN FOR EACH SIDE THAT MAKE EASY TO SIGHT THE COMPONENT LAYOUT.

(FOIL SIDE)

(COMPONENT SIDE)

3-15. DRIVE C.B.A. (VEP02563A)




DRIVE C.B.A.	
Integrated Circuit	
IC2201	B-2
IC2202	C-2
IC2203	C-3
Connector	
FP2201	A-4
FP2202	C-5
FP2203	C-4
FP6304	C-4
PP2001	B-1
PS3801	A-2
Capacitor	
C2202	A-3
C2203	A-3
C2205	A-3
C2206	A-3
C2207	A-3
C2208	B-3
C2209	B-3
C2210	B-3
C2212	B-2
C2213	B-2
C2214	B-2
C2216	A-3
C2217	A-2
C2218	B-5
C2219	B-5
C2220	A-4
C2221	B-5
C2222	C-2
C2223	C-2
C2224	C-3
C2225	C-3
C2226	C-3
C2227	A-3
C2233	C-2
Resistor	
R2201	B-3
R2202	A-3
R2203	B-3
R2204	B-3
R2205	B-2
R2206	B-2
R2207	B-2
R2208	B-2
R2209	A-5
R2210	B-5
R2211	A-4
R2212	A-5
R2213	A-3
R2214	A-3
R2215	A-2
R2216	B-3
R2217	A-2
R2218	B-3
R6801	B-3

ADDRESS INFORMATION

3-16. MIC UNIT C.B.A. (VEP04736A)

MIC UNIT C.B.A.			C4013		C4014		C4015		C4016		C4017		C4018		C4019		C4020		C4021		C4022		C4023		C4024		C4025		C4026		C4027		C4028		C4029		C4030		C4031		C4032		C4033		C4034		C4035		C4036		C4037		C4038		C4039		C4040		C4041		C4042		C4043		C4044		C4045		C4046		C4047		C4048		C4049		C4050		C4051		C4052		C4053		C4054		C4055		C4056		C4057		C4058		C4059		C4060		C4061		C4062		C4063		C4064		C4065		C4066		C4067		C4068		C4069		C4070		C4071		C4072		C4073		C4074		C4075		C4076		C4077		C4078		C4079		C4080		C4081		C4082		C4083		C4084		C4085		C4086		C4087		C4088		C4089		C4090		C4091		C4092		C4093		C4094		C4095		C4096		C4097		C4098		C4099		C4100		C4101		C4102		C4103		C4104		C4105		C4106		C4107		C4108		C4109		C4110		C4111		C4112		C4113		C4114		C4115		C4116		C4117		C4118		C4119		C4120		C4121		C4122		C4123		C4124		C4125		C4126		C4127		C4128		C4129		C4130		C4131		C4132		C4133		C4134		C4135		C4136		C4137		C4138		C4139		C4140		C4141		C4142		C4143		C4144		C4145		C4146		C4147		C4148		C4149		C4150		C4151		C4152		C4153		C4154		C4155		C4156		C4157		C4158		C4159		C4160		C4161		C4162		C4163		C4164		C4165		C4166		C4167		C4168		C4169		C4170		C4171		C4172		C4173		C4174		C4175		C4176		C4177		C4178		C4179		C4180		C4181		C4182		C4183		C4184		C4185		C4186		C4187		C4188		C4189		C4190		C4191		C4192		C4193		C4194		C4195		C4196		C4197		C4198		C4199		C4200		C4201		C4202		C4203		C4204		C4205		C4206		C4207		C4208		C4209		C4210		C4211		C4212		C4213		C4214		C4215		C4216		C4217		C4218		C4219		C4220		C4221		C4222		C4223		C4224		C4225		C4226		C4227		C4228		C4229		C4230		C4231		C4232		C4233		C4234		C4235		C4236		C4237		C4238		C4239		C4240		C4241		C4242		C4243		C4244		C4245		C4246		C4247		C4248		C4249		C4250		C4251		C4252		C4253		C4254		C4255		C4256		C4257		C4258		C4259		C4260		C4261		C4262		C4263		C4264		C4265		C4266		C4267		C4268		C4269		C4270		C4271		C4272		C4273		C4274		C4275		C4276		C4277		C4278		C4279		C4280		C4281		C4282		C4283		C4284		C4285		C4286		C4287		C4288		C4289		C4290		C4291		C4292		C4293		C4294		C4295		C4296		C4297		C4298		C4299		C4300		C4301		C4302		C4303		C4304		C4305		C4306		C4307		C4308		C4309		C4310		C4311		C4312		C4313		C4314		C4315		C4316		C4317		C4318		C4319		C4320		C4321		C4322		C4323		C4324		C4325		C4326		C4327		C4328		C4329		C4330		C4331		C4332		C4333		C4334		C4335		C4336		C4337		C4338		C4339		C4340		C4341		C4342		C4343		C4344		C4345		C4346		C4347		C4348		C4349		C4350		C4351		C4352		C4353		C4354		C4355		C4356		C4357		C4358		C4359		C4360		C4361		C4362		C4363		C4364		C4365		C4366		C4367		C4368		C4369		C4370		C4371		C4372		C4373		C4374		C4375		C4376		C4377		C4378		C4379		C4380		C4381		C4382		C4383		C4384		C4385		C4386		C4387		C4388		C4389		C4390		C4391		C4392		C4393		C4394		C4395		C4396		C4397		C4398		C4399		C4400		C4401		C4402		C4403		C4404		C4405		C4406		C4407		C4408		C4409		C4410		C4411		C4412		C4413		C4414		C4415		C4416		C4417		C4418		C4419		C4420		C4421		C4422		C4423		C4424		C4425		C4426		C4427		C4428		C4429		C4430		C4431		C4432		C4433		C4434		C4435		C4436		C4437		C4438		C4439		C4440		C4441		C4442		C4443		C4444		C4445		C4446		C4447		C4448		C4449		C4450		C4451		C4452		C4453		C4454		C4455		C4456		C4457		C4458		C4459		C4460		C4461		C4462		C4463		C4464		C4465		C4466		C4467		C4468		C4469		C4470		C4471		C4472		C4473		C4474		C4475		C4476		C4477		C4478		C4479		C4480		C4481		C4482		C4483		C4484		C4485		C4486		C4487		C4488		C4489		C4490		C4491		C4492		C4493		C4494		C4495		C4496		C4497		C4498		C4499		C4500		C4501		C4502		C4503		C4504		C4505		C4506		C4507		C4508		C4509		C4510		C4511		C4512		C4513		C4514		C4515		C4516		C4517		C4518		C4519		C4520		C4521		C4522		C4523		C4524		C4525		C4526		C4527		C4528		C4529		C4530		C4531		C4532		C4533		C4534		C4535		C4536		C4537		C4538		C4539		C4540		C4541		C4542		C4543		C4544		C4545		C4546		C4547		C4548		C4549		C4550		C4551		C4552		C4553		C4554		C4555		C4556		C4557		C4558		C4559		C4560		C4561		C4562		C4563		C4564		C4565		C4566		C4567		C4568		C4569		C4570		C4571		C4572		C4573		C4574		C4575		C4576		C4577		C4578		C4579		C4580		C4581		C4582		C4583		C4584		C4585		C4586		C4587		C4588		C4589		C4590		C4591		C4592		C4593		C4594		C4595		C4596		C4597		C4598		C4599		C4600		C4601		C4602		C4603		C4604		C4605		C4606		C4607		C4608		C4609		C4610		C4611		C4612		C4613		C4614		C4615		C4616		C4617		C4618		C4619		C4620		C4621		C4622		C4623		C4624		C4625		C4626		C4627		C4628		C4629		C4630		C4631		C4632		C4633		C4634		C4635		C4636		C4637		C4638		C4639		C4640		C4641		C4642		C4643		C4644		C4645		C4646		C4647		C4648		C4649		C4650		C4651		C4652		C4653		C4654		C4655		C4656		C4657		C4658		C4659		C4660		C4661		C4662		C4663		C4664		C4665		C4666		C4667		C4668		C4669		C4670		C4671		C4672		C4673		C4674		C4675		C4676		C4677		C4678		C4679		C4680		C4681		C4682		C4683		C4684		C4685		C4686		C4687		C4688		C4689		C4690		C4691		C4692		C4693		C4694		C4695		C4696		C4697		C4698		C4699		C4700		C4701		C4702		C4703		C4704		C4705		C4706		C4707		C4708		C4709		C4710		C4711		C4712		C4713		C4714		C4715		C4716		C4717		C4718		C4719		C4720		C4721		C4722		C4723		C4724		C4725		C4726		C4727		C4728		C4729		C4730		C4731		C4732		C4733		C4734		C4735		C4736		C4737		C4738		C4739		C4740		C4741		C4742		C4743		C4744		C4745		C4746		C4747		C4748		C4749		C4750		C4751		C4752		C4753		C4754		C4755		C4756		C4757		C4758		C4759		C4760		C4761		C4762		C4763		C4764		C4765		C4766		C4767		C4768		C4769		C4770		C4771		C4772		C4773		C4774		C4775		C4776		C4777		C4778		C4779		C4780		C4781		C4782		C4783		C4784		C4785		C4786		C4787		C4788		C4789		C4790		C4791		C4792		C4793		C4794		C4795		C4796		C4797		C4798		C4799		C4800		C4801		C4802		C4803		C4804		C4805		C4806		C4807		C4808		C4809		C4810		C4811		C4812		C4813		C4814		C4815		C4816		C4817		C4818		C4819		C4820		C4821		C4822		C4823		C4824		C4825		C4826		C4827		C4828		C4829		C4830		C4831		C4832		C4833		C4834		C4835		C4836		C4837		C4838		C4839		C4840		C4841		C4842		C4843		C4844		C4845		C4846		C4847		C4848		C4849		C4850		C4851		C4852		C4853		C4854		C4855		C4856		C4857		C4858		C4859		C4860		C4861		C4862		C4863		C4864		C4865		C4866		C4867		C4868		C4869		C4870		C4871		C4872		C4873		C4874		C4875		C4876		C4877		C4878		C4879		C4880		C4881		C4882		C4883		C4884		C4885		C4886		C4887		C4888		C4889		C4890		C4891		C4892		C4893		C4894		C4895		C4896		C4897		C4898		C4899		C4900		C4901		C4902		C4903		C4904		C4905		C4906		C4907		C4908		C4909		C4910		C4911		C4912		C4913		C4914		C4915		C4916		C4917		C4918		C4919		C4920		C4921		C4922		C4923		C4924		C4925		C4926		C4927		C4928		C4929		C4930		C4931		C4932		C4933		C4934		C4935		C4936		C4937		C4938		C4939		C4940		C4941		C4942		C4943		C4944		C4945		C4946		C4947		C4948		C4949		C4950		C4951		C4952		C4953		C4954		C4955		C4956		C4957		C4958		C4959		C4960		C4961		C4962		C4963	
-----------------	--	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--	-------	--


ADDRESS INFORMATION



3-17. MONITOR C.B.A. (VEP26204B)

MONITOR C.B.A.			
Integrated Circuit		Transistor & Resistor	
IC901	A-3	QR901	B-4
IC902	A-4	QR902	B-2
IC903	A-4	Connector	
IC904	A-3		
IC905	A-2		
IC906	A-3		
IC907	A-3		
Transistor		Test Point	
Q901	B-1	CL901	A-4
Q902	A-2		
Q903	B-1		
Q904	A-4		
Q905	A-2		
Q906	A-2		

ADDRESS INFORMATION




B

A

3-18. E.V.F. (A) C.B.A. (VEP28254B)


E.V.F. (A) C.B.A.	
Integrated Circuit	
IC801	B-6
IC802	C-7
IC803	A-5
Diode	
D801	C-7
D803	B-7
Connector	
FP804	A-4
Coil	
L801	B-7
L803	C-6
L804	C-6
L805	C-6
L820	A-5
Capacitor	
C801	C-6
C802	C-6
C803	C-6
C804	C-7
C805	B-6
C806	C-7
C807	B-6
C808	C-6
C809	C-7
C810	B-7
C811	B-7
C812	B-7
C814	C-7
C820	B-5
C821	A-5
Resistor	
R802	C-6
R805	C-6
R807	C-6
R808	C-7
R810	B-7
R812	B-7
R813	B-7
R814	B-7
R815	C-7
R816	C-7
R817	C-7
R818	C-6
R820	B-5
R821	B-5
R822	A-5
R823	A-5
R824	A-5
R825	A-5
R826	A-5
R827	A-5
R828	A-5

ADDRESS INFORMATION




NOTE: MULTILAYER C.B.A.
THIS C.B.A. IS A MULTILAYER C.B.A. THIS CIRCUIT BOARD SHOWS COMPONENT LAYOUT PATTERN
FOR COMPONENT SIDE AND FOIL SIDE. LAYOUT PATTERNS ARE SINGLE PATTERN FOR EACH
SIDE THAT MAKE EASY TO SIGHT THE COMPONENT LAYOUT.

3-19. E.V.F. (B) C.B.A. (VEP28255A)



3-20. CCD FLEX. CARD C.B.A. (VEP22279A)



3-21. OPERATION I/F C.B.A. (VEP23479A)

NOTE : MULTILAYER C.B.A.


THIS C.B.A. IS Multi-Layer C.B.A. THIS CIRCUIT BOARD SHOWS COMPONENT LAYOUT-PATTERN FOR COMPONENT SIDE AND FOIL SIDE. LAYOUT-PATTERNS ARE SINGLE PATTERN FOR EACH SIDE THAT MAKE EASY TO SIGHT THE COMPONENT LAYOUT.



SECTION 4 EXPLODED VIEWS & PARTS LIST


4-1. EXPLODED VIEWS & MECHANICAL REPLACEMENT PARTS LIST

① FRAME & CASING PARTS SECTION (1)




Note: 1. *Be sure to make your orders of replacement parts according to this list.

2. IMPORTANT SAFETY NOTICE

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.


[illegible][illegible]

② FRAME & CASING PARTS SECTION (2)




Note: 1. *Be sure to make your orders of replacement parts according to this list.


2. IMPORTANT SAFETY NOTICE

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.

[illegible][illegible]

③ LCD PARTS SECTION



Note: 1. *Be sure to make your orders of replacement parts according to this list.
2. IMPORTANT SAFETY NOTICE
Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.

[illegible][illegible]

4



D

C

B

A |

1

2

3

4

5

Note


Components identified with the r

Components identified with the mark have the special characteristics for safety. When replacing any of these components, use only the same type.


Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
301	(4) VDL0916	CRYSTAL FILTER	1	
302	(4) VEK8530	CCD ASS'Y	1	
303	(4) VMX2758	CCD CUSHION	1	
304	(4) VXW0403	LENS ASS'Y	1	
304-1	(4) VEK8456	LENS FLEX. CARD C. B. A.	1	
304-2	(4) VEM0653	ZOOM MOTOR ASS'Y	1	
304-3	(4) VMA9961	SIDE YOKE	1	
304-4	(4) VMS6418	GUIDE POLE	1	
304-5	(4) VMS6487	GUIDE POLE (A)	1	
304-6	(4) VXP1886	2ND MOVING FRAME ASS'Y	1	
304-7	(4) VXP1887	4TH MOVING FRAME ASS'Y	1	
304-8	(4) VXQ0730	MAIN FRAME ASS'Y	1	
304-9	(4) VXQ0762	3RD LENS FRAME ASS'Y	1	
304-10	(4) VXL2834	IRIS ASS'Y	1	
304-11	(4) VXQ0752	MASTER FLANGE ASS'Y	1	

[illegible]

5 PACKING PARTS & ACCESSORIES SECTION



A vertical scale with four horizontal tick marks. The marks are labeled from bottom to top: A, B, C, and D.



1


2

3

4

2

2. IMPORTANT SAFETY NOTICE

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
401 (5)	VPN4995	CUSHION (UPPER)	1	
402 (5)	VPN4996	CUSHION (LOWER)	1	
403 (5)	VPK2218	PACKING	1	
⚠ 404 (5)	VQT7769	OPERATING INSTRUCTIONS	1	
⚠ 404 (5)	VQT7770	OPERATING INSTRUCTIONS	1	
⚠ 405 (5)	VJA0664	AC CORD	1	
⚠ 405 (5)	VJA0940	AC CORD	1	
406 (5)	VFA0292	HEADPHONE CONV. ADAPTOR	1	
407 (5)	VFA0151	21PIN ADAPTOR	1	
408 (5)	VEK8588	DC CABLE ASS'Y	1	
409 (5)	VSK0540	OUTPUT TERMINAL BOX	1	
410 (5)	VYC0777	HAND STRAP	1	
412 (5)	VPN4948	ACCESSORIES PACKING	1	
413 (5)	VJA0788	AV OUTPUT CABLE	1	
414 (5)	VYK8705	HAND GRIP	1	
415 (5)	VJA0658	S-VHS CABLE	1	
416 (5)	VJA1028	AV 4PIN CABLE	1	
417 (5)	VPN4949	PAD	1	
418 (5)	YQG5094	HOOD CAP FIXING PIECE	1	
419 (5)	VFC1792	LENS CLEANER	1	
420 (5)	VEQ2141	REMOTE CONTROLLER ASS'Y	1	
421 (5)	VFC2924	SOFT CASE	1	
422 (5)	VYQ1479	WIDE CONVERSION LENS	1	
423 (5)	VYQ1510	ND FILTER	1	
424 (5)	VPN5141	PAD	1	

[illegible]

4-2. ELECTRICAL REPLACEMENT PARTS LIST

Note: 1. Be sure to make your orders of replacement parts according to this list.

2. **IMPORTANT SAFETY NOTICE:** Components identified with the mark Δ have the special characteristics for safety. When replacing any of these components, use only the same type.

3. Unless otherwise specified,
All resistors are in OHMS, K=1,000 OHMS. All capacitors are in MICROFARADS (μ F), P= μ F.

4. The P.C. Board units marked with \blacksquare show below the main assembled parts.

5. The marking (RTL) indicates the retention time is limited for this item.

After the discontinuation of this assembly in production, it will no longer be available.

[illegible]

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
	■ VEPO1827B	POWER C. B. A.	1	(RTL)
C1001-04	ECUX1C106VBP	C. CAPACITOR CH 16V 10U	4	
C1005	ECUX1A335KBW	C. CAPACITOR CH 10V 3.3P	1	
C1011	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	1	
C1012	ECUX1A335KBW	C. CAPACITOR CH 10V 3.3P	1	
C1013	ECUX1E331KBQ	C. CAPACITOR CH 25V 330P	1	
C1014	ECUX1C223KBQ	C. CAPACITOR CH 16V 0.022U	1	
C1015	VCS0JN106	E. CAPACITOR 6.3V 10M	1	
C1016	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1	
C1018, 19	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	2	
C1021	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	1	
C1022	ECUX1A335KBW	C. CAPACITOR CH 10V 3.3P	1	
C1023	ECUX1E331KBQ	C. CAPACITOR CH 25V 330P	1	
C1024	ECUX1C223KBQ	C. CAPACITOR CH 16V 0.022U	1	
C1025	VCS0JN106	E. CAPACITOR 6.3V 10M	1	
C1026-29	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	4	
C1031	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	1	
C1032	ECUX1A335KBW	C. CAPACITOR CH 10V 3.3P	1	
C1033	ECUX1E102KBQ	C. CAPACITOR CH 25V 1000P	1	
C1034	ECUX1C103KBQ	C. CAPACITOR CH 16V 0.01U	1	
C1035	VCS0JN106	E. CAPACITOR 6.3V 10M	1	
C1036	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1	
C1037	VCS0JN106	E. CAPACITOR 6.3V 10M	1	
C1041	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	1	
C1042	ECUX1A335KBW	C. CAPACITOR CH 10V 3.3P	1	
C1044	ECUX1C223KBQ	C. CAPACITOR CH 16V 0.022U	1	
C1045	VCS0JN106	E. CAPACITOR 6.3V 10M	1	
C1046	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1	
C1052	ECUX1E105KBW	C. CAPACITOR CH 25V 1U	1	
C1053	ECUX1E222KBQ	C. CAPACITOR CH 25V 2200P	1	
C1055	ECUX1C225KBW	C. CAPACITOR CH 16V 2.2U	1	
C1056, 57	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	2	
C1063, 64	ECUX1A225KBW	C. CAPACITOR CH 10V 2.2U	2	
C1065, 66	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	2	
C1082	ECUX1E105KBW	C. CAPACITOR CH 25V 1U	1	
C1083	ECUX1E222KBQ	C. CAPACITOR CH 25V 2200P	1	
C1085	ECUX1C106VBP	C. CAPACITOR CH 16V 10U	1	
C1086, 87	ECUX1E105KBW	C. CAPACITOR CH 25V 1U	2	
C1101	ECUX1H101JCQ	C. CAPACITOR CH 50V 100P	1	
C1102	ECUX1C334KBN	C. CAPACITOR CH 16V 0.33U	1	
C1103	ECUX1A473KBQ	C. CAPACITOR CH 10V 0.047U	1	
C1104	ECUX1A104KBQ	C. CAPACITOR CH 10V 0.1U	1	
C1105	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1	
C1106	ECUX1A104KBQ	C. CAPACITOR CH 10V 0.1U	1	
C1107	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1	
C1108	ECUX1A104KBQ	C. CAPACITOR CH 10V 0.1U	1	
C1111	ECUX1H102KBV	C. CAPACITOR CH 50V 1000P	1	
C1112	ECUX1E471KBQ	C. CAPACITOR CH 25V 470P	1	
C1113	ECUX1H151JCQ	C. CAPACITOR CH 50V 150P	1	
C1114	ECUX1H390JCQ	C. CAPACITOR CH 50V 39P	1	
C1117	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1	
C1118	VCS0JN106	E. CAPACITOR 6.3V 10M	1	
C1119	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1	
C1121	ECUX1H472KBV	C. CAPACITOR CH 50V 4700P	1	
C1122	ECUX1C103KBQ	C. CAPACITOR CH 16V 0.01U	1	
C1123	ECUX1H151JCQ	C. CAPACITOR CH 50V 150P	1	
C1124	ECUX1H390JCQ	C. CAPACITOR CH 50V 39P	1	
C1127-29	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	3	
C1131	ECUX1H822KBV	C. CAPACITOR CH 50V 8200P	1	
C1132	ECUX1A473KBQ	C. CAPACITOR CH 10V 0.047U	1	
C1133	ECUX1H151JCQ	C. CAPACITOR CH 50V 150P	1	
C1134	ECUX1H390JCQ	C. CAPACITOR CH 50V 39P	1	
C1141, 42	ECUX1A224KBV	C. CAPACITOR CH 10V 0.022U	2	
C1143	ECUX1H151JCQ	C. CAPACITOR CH 50V 150P	1	
C1144	ECUX1H390JCQ	C. CAPACITOR CH 50V 39P	1	
C1151	ECUX1H471JCQ	C. CAPACITOR CH 50V 470P	1	
C1152	ECUX1E222KBQ	C. CAPACITOR CH 25V 2200P	1	
C1153	ECUX1H151JCQ	C. CAPACITOR CH 50V 150P	1	
C1154	ECUX1H820JCQ	C. CAPACITOR CH 50V 82P	1	
C1155	ECUX0J225KBW	C. CAPACITOR CH6.3V 2.2U	1	
C1181	ECUX1H822KBV	C. CAPACITOR CH 50V 8200P	1	
C1182	ECUX1C103KBQ	C. CAPACITOR CH 16V 0.01U	1	

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
QR4001	MRN1103	TRANSISTOR	1	
QR4002	MRN2103	TRANSISTOR	1	
QR4201, 02	MRN1104	TRANSISTOR	2	
QR4203	MRN1103	TRANSISTOR	1	
QR4801, 02	MRN1103	TRANSISTOR	2	
R4001, 02	ERJ2RHD273	M. RESISTOR CH 2W 27K	2	
R4003, 04	ERJ2RHD822	M. RESISTOR CH 2W 8.2K	2	
R4011, 12	ERJ2RHD103	M. RESISTOR CH 2W 10K	2	
R4013, 14	ERJ2RHD223	M. RESISTOR CH 2W 22K	2	
R4015, 16	ERJ2GEJ273	M. RESISTOR CH 2W 27K	2	
R4017, 18	ERJ2GEJ331	M. RESISTOR CH 2W 330	2	
R4021	ERJ2GEJ124	M. RESISTOR CH 2W 120K	1	
R4022	ERJ2GEJ681	M. RESISTOR CH 2W 680	1	
R4201, 02	ERJ2GEJ682	M. RESISTOR CH 2W 6.8K	2	
R4203, 04	ERJ2GEJ103	M. RESISTOR CH 2W 10K	2	
R4211	ERJ2GEJ473	M. RESISTOR CH 2W 47K	1	
R4223	ERJ2GEJ473	M. RESISTOR CH 2W 47K	1	
R4702	ERJ2GEJ102	M. RESISTOR CH 2W 1K	1	
R4703	ERJ2GEJ154	M. RESISTOR CH 2W 150K	1	
R4704	ERJ2GEJ392	M. RESISTOR CH 2W 3.9K	1	
R4706, 07	ERJ2GEJ822	M. RESISTOR CH 2W 8.2K	2	
R4708, 09	ERJ2GEJ392	M. RESISTOR CH 2W 3.9K	2	
R4710, 11	ERJ2GEJ102	M. RESISTOR CH 2W 1K	2	
R4801	ERJ6GEYG392	M. RESISTOR CH 1/10W 3.9K	1	
R4803	ERJ6GEYG392	M. RESISTOR CH 1/10W 3.9K	1	
R4805	ERJ2GEJ333	M. RESISTOR CH 2W 33K	1	
R4806	ERJ2GEJ823	M. RESISTOR CH 2W 82K	1	
R4807	ERJ2GEJ223	M. RESISTOR CH 2W 22K	1	
R4808	ERJ2GEJ104	M. RESISTOR CH 2W 100K	1	
R4809, 10	ERJ2GEJ103	M. RESISTOR CH 2W 10K	2	
R4811	ERJ2GEJ333	M. RESISTOR CH 2W 33K	1	
R4812	ERJ2GEJ823	M. RESISTOR CH 2W 82K	1	
R4813	ERJ2GEJ223	M. RESISTOR CH 2W 22K	1	
R4814	ERJ2GEJ104	M. RESISTOR CH 2W 100K	1	
R4815, 16	ERJ2GEJ103	M. RESISTOR CH 2W 10K	2	
R4817, 18	ERJ2GEJ393	M. RESISTOR CH 2W 39K	2	
R4823	ERJ2GEJ223	M. RESISTOR CH 2W 22K	1	
R4824	ERJ2GEJ333	M. RESISTOR CH 2W 33K	1	
R4831, 32	ERJ2GEJ472	M. RESISTOR CH 2W 4.7K	2	
R4833	ERJ2GEJ153	M. RESISTOR CH 2W 15K	1	
R4834	ERJ2GEJ222	M. RESISTOR CH 2W 2.2K	1	
R4835	ERJ2GEJ333	M. RESISTOR CH 2W 33K	1	
R4836	ERJ2GEJ104	M. RESISTOR CH 2W 100K	1	
R4837	ERJ2GEJ332	M. RESISTOR CH 2W 3.3K	1	
R4838	ERJ2GEJ153	M. RESISTOR CH 2W 15K	1	
R4839	ERJ2GEJ222	M. RESISTOR CH 2W 2.2K	1	
R4840	ERJ2GEJ333	M. RESISTOR CH 2W 33K	1	
R4841	ERJ2GEJ104	M. RESISTOR CH 2W 100K	1	
R4842	ERJ2GEJ332	M. RESISTOR CH 2W 3.3K	1	
R4843	ERJ2GEJ472	M. RESISTOR CH 2W 4.7K	1	
R4844-49	ERJ2GEJ153	M. RESISTOR CH 2W 15K	6	
R4850	ERJ2GEJ103	M. RESISTOR CH 2W 10K	1	
R4851	ERJ2GEJ332	M. RESISTOR CH 2W 3.3K	1	
R4852	ERJ2GEJ103	M. RESISTOR CH 2W 10K	1	
R4853	ERJ2GEJ332	M. RESISTOR CH 2W 3.3K	1	
R4860	ERJ2GEJ104	M. RESISTOR CH 2W 100K	1	
R4863	ERJ2GEJ104	M. RESISTOR CH 2W 100K	1	
R4999	VEK8428	DEW SENSOR ASS'Y	1	
RA4001	EXB24V562J	COMBI. R-R 5.6K	1	
X4701	VXS0982	CRYSTAL OSCILLATOR	1	
		MISCELLANEOUS		
	VMT0902	MIC DUMPER	1	
	VMP5673	DEW HOLER ANGLE	1	
	XQN2+B2	SCREW	1	
	XQN16+B2FZ	SCREW	1	


Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
	VEP28254B	E. V. F. (A) C. B. A.	1	(RTL)
C801	ECUX1A335KBM	C. CAPACITOR CH 10V 3.3P	1	
C802	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	1	
C803	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1	
C804, 05	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	2	
C806	ECST0JY106Z	T. CAPACITOR CH6.3V 10U	1	
C807-09	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	3	
C810	ECUX1H102KBV	C. CAPACITOR CH 50V 1000P	1	
C811	ECUX1H472KBV	C. CAPACITOR CH 50V 4700P	1	
C812	ECST1CY225Z	T. CAPACITOR CH 16V 2.2U	1	
C814	ECUX1H470JCV	C. CAPACITOR CH 50V 47P	1	
C820, 21	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	2	
D801	MA338	DIODE	1	
D803	1SS355	DIODE	1	
FP804	VJS4036B016	CONNECTOR (FEMALE)	1	
IC801	ET2070F0C	IC	1	
IC802	TA75S558F	IC	1	
IC803	PQ20VZ1U	IC	1	
L801	VLQ0426J6R8	COIL 6.8UH	1	
L803-05	VLQ0807K100	COIL 10UH	3	
L820	VLQ0779K100	COIL 10UH	1	
R802	ERJ3GEYG102	M. RESISTOR CH 1/16W 1K	1	
R805	ERJ3GEYG102	M. RESISTOR CH 1/16W 1K	1	
R807, 08	ERJ3GEYG102	M. RESISTOR CH 1/16W 1K	2	
R810	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1	
R812	ERJ3GEYG102	M. RESISTOR CH 1/16W 1K	1	
R813	ERJ3GEYG472	M. RESISTOR CH 1/16W 4.7K	1	
R814, 15	ERJ3GEYG471	M. RESISTOR CH 1/16W 470	2	
R816	ERJ3GEYJ223	M. RESISTOR CH 1/16W 22K	1	
R817	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R818	ERJ3GEYG682	M. RESISTOR CH 1/16W 6.8K	1	
R820	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	1	
R821	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	1	
R822	ERJ3RBD183	M. RESISTOR CH 3W 18K	1	
R823	ERJ3RBD272	M. RESISTOR CH 3W 2.7K	1	
R824	ERJ3RBD183	M. RESISTOR CH 3W 18K	1	
R825	ERJ3GEYG102	M. RESISTOR CH 1/16W 1K	1	
R826	ERJ3RBD102	M. RESISTOR CH 3W 1K	1	
R827	ERJ3RBD112	M. RESISTOR CH 3W 1.1K	1	
R828	ERJ3RBD272	M. RESISTOR CH 3W 2.7K	1	
W802, 03	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	2	
W805, 06	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	2	
BL820	VLL0210	LAMP	1	
C822	ECUX1A226MBS	C. CAPACITOR CH 10V 22U	1	
Q820	2SK2055	TRANSISTOR	1	
T820	ETJ1K730M	TRANSFORMER	1	
	VEP28255A	E. V. F. (B) C. B. A.	1	(RTL)

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
	■ VEP00258A	AV JACK C.B.A.	1	(RTL)
C4051, 52	ECUM1H472KBN	C. CAPACITOR CH 50V 4700P	2	
FL4051	VLF1445	FILTER	1	
FL4052	VLF1341B107	FILTER	1	
J4051	VJJ0612	AV JACK	1	
		MISCELLANEOUS		
	VQ5120	TAPE	1	
	VMZ2897	BARRIER	1	
	■ VEP06C60A	HALL SENSOR FLEX. CARD C.B.A.	1	(RTL)
IC991, 92	DN8797MSC	IC	2	
	■ VEP26204B	MONITOR C.B.A.	1	(RTL)
C901	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1	
C902	ECUX1C105KBM	C. CAPACITOR CH 16V 1U	1	
C903	ECUX1E471KBQ	C. CAPACITOR CH 25V 470P	1	
C904	ECUX1H150JCQ	C. CAPACITOR CH 50V 15P	1	
C905	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	1	
C906	ECUX1E561KBQ	C. CAPACITOR CH 25V 560P	1	
C907, 08	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	2	
C909	ECST0JY106Z	T. CAPACITOR CH6. 3V 10U	1	
C910	ECUX1C105KBM	C. CAPACITOR CH 16V 1U	1	
C911	ECUX1E222KBQ	C. CAPACITOR CH 25V 2200P	1	
C912	ECST0JY106Z	T. CAPACITOR CH6. 3V 10U	1	
C913	ECUX1C105KBM	C. CAPACITOR CH 16V 1U	1	
C914	ECUX1E102KBQ	C. CAPACITOR CH 25V 1000P	1	
C915	ECUX0J106VBM	C. CAPACITOR CH6. 3V 10U	1	
C916	ECST0JY106Z	T. CAPACITOR CH6. 3V 10U	1	
C917	ECUX1A105KBN	C. CAPACITOR CH 10V 1U	1	
C918	ECST1VX225Z	T. CAPACITOR CH 35V 2.2U	1	
C919	ECUX1A334KBV	C. CAPACITOR CH 10V 0.33U	1	
C920	ECST1AY475	T. CAPACITOR CH 10V 4.7U	1	
C922-27	ECUX1C104KBV	C. CAPACITOR CH 16V 0.1U	6	
C928	ECST0JY106Z	T. CAPACITOR CH6. 3V 10U	1	
C930-33	ECUX1E471KBQ	C. CAPACITOR CH 25V 470P	4	
D901	MA329	DIODE	1	
D902	MA111	DIODE	1	
FP901	VJS4194B026	CONNECTOR (FEMALE)	1	
FP902	VJS3319B008	CONNECTOR (FEMALE)	1	
FP903, 04	VJS3971B021	CONNECTOR (FEMALE)	2	
FP905	VJS3319B006	CONNECTOR (FEMALE)	1	
IC901	CM7018L3	IC	1	
IC902, 03	TA75S558F	IC	2	
IC904	TC7S14F	IC	1	
IC905	TC7S04FU	IC	1	
IC906, 07	TA75S558F	IC	2	
L901	VLQ0807K220	COIL 22UH	1	
L902	VLQ0426J100	COIL 10UH	1	
L903-10	VLQ0807K100	COIL 10UH	8	
Q901-04	ZSD2216	TRANSISTOR	4	
Q905, 06	XP4601	TRANSISTOR-RESISTOR	2	
QR901	XP4314	TRANSISTOR-RESISTOR	1	
QR902	MRN1104	TRANSISTOR	1	

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
R901	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R902	ERJ3GEYJ105	M. RESISTOR CH 1/16W 1M	1	
R903	ERJ3GEYJ683	M. RESISTOR CH 1/16W 68K	1	
R904	ERJ2GEJ223	M. RESISTOR CH 2W 22K	1	
R905	ERJ3GEYJ683	M. RESISTOR CH 1/16W 68K	1	
R906	ERJ2GEJ472	M. RESISTOR CH 2W 4.7K	1	
R907	ERJ2GEJ473	M. RESISTOR CH 2W 47K	1	
R908	ERJ3GEYJ124	M. RESISTOR CH 1/16W 120K	1	
R909	ERJ2GEJ333	M. RESISTOR CH 2W 33K	1	
R910	ERJ2GEJ104	M. RESISTOR CH 2W 100K	1	
R911	ERJ2GEJ472	M. RESISTOR CH 2W 4.7K	1	
R912	ERJ2GEJ471	M. RESISTOR CH 2W 470	1	
R916	ERJ3RBD182	M. RESISTOR CH 3W 1.8K	1	
R917	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	1	
R918	ERJ3GEY682	M. RESISTOR CH 1/16W 6.8K	1	
R919-21	ERJ2GEJ101	M. RESISTOR CH 2W 100	3	
R922, 23	ERJ2GEJ563	M. RESISTOR CH 2W 56K	2	
R924	ERJ3GEYJ333	M. RESISTOR CH 1/16W 33K	1	
R925	ERJ2GE0R00	M. RESISTOR CH 2W 0	1	
R926	ERJ2GEJ563	M. RESISTOR CH 2W 56K	1	
R927	ERJ2GE0R00	M. RESISTOR CH 2W 0	1	
R928	ERJ2GEJ333	M. RESISTOR CH 2W 33K	1	
R930	ERJ2GEJ333	M. RESISTOR CH 2W 33K	1	
R931	ERJ2GEJ682	M. RESISTOR CH 2W 6.8K	1	
R932	ERJ2GEJ223	M. RESISTOR CH 2W 22K	1	
R933	ERJ2GEJ103	M. RESISTOR CH 2W 10K	1	
R934	ERJ2GEJ473	M. RESISTOR CH 2W 47K	1	
R935	ERJ2GEJ103	M. RESISTOR CH 2W 10K	1	
R936	ERJ2GEJ104	M. RESISTOR CH 2W 100K	1	
R937	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R938	ERJ2GEJ682	M. RESISTOR CH 2W 6.8K	1	
R939	ERJ2GEJ103	M. RESISTOR CH 2W 10K	1	
R940	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R941	ERJ3GEYJ220	M. RESISTOR CH 1/16W 22	1	
R942	ERJ2GEJ104	M. RESISTOR CH 2W 100K	1	
R955	ERJ2GEJ563	M. RESISTOR CH 2W 56K	1	
R959	ERJ2RHD104	M. RESISTOR CH 2W 100K	1	
R960, 61	ERJ2GEJ223	M. RESISTOR CH 2W 22K	2	
W902	ERJ2GE0R00	M. RESISTOR CH 2W 0	1	
	■ VEP00259A	IR C.B.A.	1	(RTL)
C6401	ECUX1E104KBN	C. CAPACITOR CH 25V 0.1U	1	
C6402	ECST0JY106Z	T. CAPACITOR CH6. 3V 10U	1	
D6801	CL150HR-CD	DIODE	1	
D6802	PH310	DIODE	1	
IR6401	VEK8283	REMOTE CONTROL RECEIVER	1	
	■ VEP22279A	CCD FLEX. CARD C.B.A.	1	(RTL)
C294	ECST1VX225Z	T. CAPACITOR CH 35V 2.2U	1	
C295	ECUM1E104ZFN	C. CAPACITOR CH 25V 0.1U	1	
D291	VJP4009C020	CONNECTOR (MALE) 20P	1	
Q291	2SC3930	TRANSISTOR	1	
R292	ERJ6GEYF472	M. RESISTOR CH 1/10W 4.7K	1	
		MISCELLANEOUS		
	VJB22279	FLEX. CARD	1	

SECTION 5

VW – AD7E



SPECIFICATIONS

ITEM	SPECIFICATION
POWER	Source: AC 100 ~ 240 V, 50/60 Hz (Automatic Voltage Adjustment)
	Consumption: Approx. 20 W
	Output: DC 7.9 V, 9 W (Movie Camera Operation) DC 8.4 V, 1.2 A (Battery Pack Charging)
	Input: DC 12 V (Car Battery)
DIMENSIONS	102 (W) × 50 (H) × 79 (D) mm
WEIGHT	Approx. 230 g (Without AC Cable)

Weight and dimensions shown are approximate.
Specifications are subject to change without notice.

CAUTION: FOR USE WITH DIGITAL VIDEO CAMERA, MODEL NV-DS77, NV-DA1, NV-EX1 Series.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.

⚠ WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

CONTENTS

1. AC ADAPTOR SCHEMATIC DIAGRAM	2
2. AC ADAPTOR CIRCUIT BOARD DIAGRAM.....	5
3. EXPLODED VIEWS & MECHANICAL REPLACEMENT PARTS LIST	7
❶ AC ADAPTOR SECTION	7
❷ PACKING & ACCESSORIES SECTION	8
4. ELECTRICAL REPLACEMENT PARTS LIST.....	9

INTRODUCTION

Caution for AC CORD (VJA0940 type)

Information for Your Safety

IMPORTANT

Your attention is drawn to the fact that recording of pre-recorded tapes or discs or other published or broadcast material may infringe copyright laws.

WARNING

To reduce the risk of fire or shock hazard, do not expose this equipment to rain or moisture.

CAUTION

To reduce the risk of fire or shock hazard and annoying interference, use the recommended accessories only.

FOR YOUR SAFETY

■DO NOT REMOVE THE OUTER COVER.

To prevent electric shock, do not remove the cover. No user serviceable parts inside. Refer servicing to qualified service personnel.


Caution for AC Mains Lead

For your safety, please read the following text carefully.

This appliance is supplied with a moulded three-pin mains plug for your safety and convenience.

A 5-ampere fuse is fitted in this plug.

Should the fuse need to be replaced please ensure that the replacement fuse has a rating of 5 amperes and it is approved by ASTA or BSI to BS1362.

Check for the ASTA mark  or the BSI mark  on the body of the fuse.

If the plug contains a removable fuse cover you must ensure that it is refitted when the fuse is replaced.

If you lose the fuse cover, the plug must not be used until a replacement cover is obtained.

A replacement fuse cover can be purchased from your local Panasonic Dealer.

If the fitted moulded plug is unsuitable for the socket outlet in your home then the fuse should be removed and the plug cut off and disposed of safely.

There is a danger of severe electrical shock if the cut off plug is inserted into any 13-ampere socket.

If a new plug is to be fitted please observe the wiring code as shown below.

If in any doubt, please consult a qualified electrician.

■IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:


Blue: Neutral

Brown: Live

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:


the wire which is coloured BLUE must be connected to the terminal in the plug which is marked with the letter N or coloured BLACK.

The wire which is coloured BROWN must be connected to the terminal in the plug which is marked with the letter L or coloured RED.

Under no circumstances should either of these wires be connected to the earth terminal of the three pin plug, marked with the letter E or the Earth Symbol .


■Before use

remove the Connector Cover as follows.




■How to replace the Fuse


1. Remove the Fuse Cover with a screwdriver.




2. Replace the fuse and attach the Fuse cover.



1. AC ADAPTOR SCHEMATIC DIAGRAM



MODULE C. B. A. VEP60567A



NOTE1: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.


NOTE2: WHEN MEASURE THE DC VOLTAGE AND WAVEFORM, CONNECT THE GND READ OR GND PROBE TO NEXT GND.
PRIMARY SIDE: IC01-2 PIN OF THE MAIN C. B. A. (PRIMARY GND).
SECONDARY SIDE: P02-4 PIN OF THE MAIN C. B. A. (SECONDARY GND).

NOTE3: THE DC VOLTAGE INDICATED IN PRIMARY SIDE IS MEASURE WHEN INPUT AC 220V IS APPLIED.


2. AC ADAPTOR CIRCUIT BOARD DIAGRAM

IMPORTANT SAFETY NOTES:
COMPONENT IDENTIFIED THE MARK Δ HAVE THE SPECIAL CHARACTERISTICS FOR SAFETY.
WHEN REPLACING OF THESE COMPONENTS, USE ONLY THE SAME TYPE.
HOT CIRCUIT BE CAREFUL AND USE AN ISOLATION TRANSFORMER WHEN SERVICING.

MAIN C.B.A. (VEP61266A)




MODULE C.B.A. (VEP60567A)



❶ AC ADAPTOR SECTION




2. IMPORTANT SAFETY NOTICE

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.

[illegible]

② PACKING & ACCESSORIES SECTION



Note: 1. *Be sure to make your orders of replacement parts according to this list.

2. IMPORTANT SAFETY NOTICE

Components identified with the mark have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
101 (2)	VP68522	PACKING CASE U.	1	
102 (2)	VPN4784	PAD	1	
103 (2)	VEK8328	DC CABLE U.	1	
104 (2)	VJA1088	DC CABLE	1	
⚠ 105 (2)	VJA0998	AC CABLE	1	VW-A07E
⚠ 105 (2)	VJA0940	AC CABLE	1	VW-A07B
⚠ 105 (2)	VJA0754	AC CABLE	1	VW-A07A

[illegible]

4. ELECTRICAL REPLACEMENT PARTS LIST

Note: 1. Be sure to make your orders of replacement parts according to this list.
 2. IMPORTANT SAFETY NOTICE: Components identified with the mark Δ have the special characteristics for safety. When replacing any of these components, use only the same type.
 3. Unless otherwise specified,
 All resistors are in OHMS, K=1,000 OHMS. All capacitors are in MICROFARADS (uf), P=uuf.
 4. The P.C. Board units marked with \blacksquare show below the main assembled parts.
 5. The marking (RTL) indicates the retention time is limited for this item.
 After the discontinuation of this assembly in production, it will no longer be available.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
Δ	\blacksquare VEP61266A	MAIN C. B. A.	1	(RTL)
	\blacksquare VEP60567A	MODULE C. B. A.	1	(RTL)
Δ F01	XBA2C10TBOL	FUSE	1	
Δ	\blacksquare VEP61266A	MAIN C. B. A.		(RTL)
Δ C01	VCF0183M473	POLYESTER FILM CAPACITOR	1	
Δ C02, 03	VCK0258M102	CERAMIC CAPACITOR	2	
C04	VCEA2GAT330	E. CAPACITOR 400V 33U	1	
C05	ECQE2473KF	P. CAPACITOR 250V 0.047U	1	
C06	EGCZ3A560K6E	C. CAPACITOR 1KV 56P	1	
C07	ECAT1HHG3R3	E. CAPACITOR 50V 3.3U	1	
C08	EGAOJHG471	E. CAPACITOR 6.3V 470U	1	
C09	ECUM1H102KBN	C. CAPACITOR CH 50V 1000P	1	
C10	ECUM1C224KBN	C. CAPACITOR CH 16V 0.22U	1	
C21	EEUFA1C821	E. CAPACITOR 16V 820U	1	
C22	EGAT1CHG471	E. CAPACITOR 16V 470U	1	
C23	ECAT1VHG101	E. CAPACITOR 35V 100U	1	
C24	EGEA1CKG100	E. CAPACITOR 16V 10U	1	
C25	ECUM1E104ZFN	C. CAPACITOR CH 25V 0.1U	1	
D01	S1WBA80	DIODE	1	
D02	ERA22-08	DIODE	1	
D03	MA185	DIODE	1	
D04	MA4360L	DIODE	1	
D21	F5KF20	DIODE	1	
D22	MA185	DIODE	1	
D23	MA4120	DIODE	1	
D24	MA185	DIODE	1	
D25	MA165VT	DIODE	1	
Δ D201	ERZVA50471	TRANSIENT/SURGE ABSORBER	1	
Δ FL01	ELF15N003A	LINE FILTER	1	
IC01	MIP0224SY	IC	1	
IC21	UPC78N05H	IC	1	
JK21	VJJ0576	DC JACK	1	
JK22	VJJ0608	DC JACK (4P)	1	
L21	VLP0056	COIL	1	
L22	VLP0137	COIL	1	
Δ P01	VJS3306	AC INLET	1	
P02	VWJ13NB0700Q	FLAT CARD CABLE	1	
Δ PC01	PG123FY2	PHOTO COUPLER	1	
Q01	XN4601	TRANSISTOR-TRANSISTOR	1	
Q21, 22	2SA1897	TRANSISTOR	2	
QR21	XN1214	TRANSISTOR-RESISTOR	1	
R01	ERG2SJ683	M. RESISTOR 2W 68K	1	
R02	ERJ8GEYJ330	M. RESISTOR CH 1/8W 33	1	
R03	ERDS2TJ220	C. RESISTOR 1/4W 22	1	
R04	ERDS2TJ272	C. RESISTOR 1/4W 2.7K	1	
R05	ERJ6GEYG102	M. RESISTOR CH 1/10W 1K	1	
R06, 07	ERJ6GEYG474	M. RESISTOR CH 1/10W 470K	2	
R08	ERJ6GEYG102	M. RESISTOR CH 1/10W 1K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R22	ERX1SZGR10	M. RESISTOR 1W 0.1	1	
R23	ERG2SJ151	M. RESISTOR 2W 150	1	
R24	ERJ6GEYG512	M. RESISTOR CH 1/10W 5.1K	1	
R25	ERJ6GEYG152	M. RESISTOR CH 1/10W 1.5K	1	
R26, 27	ERJ8GEYJ151	M. RESISTOR CH 1/8W 150	2	
R28	ERJ6GEYG102	M. RESISTOR CH 1/10W 1K	1	
R29, 30	ERJ8GEYJ151	M. RESISTOR CH 1/8W 150	2	
Δ T01	VLT0905	TRANSFORMER	1	
VR21	EVMF6SA00B14	V. RESISTOR 10K	1	
		MISCELLANEOUS		
	VSC4733	HEAT SINK	1	
	XTB26+6G	SCREW	2	
	VSC4744	SHIELD COVER	1	
	\blacksquare VEP60567A	MODULE C. B. A.		(RTL)
C202	ECUM1E104ZFN	C. CAPACITOR CH 25V 0.1U	1	
C203-06	ECUM1E104KBN	C. CAPACITOR CH 25V 0.1U	4	
C207	ECUM1C105ZFN	C. CAPACITOR CH 16V 1U	1	
C208, 09	ECUM1E104ZFN	C. CAPACITOR CH 25V 0.1U	2	
C210	ECUM1C224KBN	C. CAPACITOR CH 16V 0.22U	1	
C211-16	ECUM1E104ZFN	C. CAPACITOR CH 25V 0.1U	6	
C217	ECUX1E104ZFN	C. CAPACITOR CH 25V 0.1U	1	
C219	ECUX1E104ZFN	C. CAPACITOR CH 25V 0.1U	1	
C220	ECUM1E104ZFN	C. CAPACITOR CH 25V 0.1U	1	
C221	ECUX1E104ZFN	C. CAPACITOR CH 25V 0.1U	1	
C222	ECUM1E104ZFN	C. CAPACITOR CH 25V 0.1U	1	
C223-25	ECUX1E104ZFN	C. CAPACITOR CH 25V 0.1U	3	
C226	ECUM1E104ZFN	C. CAPACITOR CH 25V 0.1U	1	
C227, 28	ECUX1E104ZFN	C. CAPACITOR CH 25V 0.1U	2	
D201	LN276RPX	DIODE	1	
D202-07	LN376GPX	DIODE	6	
D208	MA152WA	DIODE	1	
D209, 10	MA128	DIODE	2	
D211, 12	MA3062M	DIODE	2	
D215, 16	MA3062M	DIODE	2	
IC203	NJM2902M	IC	1	
IC204	NJU7034M	IC	1	
IC205	LU5K68B4	IC	1	
P202	VEK8306	BATTERY CATCHER	1	
Q201	2SD601A	TRANSISTOR	1	
Q203	XN4601	TRANSISTOR-TRANSISTOR	1	
QR203	XN1114	TRANSISTOR-RESISTOR	1	
QR205	XN1211	TRANSISTOR-RESISTOR	1	
R201	ERJ6GEYG331	M. RESISTOR CH 1/10W 330	1	
R202-04	ERJ6GEYG181	M. RESISTOR CH 1/10W 180	3	
R205, 06	ERJ6GEYG392	M. RESISTOR CH 1/10W 3.9K	2	
R207	ERJ3RBD123	M. RESISTOR CH 1/16W 12K	1	
R208	ERJ3RBD133	M. RESISTOR CH 1/16W 13K	1	
R210	ERJ3GEYG332	M. RESISTOR CH 1/16W 3.3K	1	
R211	ERJ3GEYJ103	M. RESISTOR CH 1/16W 10K	1	
R212	ERJ6RED134	M. RESISTOR CH 1/10W 130K	1	
R213	ERJ3RBD392	M. RESISTOR CH 1/16W 3.9K	1	
R214	ERJ3GEYG332	M. RESISTOR CH 1/16W 3.3K	1	
R215	ERJ3GEYG102	M. RESISTOR CH 1/16W 1K	1	
R216	ERJ6GEYG102	M. RESISTOR CH 1/10W 1K	1	
R217, 18	ERJ3GEYG332	M. RESISTOR CH 1/16W 3.3K	2	
R219	ERJ3GEYJ221	M. RESISTOR CH 1/16W 220	1	
R220	ERJ6GEYG102	M. RESISTOR CH 1/10W 1K	1	
R221	ERJ6RBD102	M. RESISTOR CH 1/10W 1K	1	
R222	ERJ3RBD243	M. RESISTOR CH 1/16W 24K	1	
R223	ERJ3GEYG472	M. RESISTOR CH 1/16W 4.7K	1	
R224, 25	ERJ6RBB473	M. RESISTOR CH 1/10W 47K	2	
R226	ERJ6RED204	M. RESISTOR CH 1/10W 200K	1	
R227	ERJ3RBD104	M. RESISTOR CH 1/16W 100K	1	

[illegible]

Panasonic